

ELJ HINGED WINDOW ENCLOSURE



ELJ HINGED WINDOW ENCLOSURE



- A. Apply strip gasket provided with bolt pack to the exterior back of the enclosure.
- B. Start applying the strip gasket centered at the bottom of the enclosure.
- C. The strip gasket needs to be applied in one continuous path, on the outside of each mounting hole.
- D. End with the strip gasket seam centered at bottom of the enclosure, flush to the starting point.