



SOLOTEMPERATURE CONTROLLER USER MANUAL

Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number: SL-USER-M
Issue: 2nd Edition Rev. D
Issue Date: 04/18

Publication History		
Issue	Date	Description of Changes
First Edition	06/07	Original Issue
Rev. A	09/07	Revised parameter ranges, made corrections, added Index
Rev. B	11/07	Revised analog parameters, updated specifications table
Rev. C	07/08	Revised analog parameters, updated specifications table
Rev D	06/10	Revised PC connection information
Rev. E	10/10	Added ungrounded thermocouple note
Rev. F	12/10	Added note to Analog High and Analog Low Adjustment.
2nd Edition	07/11	Added DC controllers
Rev. A	12/11	Revised wiring diagrams
Rev. B	12/15	Revised Relay output specification for SL4848 and SL4896.
Rev. C	04/18	Revised Chapter 6. Most content included in online help. Comm Port settings updated.
Rev. D	04/18	Added PV Offset parameter tables. Revised manual layout.