



TABLE OF CONTENTS

Chapter 1: Hardware

Introduction	1-2
The Purpose of This User’s Manual.....	1-2
Technical Support.....	1-2
Conventions Used	1-2
STRIDE Pocket Portal Product Overview	1-3
Hardware Overview.....	1-3
Specifications.....	1-4
Dimensions.....	1-6
Installation	1-7
Installation and Removal Procedures.....	1-7
Wiring.....	1-8
Operation	1-14
LED Status Indicators.....	1-14
Bluetooth Control.....	1-14
Reset to Factory Default.....	1-14
Agency Approvals	1-15
Applicable Safety Standards.....	1-15
FCC Compliance.....	1-15
Certifications.....	1-15

Chapter 2: STRIDE Pocket Portal Platform

Overview	2-2
Terms of Use.....	2-2
Getting started	2-3
Setting up the Pocket Portal account	2-3
Create a new Stride Pocket Portal cloud account.....	2-3
Setting up the Pocket Portal device	2-4

Table of Contents

Installing Pocket Portal App on a mobile device	2-4
Add a new Pocket Portal device	2-5
Using the STRIDE Pocket Portal Web App	2-9
Main Web app interface	2-9
Device page—viewing live data and editing device settings.....	2-9
Device Profile page—configuring connections to Modbus and local I/O.....	2-14
Rules page—set email notifications triggered by data values.....	2-24
Settings page—updating account, user, organization, and subscriptions	2-26
Data Logs page—viewing recent data online	2-32
Export logs page—downloading historical log data to your PC.....	2-33
Firmware page—updating device firmware.....	2-34
Device Diagnostics page—information for technical support	2-35
Help page—accessing online documentation	2-35
Notifications.....	2-36
Using STRIDE Pocket Portal on Your Mobile Device	2-37
Installing Pocket Portal App on a mobile device	2-37
View Device List in mobile app.....	2-38
View and edit live data	2-38
Change device settings, profile, and Wi-Fi network.....	2-38
View Notifications.....	2-39
Change or Create Organization.....	2-39
Help	2-40
Report Issue.....	2-40
Other Settings.....	2-40
View or Export Data Logs.....	2-40

Appendix A: Troubleshooting

Initial Setup Issues	A-2
I can't see the Pocket Portal device from my mobile app.....	A-2
My Pocket Portal unit doesn't show up in my dashboard.....	A-3
Not receiving data from my Modbus device	A-4

Appendix B: Safety and Security Considerations

Security Considerations for Control Systems Networks.....	B-2
Safety Guidelines.....	B-3

Appendix C: Data Logging Address Notation – AutomationDirect Devices

Pocket Portal Modbus to AutomationDirect PLC Address Maps	C-2
CLICK PLCs.....	C-2
DirectLogic PLCs	C-5
Do-more PLCs.....	C-7
Productivity Series PLCs	C-9