



Errata Sheet

This Errata Sheet contains corrections or changes made after the publication of this manual.

Product Family: Terminator I/O **Date:** December 2018
Manual Number: T1K-DEVNETS-M
Revision and Date: 1st Edition; November 2001

Changes to Chapter 2. Installing the T1K-DEVNETS Base Controller

Page 2-9. Configuring the Controller; Status Indicators

Replace the top portion of the table [MS (Module Status) Indicator] with the table below.

Two new rows were added for Flashing Green and Flashing Red.

No changes were made to the lower portion of the table [NS (Network Status) Indicator].

MS (Module Status) Indicator	
Indication	Status
OFF	No power to Controller. Check wiring.
ON (Green)	Power applied to Controller, no fault
ON (Red)	Critical Controller Fault
Flashing Green	In Firmware Update Mode
Flashing Red	I/O system error Missing module error New module present error I/O diagnostic error