

Table of Contents

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Where to Begin	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Chapters	1-3
Appendices	1-3
What is Remote I/O?	1-4
When Do You Need Remote I/O?	1-4
Remote I/O Communication Protocols	1-5
Number of Masters and Slaves Allowed (RM-NET)	1-6
Distance Between Slaves and Master, Baud Rates (RM-NET)	1-6
Number of Masters and Slaves Allowed (SM-NET)	1-7
Distance Between Slaves and Master, Baud Rates (SM-NET)	1-7
Choosing the Protocol Mode – RM-NET vs. SM-NET	1-8
How the CPU Updates Remote I/O Points	1-9
3 Easy Steps for Setting Up Remote I/O	1-10
Design the Remote I/O System	1-10
Install the Components	1-10
Write the Setup Program	1-10
Frequently Asked Questions	1-11
Determine the Hardware Configuration	1-11

Chapter 2: D2-RMSM / T1K- RSSS Remote I/O System

Remote Master (D2-RMSM) Features	2-2
Functional Specifications	2-2
Physical Specifications	2-3
Auto Return to Network Option	2-3
Remote Slave (T1K-RSSS) Features	2-4
Functional Specifications	2-4
Functional Specifications	2-4
Physical Specifications	2-5
Serial Port Pinout	2-5
Setting the Rotary Switches	2-6
Setting the DIP Switches	2-7
Determine the System Layout	2-9
Determine I/O Needed and How Many Masters & Slaves	2-9
Define the System Details By Using Worksheets	2-10
Completing the Channel Configuration Worksheet (top half)	2-10
Completing the Remote Slave Worksheet for Slave #1	2-11
Completing the Remote Slave Worksheet for Slave #2	2-12
Completing the Remote Slave Worksheet for Slave #3	2-13
Completing the Channel Configuration Worksheet (bottom half)	2-14
Connecting the Wiring	2-15
General Wiring Guidelines	2-15
Cable Recommendation	2-15
Cabling Between the Master and Slaves	2-15
Termination Resistors	2-16

Chapter 3: D2–RMSM Setup Programming and Troubleshooting

Getting Started with the Programming	3–2
Writing the Remote I/O Setup	3–3
Step 1: Decide How You Are Going to Call Your Program	3–3
Step 2: Write the Setup Logic for Each Channel	3–4
Example Program Using Discrete I/O Modules	3–5
Example 1: Addressing using X and Y Memory	3–5
Example Program Using Analog I/O Modules	3–10
Example 2: Addressing using V–Memory	3–10
Changing Configurations	3–16
Shared Memory Table for D2–RMSM Remote Master	3–17
Troubleshooting Remote I/O	3–25
Troubleshooting Quick Steps	3–25
Troubleshooting Chart	3–26
Special CPU Memory for Diagnostics	3–27
Communication Status Flags in V-memory	3–27
Error Flags in V-memory	3–28
D2–RMSM Memory for Diagnostics	3–29
Hardware Status	3–29
Bus Scan Status	3–29
Network Errors	3–29
How to Access Diagnostics Information	3–30
Example 1: Reading Diagnostic Errors	3–31
Example 2: Writing Bus Scan Overlimit and Reading Bus Scan Status	3–32

Chapter 4: DL250 / DL350 / DL450 CPU With T1K–RSSS Remote I/O System

DL250/DL350/DL450 CPU Bottom Port as Remote Master	4–2
Remote Slave (T1K–RSSS) Features	4–3
Functional Specifications	4–3
Physical Specifications	4–4
Configuring the Bottom Port of the DL250/DL350/DL450 CPU	4–5
Setting the T1K–RSSS Rotary Switches	4–6
Setting the T1K–RSSS DIP Switches	4–7
Example Program Using Discrete I/O Modules	4–9
Example 1: Using X and Y Addresses as the Remote I/O Memory Types	4–9
Example Program Using Analog I/O Modules	4–14
Example 2: Using V Memory Addresses as the Remote I/O Memory Type	4–14
DL250/DL350/DL450 Reserved Memory for Bottom Port as Remote Master	4–18
DL250/DL350/DL450 V Memory Port Setup Registers	4–19
Connecting the Wiring	4–20
Cabling Between the D2–250 CPU Bottom Port and Slaves	4–20
Cabling Between the D3–350/D4–450 CPU Bottom Port and Slaves	4–21
Special CPU Memory for Diagnostics	4–22

Appendix A: Remote I/O Worksheets

Appendix B: Terminator Analog I/O

Analog Input Module	B-2
Scaling the Input Data	B-2
Example 1: Scaling 4–20mA Input Signal	B-2
Example 2: Scaling Unipolar and Bipolar Input Signals	B-3
Analog Output Module	B-4
Calculating the Digital Value	B-4
Engineering Unit Conversion	B-4

Appendix C: Determining I/O Update Time

Overview	C-2
Remote I/O Update Table	C-3
Remote Scan Time Formula	C-3
D2–RMSM: Calculating Total Delay for the System	C-4
Total Delay Time Formulas	C-5
D2–RMSM Delay Time Example	C-6

Appendix D: I/O Module Hot Swap

T1K–RSSS I/O Module Hot Swap Feature	D-2
Check External 24VDC Wiring Before Hot Swapping!	D-2
Hot Swap: I/O Module Replacement	D-3
Outputs Enable / Disable Switch	D-3