

HOW TO REPLACE THE TIP

1. Use only genuine QUICK FX3 replacement tips.
2. Ensure QUICK FX3 Heat Tool switch is in the OFF position.
Allow tip to cool completely before replacing tip.
3. Unscrew old tip by rotating translucent locking nut counterclockwise.
4. Screw in new tip by rotating translucent locking nut clockwise until it snaps into the lock position.
5. Do not file tip.

Knurled Nut
Locking Nut
LED Light



Note: Align the notch on the housing to install the new tip.

To adjust the direction of tip:

Rotate the black knurled nut to adjust the direction of the tip.

⚠ WARNING

- Lithium-ion Batteries and/or products that contain Lithium-ion Batteries can expose you to chemicals including cobalt lithium nickel oxide, and nickel, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov
- This product when used for soldering and similar applications, can expose you to chemicals including lead known to the State of California to cause cancer and birth defects (or other reproductive harm). For more information go to www.P65Warnings.ca.gov. **Note: Lead-free solder is recommended.**



Wall Lenk Corporation

PO Box 3349
252-527-4186

Kinston, N.C. 28502-3349
Fax 252-527-4189