


| No. | Tone   | dB(A) max. |
|-----|--------|------------|
| T1  | 1.6kHz | 88         |
| T2  | 3.4kHz | 100        |
| T3  | 1.6kHz | 88         |
| T4  | 3.4kHz | 100        |
| T5  | 1.6kHz | 86         |
| T6  | 3.4kHz | 96         |
| T7  | 3.4kHz | 90         |


0 - 100 dB(A)



| 1    | 2    | 3    | 4 | 5 | No. |
|------|------|------|---|---|-----|
| NC   | NC   | NC   | - | - | -   |
| +24V | +24V | NC   | - | - | T1  |
| +24V | +24V | +24V | - | - | T2  |
| +24V | NC   | NC   | - | - | T3  |
| +24V | NC   | +24V | - | - | T4  |
| NC   | +24V | NC   | - | - | T5  |
| NC   | +24V | +24V | - | - | T6  |
| NC   | NC   | +24V | - | - | T7  |




| 1  | 2    | 3    | 4    | 5 | No. |
|----|------|------|------|---|-----|
| S1 | NC   | NC   | NC   | - | -   |
|    | +24V | +24V | NC   | - | T1  |
|    | +24V | +24V | +24V | - | T2  |
|    | +24V | NC   | NC   | - | T3  |
|    | +24V | NC   | +24V | - | T4  |
|    | NC   | +24V | NC   | - | T5  |
|    | NC   | +24V | +24V | - | T6  |
|    | NC   | NC   | +24V | - | T7  |




| 1  | 2  | 3    | 4    | 5    | No. |
|----|----|------|------|------|-----|
| S1 | S2 | NC   | NC   | NC   | -   |
|    |    | +24V | +24V | NC   | T1  |
|    |    | +24V | +24V | +24V | T2  |
|    |    | +24V | NC   | NC   | T3  |
|    |    | +24V | NC   | +24V | T4  |
|    |    | NC   | +24V | NC   | T5  |
|    |    | NC   | +24V | +24V | T6  |
|    |    | NC   | NC   | +24V | T7  |



| 1  | 2  | 3  | 4    | 5    | No. |
|----|----|----|------|------|-----|
| S1 | S2 | S3 | NC   | NC   | -   |
|    |    |    | +24V | +24V | T1  |
|    |    |    | +24V | NC   | T3  |
|    |    |    | NC   | +24V | T5  |



| 1  | 2  | 3  | 4  | 5    | No. |
|----|----|----|----|------|-----|
| S1 | S2 | S3 | S4 | NC   | -   |
|    |    |    |    | +24V | T3  |



Vor Tonänderung ist die Versorgungsspannung auszuschalten / Power supply must be switched off before tone is changed / L'Alimentation doit être interrompue avant que le son soit changé.


310.844.004.0113

| No. | Tone   | dB(A) max. |
|-----|--------|------------|
| T1  | 1.6kHz | 88         |
| T2  | 3.4kHz | 100        |
| T3  | 1.6kHz | 88         |
| T4  | 3.4kHz | 100        |
| T5  | 1.6kHz | 86         |
| T6  | 3.4kHz | 96         |
| T7  | 3.4kHz | 90         |


0 - 100 dB(A)



| 1    | 2    | 3    | 4 | 5 | No. |
|------|------|------|---|---|-----|
| NC   | NC   | NC   | - | - | -   |
| +24V | +24V | NC   | - | - | T1  |
| +24V | +24V | +24V | - | - | T2  |
| +24V | NC   | NC   | - | - | T3  |
| +24V | NC   | +24V | - | - | T4  |
| NC   | +24V | NC   | - | - | T5  |
| NC   | +24V | +24V | - | - | T6  |
| NC   | NC   | +24V | - | - | T7  |




| 1  | 2    | 3    | 4    | 5 | No. |
|----|------|------|------|---|-----|
| S1 | NC   | NC   | NC   | - | -   |
|    | +24V | +24V | NC   | - | T1  |
|    | +24V | +24V | +24V | - | T2  |
|    | +24V | NC   | NC   | - | T3  |
|    | +24V | NC   | +24V | - | T4  |
|    | NC   | +24V | NC   | - | T5  |
|    | NC   | +24V | +24V | - | T6  |
|    | NC   | NC   | +24V | - | T7  |




| 1  | 2  | 3    | 4    | 5    | No. |
|----|----|------|------|------|-----|
| S1 | S2 | NC   | NC   | NC   | -   |
|    |    | +24V | +24V | NC   | T1  |
|    |    | +24V | +24V | +24V | T2  |
|    |    | +24V | NC   | NC   | T3  |
|    |    | +24V | NC   | +24V | T4  |
|    |    | NC   | +24V | NC   | T5  |
|    |    | NC   | +24V | +24V | T6  |
|    |    | NC   | NC   | +24V | T7  |



| 1  | 2  | 3  | 4    | 5    | No. |
|----|----|----|------|------|-----|
| S1 | S2 | S3 | NC   | NC   | -   |
|    |    |    | +24V | +24V | T1  |
|    |    |    | +24V | NC   | T3  |
|    |    |    | NC   | +24V | T5  |



| 1  | 2  | 3  | 4  | 5    | No. |
|----|----|----|----|------|-----|
| S1 | S2 | S3 | S4 | NC   | -   |
|    |    |    |    | +24V | T3  |



Vor Tonänderung ist die Versorgungsspannung auszuschalten / Power supply must be switched off before tone is changed / L'Alimentation doit être interrompue avant que le son soit changé.

310.844.004.0113