



Stepping Drive Accessories

Ever Studio Drive Software

Ever Studio is a Windows PC software tool for the configuration of Ever's LW4D and LW3A series stepper drives. The software allows easy modification of drive parameters. Ever Studio allows more flexibility in configuring a motor than DIP switches. For example, LW3A has 6 DIP switch options for Step Angle, but Ever Studio can set the drive for many other microstep settings. Ever Studio also allows jogging/indexing of LW4D and has a built-in oscilloscope to help with tuning and debugging the LW4D.

System requirements:

- CPU: Intel i3 or better
- Operating System: Windows 7/8/8.1/10/11
- Memory: 512MB over the Windows OS requirement
- Hard Disk: 50MB free space
- Communications Interface: PC's USB to the drive's serial service interface (using [EVER-PGM-1](#) or [EVER-PGM-2](#) cable)



Ever Studio

Ever Stepper Drive Software			
Part Number	Price	Description	Use With
EVER-STUDIO	Free	Ever Motion Solutions Windows configuration software, free download only. For use with Ever Motion Solutions stepper drives with service interface port. Requires PC USB port.	LW4D3070N2I1-00 LW3A9030N2A1-00



ATTENTION!!!
Correct insertion
direction of the
CN6: TAB UP.

