
GS20(X) Optional Accessories – Keypad


GS20(X) Replacement Keypad

The GS20A-KPD can be used to replace the keypad that comes with each GS20 drive. The replacement keypad can be plugged directly into the drive (no screws needed) or mounted remotely using M3 screws and a keypad extension cable.


GS20-KPD Replacement Keypad				
Price	Part	Screw	Torque	
\$4c6g:	GS20A-KPD	М3	8–9 kg·cm (6.947.81 lb-in.) [0.78–0.88 N·m]	







Direct Mounting on Plate



Embedded Mounting in Plate

GS20 Keypad Extension Cables

The default GS20 keypad is removable and can be remote installed if desired. Use one of the cables below to connect the remotely installed keypad back to the GS20 drive.

GS20 Keypad Compatible Extension Cables			
Price	Cable	Length (m [ft])	
\$04yo:	GS-CBL2-1L	1 [3.28]	
\$04yp:	GS-CBL2-3L	3 [9.84]	
\$04yq:	GS-CBL2-5L	5 [16.4]	