


## XGB PLC Replacement Terminals

| Part Number                         | Price    | Function                                                            | Description                                                                                                      | Compatible With                                                         |
|-------------------------------------|----------|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| <a href="#"><u>XGB-CON-3PBC</u></a> | \$6dkp:  | LS Bus coupler power connector, 3 pole                              | LS Electric XGB terminal block, 3-pin screw type, replacement. For use with LS Electric XGB series bus coupler.  | XEL-BSSCT<br>XEL-BSSRT                                                  |
| <a href="#"><u>XGB-CON-3PX</u></a>  | \$;5]5u: | LS XEM Processor Power 3 pole , Tab Lock, Assembly Connector & Wire | LS Electric XGB terminal block, 3-pin with cable pigtail, replacement. For use with LS Electric XEM-DxxxHx PLCs. | XEM-DN32H2, XEM-DN32HP,<br>XEM-DP32H2, XEM-DP32HP                       |
| <a href="#"><u>XGB-CON-5PX</u></a>  | \$;5]5t: | LS XEM Processor Serial Communication 5 Pole, Screw Lock            | LS Electric XGB terminal block, 5-pin spring clamp, replacement. For use with LS Electric XEM-DxxxHx PLCs.       | XEM-DN32H2, XEM-DN32HP,<br>XEM-DP32H2, XEM-DP32HP                       |
| <a href="#"><u>XGB-CON-8P</u></a>   | \$;5]5v: | LS XGB PLC IO Connector 8 Pole                                      | LS Electric XGB terminal block, 8-pin screw type, replacement. For use with LS Electric XGB series I/O modules.  | XBE-DC16A, XBE-DC16B,<br>XBE-TN16A, XBE-TP16A,<br>XBF-AD08A             |
| <a href="#"><u>XGB-CON-9P</u></a>   | \$;5]5x: | LS XGB PLC IO Connector 9 Pole                                      | LS Electric XGB terminal block, 9-pin screw type, replacement. For use with LS Electric XGB series I/O modules.  | XBE-RY08B, XBE-RY16A                                                    |
| <a href="#"><u>XGB-CON-10P</u></a>  | \$;5]5y: | LS XGB PLC IO Connector 10 Pole                                     | LS Electric XGB terminal block, 10-pin screw type, replacement. For use with LS Electric XGB series I/O modules. | XBE-DC16A, XBE-DC16B,<br>XBE-TN16A, XBE-TP16A,<br>XBF-AD08A, XBE-AC08A  |
| <a href="#"><u>XGB-CON-11P</u></a>  | \$;5]5q: | LS XGB PLC IO Connector 11 Pole                                     | LS Electric XGB terminal block, 11-pin screw type, replacement. For use with LS Electric XGB series I/O modules. | XBF-AD04A , XBF-AH04A,<br>XBF-DV04A, XBF-DV04C,<br>XBF-DC04A, XBF-DC04C |
| <a href="#"><u>XGB-CON-15P</u></a>  | \$;5]5s: | LS XGB PLC IO Connector 15 Pole                                     | LS Electric XGB terminal block, 15-pin screw type, replacement. For use with LS Electric XGB series I/O modules. | XBF-AD04C                                                               |



**XGB-CON-3PX**



**XGB-CON-9P**



**XGB-CON-15P**



**XGB-CON-3PBC**