
ReeR MOSAIC-MO4L Output Expansion Unit



The ReeR MOSAIC (MOdular SAfety Integrated Controller) MO4L output expansion unit provides additional OSSD outputs.

Features

- Four configurable I/O for start/restart interlock, external device monitoring (EDM) and output status monitoring
- Four individual or two pair OSSD safety outputs (PNP 400mA)
- · LED status and fault diagnostics indicator
- Removable terminal block plus screw contacts
- · Connection to M1S via MSC 5-way ReeR proprietary bus. Bus connector included.





MOSAIC-MO4L

Safety Data per EN 13849-1				
Category	4			
Performance level	е			
MTTF _d (years)	30-100			
DC _{avg}	High			
Safety Data per	IEC/EN 62061, IEC/EN 61508			
SIL CL	3			
SIL	3			
HFT	1			
DC _{avg}	High			
SFF	99.8%			
PFH _d (t-20a)	1.11e ⁻⁸			

Safety data is dependent on circuit architecture. See manual for further details.

MOSAIC-MO4L Expansion Unit						
Part Number	Price	Voltage	Description	Connection		
MOSAIC-MO4L	\$057h_:	24VDC	Output expansion unit providing 4 single or 2 pair OSSD outputs and 4 configurable I/O	Removable terminal block, screw contacts		







MOSAIC-MO4L Specifications					
General Specifications					
Operating Temperature	-10°C to +55°C [14°F to 131°F]				
Storage Temperature	-20°C to +85°C [-4°F to 185°F]				
Altitude	2000m (max)				
Vibration Resistance	Tested to IEC 60068-2-6				
Degree of Protection	IP 20				
Housing	Polyamide				
Weight	240g [8.47 oz]				
Agency Approvals and Standard	cULus, CE, TÜV				
Terminal Designation per EN 50 005	AWG 12-30 solid/stranded. Use 60/75°C copper (Cu) conductor only.				
Wire Fixing	Screw pluggable terminal blocks. Terminal tightening torque 5-7 lb•in (0.6-0.7 N•m).				
	Specifications				
Nominal Voltage	24VDC				
Voltage Range	± 20%				
Maximum Consumption	3W				
Digital Inputs	None				
Test Outputs	None				
OSSD Outputs	4 individual or 2 pair solid state safety outputs PNP active high 400mA@24VDC max				
Configurable I/O	4 terminals to be used for I/O Input: EDM, feedback, reset, restart Output: status monitoring				

Note: See product manual for complete details.

Note: To obtain the most current agency approval information, see the Agency Approval Checklist section on the specific part number's web page.

Electrical Connections to MOSAIC-MO4L




- Wire size range: AWG 12-30 (solid/stranded) (UL).
- Use 60/75°C copper (Cu) conductor only.
- Turn off power before making connections.
- The supply voltage must be 24VDC \pm 20% (PELV, in compliance with the standard EN 60204-1 (Chapter 6.4).
- Do not use the MOSAIC to supply external devices.
- The same ground connection (0VDC) must be used for all system components.
- Separate power supplies are recommended for the safety modules and for other electrical power equipment (electric motors, inverters, frequency converters) or other sources of disturbance.
- Cables used for connections of longer than 50m [164ft] must have a cross-section of at least 1mm² (AWG16).

This expansion unit works only with the M1S controller.

Dimensions

mm [inches]



MO4L Module Connections						
Terminal	Signal	Туре	Description			
1	24VDC	_	24VDC power supply			
2	NODE_SEL0	Input	Made calculian			
3	NODE_SEL1	Input	Node selection			
4	0VDC	-	0VDC power supply			
5	OSSD1	Output	Static safety output 1			
6	OSSD2	Output	Static safety output 2			
7	RESTART_FBK1 or	Input	Feedback/Restart 1			
/	STATUS1	Output	SIL 1 / PLc			
8	RESTART_FBK2 or	Input	Feedback/Restart 2			
0	STATUS2	Output	SIL 1 / PLc			
9	OSSD3	Output	Static safety output 3			
10	OSSD4	Output	Static safety output 4			
44	RESTART_FBK3 or	Input	Feedback/Restart 3			
11	STATŪS3	Output	SIL 1 / PLc			
12	RESTART_FBK4 or	Input	Feedback/Restart 4			
12	STATŪS4	Output	SIL 1 / PLc			

Please see the ReeR MOSAIC supplemental manual for basic wiring.





MODULAR **SA**FETY INTEGRATED CONTROLLER

The MOSAIC system is a unique safety controller that's modular, expandable and configurable for managing all safety functions of a single machine or an entire plant. It offers cost reductions with minimal wiring.

COMMS



MOSAIC-MBEI

Industrial Fieldbus: EtherNet/IP.

MOSAIC-MBEM

Industrial Fieldbus: ModBus TCP/IP.

DIGITAL INPUTS



MOSAIC-MI8

8 digital inputs and four test outputs.

MOSAIC-MI16

16 digital inputs and 4 test outputs.

MOSAIC-MI12T8

12 digital inputs, 8 test outputs.

I/O EXPANSION UNIT



MOSAIC-MI8O2

8 digital inputs, 2 EDM/ RST inputs, 4 test outputs, 2 OSSD pairs, and 2 status outputs.

MOSAIC-MI8O4

- 8 digital inputs, 4 test outputs,
- 4 individual or 2 pair OSSD outputs, and
- 4 configurable I/O.

SPEED MONITORING

MOSAIC-MV0

2 prox switch inputs.

MOSAIC-MV1T

1 TTL encoder and 2 prox switch inputs.



MOSAIC-MV1H

1 HTL encoder and 2 prox switch inputs.

MOSAIC-MV1S

1 SIN/COS encoder and 2 prox switch inputs.

MOSAIC-MV2T

2 TTL encoder and 2 prox switch inputs.

MOSAIC-MV2H

2 HTL encoder and 2 prox switch inputs.

MOSAIC-MV2S

2 SIN/COS encoder and 2 prox switch inputs.

MOSAIC SYSTEM



MOSAIC M1, M1S, or M1S-USBC controller units are able to interface with up to 14 individual expansion modules (up to a maximum of 4 of any one module type).

Controller units can also be used in a stand-alone configuration.

Blue-highlighted modules work only with the MOSAIC-M1S or MOSAIC-M1S-USBC controller.

SAFETY RELAYS

MOSAIC-MR2

2 relays – 2 NO + 1 NC connectable to 1 OSSD pair + 1 NC contact for external device monitoring. 2 safety relays with guided contacts. Screw contacts.



MOSAIC-MR4

4 relays – 4 NO + 2 NC connectable to 2 OSSD pair + 2 NC contacts for external device monitoring. 4 safety relays with guided contacts. Screw contacts.

These extension relays can connect to the outputs on the MOSAIC M1, M1S, or to any of the output cards

DIGITAL OUTPUTS

MOSAIC-MO2

2 EDM/RST inputs, 2 OSSD pairs and 2 status outputs.



MOSAIC-MO4

4 EDM/RST inputs, 4 OSSD pairs and 4 status outputs.

MOSAIC-MOR4

4 single-channel outputs or 2 dual-channel outputs.

MOSAIC-MOR4S8

4 single-channel outputs or 2 dual-channel outputs with 8 status outputs.

MOSAIC-MO4L

4 individual or 2 pair OSSD outputs, and 4 configurable I/O.

ANALOG INPUTS



MOSAIC-MA4 4 analog inputs.

STATUS OUTPUTS

MOSAIC-MOS8

8 status outputs.



16 status outputs.



ACCESSORIES

MOSAIC-MSC-C

Safety communication bus connector and terminal end caps. Required to connect additional module to MOSAIC-M1, MOSAIC-M1S, or MOSAIC-M1S-USBC.

MOSAIC-MCM, MOSAIC-MCMB

A proprietary removable memory card that can be used to save MOSAIC configuration data for subsequent transfer to a new device without using a PC.



Safety Products



Warning: Safety products sold by AutomationDirect are Safety components only. The purchaser/installer is solely responsible for the application of these components and ensuring all necessary steps have been taken to assure each application and use meets all performance and applicable safety requirements and/or local, national and/or international safety codes as required by the application. AutomationDirect cannot certify that our products, used solely or in conjunction with other AutomationDirect or other vendors' products, will assure safety for any application. Any person using or applying any products sold by AutomationDirect is responsible for learning the safety requirements for their individual application and applying them, and therefore assumes all risks, and accepts full and complete responsibility, for the selection and suitability of the product for their respective application.

AutomationDirect does not provide design or consulting services, and cannot advise whether any specific application or use of our products would ensure compliance with the safety requirements for any application.