



ProSense Windows configuration software, free download only. For use with ProSense temperature transmitter XTP series, digital temperature sensor ETS series and programmable temperature sensor XTD-0-UNV.

For complete product information, please see this item on our store at the following link:



https://www.automationdirect.com/pn/XT-SOFT

## **Technical Specifications**

Brand	ProSense
Item	Configuration software
Media Type	Free download only
Software Type	Windows
For Use With	ProSense temperature transmitter XTP series, digital temperature sensor ETS series and programmable temperature sensor XTD-0-UNV
Requires	XT-USB for XTH and XTD series, XT-USB and XT-M12 required for XTP series

## Agency Approvals

5 7 11	
UL Listed File #	None
UL Recognized File #	E311366
UL Hazardous File #	None
CSA File #	None
RoHS Status	No
EU REACH	View EU REACH document