

Programming Software

PG-PGMSW * FREE * (\$495 value)

Free online download!

Productivity Suite is user-friendly programming software designed to allow quick and easy programming of ladder logic programs for the Productivity3000® CPU.

The online help file provides information that will help you get acquainted with the software quickly.

PC Requirements

For Productivity Suite software and hardware system requirements please visit our web site for the minimum system requirements: <https://support.automationdirect.com/downloads.html>

Programming Cable

You will need a standard USB or Ethernet cable for programming, depending on whether you use the USB (P3-550) or Ethernet (P3-530 and P3-550(E)) programming port.

We recommend using a USB programming cable (P3-550 only); just plug it in and it works. We sell A-to-B USB cables in various lengths:

- [USB-CBL-AB3](#) (3ft)
- [USB-CBL-AB6](#) (6ft)
- [USB-CBL-AB10](#) (10ft)
- [USB-CBL-AB15](#) (15ft)


Or where possible use an Ethernet Cable:

- CAT5E STP (3ft to 50ft lengths available at www.automationdirect.com)



Main window

The Main Window is displayed when the program opens. It is divided into Menus, Toolbars, and Windows that work together to make project development as simple as possible.



Application Tool Panel

Task Management Panel

Ladder Editor Window

Instruction Panel Window