

Programming Software

PS-PGMSW FREE OnLine Download

Productivity Suite is user-friendly programming software designed to allow quick and easy programming of ladder logic programs for the Productivity® 1000, Productivity® 2000 and Productivity3000® CPUs.

The online help file provides information that will help you get acquainted with the software quickly.

PC Requirements

Productivity Suite, a Windows-based programming software, is available as a FREE download at <http://support.automationdirect.com/downloads.html>. Please check our website for your product's current operating system requirements.

Programming Cable

You will need a Micro USB or Cat-5 Ethernet cable for programming, depending on whether you use the USB or Ethernet programming port.

We recommend using a USB programming cable; just plug it in and it works. We sell these USB Type A to Micro Type B USB cables:

- [USB-CBL-AMICB6](#) (6 ft.)
- [USB-CBL-AMICB15](#) (15 ft.)
- [USB-CBL-AC6](#) (6 ft.)



Main window

The Main Window is displayed when the program opens. It is divided into Menus, Toolbars, and Windows that work together to make project development as simple as possible.

