



## **OWLINE** EchoPod/EchoTouch® Reflective **Technology™ Ultrasonic Liquid Level Sensors**



#### Overview

The innovative EchoPod/EchoTouch Reflective Technology ultrasonic liquid level sensors replace other ultrasonic level sensors in condensation applications, as well as float, conductance and pressure sensors that fail due to contact with dirty, sticky and scaling media in small, medium and large capacity tanks. Applied in chemical, water and wastewater applications, these general purpose or intrinsically safe non-contact sensors are available with single and multi-function capabilities, including continuous level measurement, switching and control. The standard 4-20 mA output is easily monitored by a PLC or other controller. Models with four relays can be configured for level alarms and/or standalone level control such as automatic fill or empty functions using the embedded level controller. PC configuration of all models is simple with WEBCAL™ software, while the UG06, UG12 and US06 models also offer limited configuration via their pushbuttons and integral display.



#### What is Reflective Technology™?

Condensation is the most commonly encountered variable in liquid level applications. Condensation attenuates the acoustic signal of ultrasonic sensors that have a flat horizontal transducer face, weakening their signal strength and signal-to-noise ratio by up to 50%, and substantially reducing their measurement reliability. At the core of Reflective Technology™ is a simple fact: unlike flat horizontal surfaces, significant water droplets cannot adhere to smooth vertical surfaces. By orienting the internal ultrasonic transducer vertically, condensation runs off the transducer face and does not affect sensor performance. The unimpeded transmit and receive signals are redirected to and from the liquid off a 45° reflector, delivering reliable level measurement. Thanks gravity!










L199-2001

### WebCal Software


WEBCAL PC software is a utility program that enables users to easily configure their EchoSonic II, EchoTouch and EchoPod level transmitters, switches, and controllers. Download your free copy of WebCal at www.AutomationDirect.com, and connect your sensor through our Fob USB adapter (LI99-2001). Develop your configuration using pre-programmed function menus as the tank graphic and set point fields automatically change to match your configuration. Then, input your level set point values and click the Write to Unit button. Your configuration will be downloaded into the sensor and verified in less than a second. Last, click the Wiring Diagram button to open a wiring schematic of your configuration in PDF format. Print the document, disconnect the sensor and wire it per the schematic. As new software or firmware becomes available, it can be downloaded and updated through WebCal.

### Reflective **Technology**

Horizontal Transducer



Reflective Transducer



Reliable Measurement





## EchoPod/EchoTouch® Reflective **Technology™ Ultrasonic Liquid Level Sensors**

EchoPod/EchoTouch Reflective Technology Ultrasonic Liquid Level Sensors General Specifications								
Model	<u>UG01-0001-40</u>	<u>UG03-0001-40</u>	<u>UG06-0001-00</u>	<u>UG12-0001-00</u>	<u>US01-0001-00</u>	<u>US03-0001-00</u>	<u>US06-0001-00</u>	
Price	\$525.00	\$600.00	\$800.00	\$1,050.00	\$645.00	\$715.00	\$1,000.00	
Туре	EchoPod/EchoTouch Reflective Technology (works in condensing environments)							
Classification		General purpose	ion-hazardous)		Intrinsically safe			
Media	Liquids							
Range	1.5 in to 4.9 ft (3.8 cm to 1.5 m)	4in to 9.8 ft (10.1 cm to 3m)	8in to 19.6 ft (20cm to 6m)	18in to 39.3 ft (45.7 cm to 12m)	1.5 in to 4.9 ft (3.8 cm to 1.5 m)	4in to 9.8 ft (10.1 cm to 3m)	8in to 19.6 ft (20cm to 6m)	
Output	4-20 mA and (4	4) SPST relays			4-20 mA (No Relays)			
Mounting	Vertic	al, top of tank, 2in NPT	male	Vertical, top of tank, 3in NPT male	Vertical, top of tank, 2in NPT male			
Electrical Termination	Integral 48in, 9-conductor, shielded cable		Screwless terminals, 1/2in female NPT		Integral 48in, 4-conductor, shielded cable		Screwless terminals, 1/2in female NPT	
Configuration	WEBCAL Software (free download) and Ll99-2001 Fob USB Adapter (purchased separately)		WEBCAL Software (free download) and LI99-2001 Fob USB Adapter (purchased separately) or Pushbutton / LCD		WEBCAL Software (free download) and LI99-2001 Fob USB Adapter (purchased separately)		WEBCAL Software (free download) and LI99-2001 Fob USB Adapter (purchased separately) or Pushbutton / LCD	
Ambient Temperature	-31° to 140°F (-35° to 60°C)					-40° to 176°F (-40° to 80°C)		
Process Temperature	-40° to 176°F (-40° to 80°C)							
Pressure	30 PSI (2 bar) max.							

www.automationdirect.com **Level Sensors** tULS-2



OWLINE EchoPod® UG01 & UG03 Series **Ultrasonic Liquid Level Sensors** 



Part No. <u>UG01-0001-40</u> Shown					
UG01 & UG03 Technical					
	Specifications				
Model	<u>UG01-0001-40</u>	<u>UG03-0001-40</u>			
Price	\$525.00	\$600.00			
Weight (lbs)	1.5	1.5			
Range	1.5 in to 4.9 ft (3.8 cm to 1.5 m)	4in to 9.8 ft (10.1 cm to 3m)			
Accuracy	0.125 in (3mm)	±0.2% of range			
Resolution	0.019 in (0.5 mm)	0.039 in (1mm)			
Sensing Dead Band*	1.5 in (3.8 cm)	4in (10.1 cm)			
Beam Width	2in (	5cm)			
Configuration	WEBCAL® PC Windows® USB® 2.0				
Memory	Non-v	olatile			
Supply Voltage	14-28 VDC				
Max. Consumption	0.5 W				
Loop Resistance	500Ω @ 24VDC				
Signal Output	4-20 mA, two-wire				
Signal Invert	4-20 mA or 20-4 mA				
Signal Fail-Safe	4mA, 20mA, 21mA, 22mA, hold last				
Contact Type	(4) SPST relays (N.O./N.C. selectable)				
Contact Rating	60VA, 1A maximum				
Contact fail-safe	Open, closed, hold last				
Contact Hysteresis	Selectable				
Process Temperature	-40° to 176°F (-40° to 80°C)				
Temp. Compensation	Automatic				
Ambient Temperature	-31° to 140°F (-35° to 60°C)				
Pressure	30 PSI (2 bar)				
Enclosure Rating	Type 6P (IP68)				
Enclosure Material	Polypropylene (PP)				
Transducer Type	Reflective				
Transducer Material	Polyvinylidene flouride (PVDF)				
Cable Jacket Material	Polyurethane (PUR)				
Cable Type	9-conductor, shielded				
Cable Length	48in (1.2 m)				
Process Mount	2in Male NPT				
Classification	General purpose				
Approval	CSA certified to UL 61010-1				
Compliance	CSA, CE				

<sup>\*</sup> Dead band is the minimum distance the sensor must be mounted above the max liquid level.

#### Overview

The EchoPod UG01 and UG03 general-purpose reflective ultrasonic multi-function level transmitters provide continuous level measurement up to 9.8' (3m) with a 4-20 mA analog signal output and four relays, and are configured via WEBCAL software. The noncontact liquid level sensor features Flowline's proprietary Reflective Technology™ that delivers reliable level measurement in condensing environments. Each output relay can be configured for alarm, automatic fill or empty functions. Select this sensor for small tanks with non-foaming and mildly vaporous media such as chemicals, water, wastewater and oil. Typical applications include day tank, IBC or drum, cooling tower, skid or machine, process tank and waste sumps.

#### **Features**

- 1.5m (4.9') and 3m (9.8') measurement ranges
- Fail-safe diagnostics with selectable relay and signal outputs
- Narrow 2" (5cm) beam width for applications with limited space
- Corrosion resistant PVDF transducer and compact PP enclosure
- Short 1.5" (3.8cm) dead band maximizes tank filling capacity
- Automatic temperature compensation from -40° to 176°F (-40° to 80°C)
- Configuration via WEBCAL software
- Four programmable relays with embedded level control logic
- 1 pump or valve with 3 alarms
- 2 pumps lead-lag with 2 alarms
- 2 pumps duplexing with 2 alarms
- 4 independent switch point alarms
- · 2-year warranty

#### Agency Approvals


• CSA, CE






#### **Dimensions**

#### inches [mm]






See our website www.AutomationDirect.com for complete Engineering drawings.

#### Configuration

The settings for the the UG01 & UG03 are configured with free WEBCAL software (downloadable from AutomationDirect Web site), and an LI99-2001 Fob USB adapter (purchased separately).



See the end of the Ultrasonic Level Sensor Section for further details and Accessories



# **Ultrasonic Liquid Level Sensor Accessories**

Ultrasonic Liquid Level Sensor Accessories						
Part No.	Item Photo	Description	Quantity	Weight	Price	
<u>LI40-1001</u>		Flowline PodView general purpose digital indicator, displays tank level or volume and sensor relay status, 6-digit LCD display with four relay status indicators, 3-button user interface, polycarbonate panel mount enclosure with NEMA 4 (IP65) faceplate, 6-foot (1.8-meter) 22AWG 4-conductor cable, for use with Flowline EchoPod DL, DS and DX series ultrasonic level sensor with firmware V50.0 or later	1	0.6	\$275.00	
<u>LM50-1001</u>		Flowline side mount bracket, 2 inch NPT female threads, polypropylene (PP), for use with Flowline DL34, LU23, LU28, LU29, LU74, LU78, LU81, LU83, LU84, UG01, UG03, UG06, US01, US03 and US06 series ultrasonic level sensors	1	0.4	\$48.00	
<u>LM50-1001-1</u>		Flowline side mount bracket, 2 inch NPT female threads, polypropylene (PP), and 2 inch NPT male x 1 inch NPT female reducer bushing (PVC), for use with Flowline DL14, DL24, DS14, DL10, DX10, LU27, LU77 and LU80 series ultrasonic level sensors	1	0.6	\$64.00	
<u>LM52-1400</u>	9	Flowline reducer bushing, 2 inch NPT male x 1 inch NPT female threads, PVC, for use with Flowline DL14, DL24, DS14, DL10, DX10, LU27, LU77 and LU80 series ultrasonic level sensors	1	0.2	\$18.00	
<u>LM52-2400</u>	9	Flowline reducer bushing, 3 inch NPT male x 2 inch NPT female threads, PVC, for use with Flowline DL34, LU23, LU28, LU29, LU74, LU78, LU81, LU83, LU84, UG01, UG03, UG06, US01, US03 and US06 series ultrasonic level sensors	1	0.6	\$46.00	
<u>LM52-3800</u>	9	Flowline reducer bushing, PVC, 4in male NPT to 2in female NPT. For use with Flowline DL34, LU23, LU29, LU74, LU78, LU81, LU83, LU84, UG01, UG03, UG06, US01, US03 and US06 series ultrasonic level sensors	1	2.0	\$156.00	
<u>LM52-1890</u>	l.	Flowline low-profile bulkhead fitting, 1 inch NPT female x slip socket, with mounting nut, PVC, for use with Flowline DL14, DL24, DS14, DL10, DX10, LU27, LU77 and LU80 series ultrasonic level sensors	1	0.5	\$60.00	
<u>LM52-2890</u>	30	Flowline low-profile bulkhead fitting, 2 inch NPT female x slip socket, with mounting nut, PVC, for use with Flowline DL34, LU23, LU28, LU29, LU74, LU78, LU81, LU83, LU84, UG01, UG03, UG06, US01, US03 and US06 series ultrasonic level sensors	1	1.2	\$114.00	
<u>LM52-3890</u>		Flowline low-profile bulkhead fitting, PVC, 3in female NPT to slip socket. For use with Flowline UG12 series ultrasonic level sensors. Mounting hardware included.	1	2.1	\$194.00	
<u>LM52-1850</u>		Flowline mounting flange, 1 inch NPT female threads, CPVC, for use with Flowline DL14, DL24, DS14, DL10, DX10, LU27, LU77 and LU80 series ultrasonic level sensors	1	0.5	\$92.00	
<u>LM52-2850</u>		Flowline mounting flange, 2 inch NPT female threads, CPVC, for use with Flowline DL34, LU23, LU28, LU29, LU74, LU78, LU81, LU83, LU84, UG01, UG03, UG06, US01, US03 and US06 series ultrasonic level sensors	1	1.0	\$140.00	
<u>LM52-3850</u>		Flowline mounting flange, CPVC, 3in female NPT. For use with Flowline UG12 series ultrasonic level sensors.	1	1.9	\$280.00	
<u>204038</u>	0	Replacement mounting gasket, for use with Flowline DL14, DL10, DX10 and DS14 series ultrasonic level sensors	1	0.1	\$8.00	
<u>200128</u>	0	Replacement mounting gasket, for use with Flowline DL24, LU27, LU77 and LU80 series ultrasonic level sensors	1	0.1	\$12.00	
<u>200129</u>	0	Replacement mounting gasket, for use with Flowline DL34, LU23, LU28, LU29, LU74, LU78, LU81, LU83 and LU84 series ultrasonic level sensors	1	0.1	\$18.00	

When installing the 1" NPT level sensors care should be used to mechanically isolate the sensor housing from the tank. This can easily be done by using any of the Flowline mounting accessories which are designed to provide the isolation needed.




## Ultrasonic Liquid Level Sensor Accessories


#### **Dimensions**

inches [mm]


#### LM50-1001




#### LM50-1001-1




#### LM52-1400




#### LM52-2400




#### LM52-3800




#### LM52-1890




#### LM52-2890



#### LM52-3890





See our website www.AutomationDirect.com for complete Engineering drawings.




# Ultrasonic Liquid Level Sensor Accessories


#### **Dimensions**

inches [mm]


#### LM52-1850



#### LM52-2850



#### LM52-3850





### WebCal Ultrasonic Level Sensor Software and USB Fob Adapter

#### **Overview**

WEBCAL PC software is a utility program that allows users to easily configure their EchoPod, EchoTouch and EchoSonic II level transmitters, switches, and controllers. Download your free copy of WEBCAL at www.AutomationDirect.com, and connect your sensor through the Fob USB adapter (LI99-2001). Develop your configuration using pre-programmed function menus as the tank graphic and set point fields automatically change to match your configuration. Then, input your level set point values and click the Write to Unit button. Your configuration will be downloaded into the sensor and verified in less than a second. Last, click the Wiring Diagram button to open a wiring schematic of your configuration in PDF format. Print the document, disconnect the sensor and wire it per the schematic. It's that simple.


Configuration files can be named, saved, emailed, printed, opened and used again under revision control. The advanced feature page enables you to change the measurement signal, output filtering and invert relay states from N.O. to N.C. As new software or firmware becomes available, they can be downloaded and updated through <u>WEBCAL</u>.

#### **Features**

- 169 configurations with pull-down menu selections
- Graphical interface lets you visualize your configuration
- Applicable level set point fields appear automatically
- Installs and tests configuration in less than a second
- Available PDF wiring diagram for each configuration
- Technical help menu with FAQs, tips and glossary
- Rapidly program sensors to the same configuration
- Save configuration files for future use or reference
- Print wiring diagrams and configuration text files
- Email configuration files to other remote users
- Please check www.automationdirect.com for the most recent system requirments.

WebCal Ultrasonic Level Sensor Software and USB Adapter							
Part No.	Item Photo	Description	Quantity	Weight (lbs)	Price		
<u>L199-2001</u>		Flowline Fob USB adapter, required for use with WebCal software to configure Flowline EchoPod, EchoTouch and EchoSonic II ultrasonic level sensors.	1	0.1	\$65.00		
<u>WEBCAL</u>		Configuration software for Flowline EchoPod, EchoTouch and EchoSonic II ultrasonic level sensors. Requires an <u>LI99-2001</u> Fob USB adapter (purchased separately).	1	0.1	Free Download		

#### **EchoPod Configuration**





Click on the thumbnail or go to https://www.automationdirect.com/VID-LE-0004 for Part 1 of our How To video on the use of the Flowline Ultrasonic Level Sensors

#### **EchoSonic II Configuration**





Click on the thumbnail or go to https://www.automationdirect.com/VID-LE-0005 for Part 2 of our How To video on the use of the Flowline Ultrasonic Level Sensors