ABB Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter U at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
FNS-HS12	D1
FNS-HS4	D1
K5FCH	D1
K5FCH4	D1
K7FCH	D2
K7FCH4	D2
OHF1C12T	D1
OHF1C12	D1
OHF1C4	D1
OHF1C4T	D1
XT1, S1	D1
XT2, S2	D1
XT3, S3	D1
XT4, S4	D1
XT5, T5, S5	D1
XT6, T6, S6	D2
XT7, T7, S7	D2

D1



D2



D7



Allen-Bradley Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
140G	D1
140RC	D1
140U	D1
1494C < 400 AMP	D1
1494C 400, 600 AMP	D2
1494F-200	D7
1494F-N100	D7
1494F-N30	D7
1494F-N60	D7
1494F-M1	D1
1494F-M2	D2

HANDLE / OPERATOR	CUTOUT DETAIL
1494F-P1	D1
1494F-P2	D1
1494F-S1	D1
1494F-S2	D2
1494FU-HS1	D1
1494M-NF200	D6
1494U	D1
1494U-HM1	D1
1494U-HP1	D1
1494U-HS1	D1
1494V-H10	D1

HANDLE / OPERATOR	CUTOUT DETAIL
1494V-H2	D2
1494V-H5	D1
1494V-H8	D2
1494V-M1	D1
1494V-M2	D2
1494V-R1	D14
1494V-R2	D15
1494V-W10	D1
1494V-W2	D2
1494V-W5	D1
1494V-W8	D2

D1



D2



D6



D7



D14



D15



Bussmann Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
BDFHNHS12	D1
FLH1	D1
FLH2	D1

D1



D2



D7



Cutler-Hammer Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
C361H1	D1
C361H2	D1
C361H3	D1
C361H4	D1
F0S03	D1
F0S04	D1
F0S05	D1
F1S03C	D1
FLEX SHAFT	D1
FLEX SHAFT CH	D1
LHMFS04	D1
SM150	D10
SM250	D9

D1



D2



D7



D9



D10



GE Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
SCH1	D1
STDA1	D1
STDA2	D2
STDA3	D2
STDOM	D1
TDOM	D1

D1



D2



D7



Gould Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
GOULD D10	D11

D1



D2



D7



D11



LSis Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter U at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
FHU-L	D1
FHX-S	D1
FHX-L	D1
COM-0	D1
COM-2	D1
COM-3	D1
COM-5	D1

D1



D7



Moller Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
SH36-4X-NZM7	D1
SH36-4X-NZM10	D1
SH48-4X-NZM7	D1
SH48-4X-NZM10	D1

D1



D2



D7



Siemens Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
FDH10	D1
FDH104	D1
FDH20	D1
FDH204	D1
FDS06L	D1
FDS06R	D1
FDS20L	D1
FDS20R	D1
FHOH	D1
FHOH4	D1
FHOHN	D2
FHOHN4	D2
MFHM3R	D1

HANDLE / OPERATOR	CUTOUT DETAIL
MFHM3RB	D1
MFHM3RS	D1
MFHM3RSB	D1
MFHM4X	D1
MFHP3RS	D2
MFHP3RSB	D2
MFHP4X	D2
MFKF3R	D1
VBH1	D1
VBH14X	D1
VBH2	D2
VBH24X	D2
VBH2R	D2

D1



D2



D7



Square D Flange Mounted Disconnects and Circuit Breakers

Flange Mounted Operator Handle and Operating Mechanisms, variable depth and cable operated. The D1 Cutout detail is the standard cutout in all Stock SCE enclosures.

*The exception is part numbers with the Letter *U* at the end (Example: SCE-84XM4018U), this indicates the Universal Cutout (D7).
Adapter Kits available for use with Universal Cutout, for D2 cutout: SCE-UA400V and for D1 cutout: SCE-UAV.

HANDLE / OPERATOR	CUTOUT DETAIL
9422 A1 to A4	D1
9422 A5 to A8	D3
9422 A9 to A10	D1
9422 BG1	D5
9422 BN1	D5
9422 BP1	D5
9422 BR1	D5

HANDLE / OPERATOR	CUTOUT DETAIL
9422 CFA	D1
9422 CFT	D1
9422 CGJ	D1
9422 TG A5	D3
9422 TG A6	D3
9422 TG A7	D3
9422 TG A8	D3

D1



D2



D3



D5



D7