Chemical Compatibility



In this Appendix...

Chemical Compatibility	
Recommeded Cleaning Method	D-2
Approved Cleaning Chemicals	D-2
Do Not Use the Following Chemicals	D-2



Chemical Compatibility

This appendix is made up of specifications provided by the manufacturer of the material.

The chemical compatibility of the following parts is described below.

• Glass: Touch screen

Anti-fingerprint coating

SGCC: BezelEPDM: Gasket

Recommended Cleaning Method

Use a neutral detergent (pH 6~8) and warm water for cleaning. Wipe gently with a soft cloth such as a microfiber cloth. Avoid using any corrosive, solvent or abrasive chemicals and tools.

Approved Cleaning Chemicals

Recommended Cleaning Chemicals			
Chemical Material	Density (%)	Temperature Range	
Isopropyl Alcohol	70-80	68-77 °F [20-25 °C]	
Distilled Water	100	68-77 °F [20-25 °C]	
Ethanol	70-80	68-77 °F [20-25 °C]	
Mild Soap Solution	1-2 (soap)	68-77 °F [20-25 °C]	

Do Not Use the Following Chemicals

Do Not Use
Chemical Material
Methyl Alcohol at concentration > 35%
Thinner or benzene
Strong alkali lye
Strong solvents
Acids
Detergents with fluoride
Detergents with ammonia at concentration > 1.6%
Abrasive cleaners
Detergents with abrasives
Formula 409