

# HARDWARE

---



# CHAPTER 1

## In This Chapter...

Introduction.....	1-2
Conventions Used.....	1-2
Product Overview.....	1-3
Managed Switch Accessories.....	1-5
General Information.....	1-6
LED Indicators.....	1-9
Installation, Plastic Case Switches.....	1-11
Installation, Metal Case Switches.....	1-12
Power and Alarm Wiring.....	1-25
Communication Ports Wiring.....	1-27
Technical Specifications.....	1-31

## Introduction

### The Purpose of this User's Manual

Thank you for purchasing our *Stride*™ Industrial Ethernet Switches and Media Converters. This manual describes *AutomationDirect.com*'s *Stride* industrial Ethernet switches and media converters, their specifications, included components, and provides you with important information for installation, connectivity and setup. The manual shows you how to install, wire and use the products.

### Technical Support

We strive to make our manuals the best in the industry. We rely on your feedback to let us know if we are reaching our goal. If you cannot find the solution to your particular application, or, if for any reason you need technical assistance, please call us at:

**770-844-4200**

Our technical support group will work with you to answer your questions. They are available Monday through Friday from 9:00 A.M. to 6:00 P.M. Eastern Time. We also encourage you to visit our web site where you can find technical and non-technical information about our products and our company.

**<http://www.automationdirect.com>**

If you have a comment, question or suggestion about any of our products, services, or manuals, please let us know.

## Conventions Used



---

*When you see the "notepad" icon in the left-hand margin, the paragraph to its immediate right will be a special note. The word **NOTE:** in **boldface** will mark the beginning of the text.*

---



---

*When you see the "exclamation mark" icon in the left-hand margin, the paragraph to its immediate right will be a warning or a caution. This information could prevent injury, loss of property, or even death (in extreme cases). The words **WARNING** or **CAUTION:** in **boldface** will mark the beginning of the text.*

---

## Product Overview

Stride Unmanaged Ethernet Switches		
Part Number		Description
<b>SE-SW5U</b> <b>SE-SW5U-WT</b>		<p><b>STRIDE™</b> SlimLine Industrial Unmanaged Ethernet Switch with five 10/100BaseT RJ45 Ethernet ports. Redundant power inputs with surge and spike protection. Auto-crossover. 35 mm DIN rail mounting. Supports store &amp; forward wire speed switching and full-duplex with flow control. UL, CSA (CUL), &amp; CE</p> <p><i>Note: -WT models have a metal case and are rated for a wider temperature range, from -40 ° to +85 °C.</i></p>
<b>SE-SW8U</b> <b>SE-SW8U-WT</b>		<p><b>STRIDE™</b> SlimLine Industrial Unmanaged Ethernet Switch with eight 10/100BaseT RJ45 Ethernet ports. Redundant power inputs with surge and spike protection. Auto-crossover. 35 mm DIN rail mounting. Supports store &amp; forward wire speed switching and full-duplex with flow control. UL, CSA (CUL), &amp; CE</p> <p><i>Note: -WT models have a metal case and are rated for a wider temperature range, from -40 ° to +85 °C.</i></p>
<b>SE-SW5U-ST</b> <b>SE-SW5U-SC</b> <b>SE-SW5U-ST-WT</b> <b>SE-SW5U-SC-WT</b>		<p><b>STRIDE™</b> SlimLine Industrial Unmanaged Ethernet Switch with four 10/100BaseT RJ45 Ethernet Ports and one 100BaseFX Fiber Optic Port (ST or SC type multimode fiber connector for links up to 4km). Redundant power inputs with surge and spike protection. Auto-crossover. 35 mm DIN rail mounting. Supports store &amp; forward wire speed switching and full-duplex with flow control. UL, CSA (CUL), &amp; CE</p> <p><i>Note: -WT models have a metal case and are rated for a wider temperature range, from -40 ° to +85 °C.</i></p>
<b>SE-SW9U-ST</b> <b>SE-SW9U-SC</b> <b>SE-SW9U-ST-WT</b> <b>SE-SW9U-SC-WT</b>		<p><b>STRIDE™</b> SlimLine Industrial Unmanaged Ethernet Switch with eight 10/100BaseT RJ45 Ethernet Ports and one 100BaseFX Fiber Optic Port (ST or SC type multimode fiber connector for links up to 4km). Redundant power inputs with surge and spike protection. Auto-crossover. 35 mm DIN rail mounting. Supports store &amp; forward wire speed switching and full-duplex with flow control. UL, CSA (CUL), &amp; CE</p> <p><i>Note: -WT models have a metal case and are rated for a wider temperature range, from -40 ° to +85 °C.</i></p>
<b>SE-MC2U-ST</b> <b>SE-MC2U-SC</b>		<p><b>STRIDE™</b> SlimLine Industrial Unmanaged Ethernet to Fiber Converter with one 10/100BaseT auto-detecting, auto-crossover and auto-polarity RJ45 Ethernet Port and one 100BaseFX Fiber Optic Port (ST or SC type multimode fiber connector for links up to 4km). Redundant power inputs with surge and spike protection. 35 mm DIN rail mounting. Supports store &amp; forward wire speed switching and full-duplex with flow control. UL, CSA (CUL), &amp; CE</p>

## Product Overview (cont'd)

<b>Stride Managed Ethernet Switches</b>		
<b>Part Number</b>		<b>Description</b>
<b>SE-SW5M</b>		<b>STRIDE™</b> SlimLine industrial managed 5-port Ethernet switch, metal housing, -40 to +75 deg. C operating temperature range, five 10/100BaseT RJ45 Ethernet ports. Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked.
<b>SE-SW5M-2ST</b> <b>SE-SW5M-2SC</b>		<b>STRIDE™</b> SlimLine industrial managed 5-port Ethernet switch, metal housing, -40 to +75 deg., three 10/100BaseT RJ45 Ethernet ports and two multi-mode 100BaseFX fiber ports(ST or SC type multimode fiber connector for links up to 4km). Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked.
<b>SE-SW8M</b>		<b>STRIDE™</b> SlimLine industrial managed 8-port Ethernet switch, metal housing, -40 to +75 deg. C operating temperature range, eight 10/100BaseT RJ45 Ethernet ports. Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked.
<b>SE-SW8M-2ST</b> <b>SE-SW8M-2SC</b>		<b>STRIDE™</b> SlimLine industrial managed 8-port Ethernet switch, metal housing, -40 to +75 deg., six 10/100BaseT RJ45 Ethernet ports and two multi-mode 100BaseFX fiber ports(ST or SC type multimode fiber connector for links up to 4km). Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked.
<b>SE-SW16M</b>		<b>STRIDE™</b> SlimLine industrial managed 16-port Ethernet Switch, metal housing, -40 to +75 deg. C operating temperature range, sixteen 10/100BaseT RJ45 Ethernet ports. Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked.
<b>SE-SW8MG-4P</b>		<b>STRIDE™</b> SlimLine industrial managed 8-port Ethernet switch all Gigabit, metal housing, -40 to +75 deg., eight 10/100/1000 BaseT RJ45 Ethernet ports and four advanced combination SFP ports that accept noise-immune fiber optic links up to 40 km. Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked. SFP option modules sold separately.
<b>SE-SW10MG-2P</b>		<b>STRIDE™</b> SlimLine industrial managed 10-port Ethernet switch with Gigabit, metal housing, -40 to +75 deg., seven 10/100 BaseT RJ45 Ethernet ports, three Gigabit 10/100/1000 BaseT RJ45 port and two advanced combination SFP ports that accept noise-immune fiber optic links up to 40 km. Redundant power inputs with surge and spike protection, auto-crossover, 35 mm DIN rail mounting. Supports Store and Forward wire speed switching and full-duplex with flow control. UL/CUL HazLoc (Class I, Div. 2, Groups A, B, C, D) and CE marked. SFP option modules sold separately.

## Managed Switch Accessories

<i>SFP Transceiver</i>	
<i>Part Number</i>	<i>Description</i>
<i>SFP-4K-FMF</i>	<b>STRIDE™</b> 100Mb Small Form Factor Pluggable (SFP) transceiver module (Transmit/Receive). Uses a long wavelength of 1310nm, supports data transmission up to 4km on a multi-mode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant. 125Mbps IEEE802.3u 100Base-FX compliant, 125Mbps FDDI ISO/IEC 9314-1 compliant.
<i>SFP-30K-FSF</i>	<b>STRIDE™</b> 100Mb Small Form Factor Pluggable (SFP) transceiver module (Transmit/Receive). Uses a long wavelength of 1310nm, supports data transmission up to 30km on a singlemode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant.
<i>SFP-500-GMF</i>	<b>STRIDE™</b> Gigabit (1.25GB) Small Form Factor Pluggable (SFP) transceiver module (Transmit/Receive). Uses a short wavelength of 850nm, supports data transmission up to 550 meters on a multi-mode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant. 1.0625Gbps Fibre Channel FC-PI 100-M5-SN-I compliant. 1.0625Gbps Fibre Channel FC-PI 100-M6-SN-I compliant. 1.25Gbps IEEE802.3z 1000Base-SX compliant. 1.25Gbps IEEE802.3ah compliant.
<i>SFP-2K-GMF</i>	<b>STRIDE™</b> Gigabit (1.25GB) Small Form Factor Pluggable (SFP) transceiver module. Uses a long wavelength of 1310nm, supports data transmission up to 2km on a multi-mode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant. IEEE 802.3 1000Base-SX compliant.
<i>SFP-10K-GSF</i>	<b>STRIDE™</b> Gigabit (1.25GB) Small Form Factor Pluggable (SFP) transceiver module (Transmit/Receive). Uses a long wavelength of 1310nm, supports data transmission up to 10km on a singlemode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant. 1.0625Gbps Fiber Channel FC-PI 100-SM-LC-L compliant. 1.25Gbps IEEE 802.3 1000Base-LX compliant.
<i>SFP-30K-GSF</i>	<b>STRIDE™</b> Gigabit (1.25GB) Small Form Factor Pluggable (SFP) transceiver module (Transmit/Receive). Uses a long wavelength of 1310nm, supports data transmission up to 30km on a singlemode fiber. LC duplex receptacle, SFP Multi-Source Agreement compliant. 1.25Gbps IEEE 802.3 1000Base-LX compliant.



## General Information

### Overview

This user's manual will help you install and maintain the *STRIDE* industrial Ethernet switches and media converters. Installation of these devices is very easy and they will begin to operate as soon as they are powered up.

### Operation

Unlike an Ethernet hub that broadcasts all messages out all ports, these industrial Ethernet switches will intelligently route Ethernet messages only out the appropriate port. The major benefits of this are increased bandwidth and speed, reduction or elimination of message collisions, and deterministic performance when tied with real-time systems.

These industrial Ethernet switches can support 10BaseT (10 Mbps) or 100BaseT (100 Mbps) on their RJ45 ports. Each of these ports will independently auto-sense the speed and duplex, mdi/mdix-crossover and polarity allowing you to use patch or crossover cables. Managed switches include models that support gigabit Ethernet.

Some models include fiber optic ports, or slots that accept SFP fiber optic transceivers.

### Security Considerations

When implementing any method of remote access to your equipment, you need to consider the security exposure in order to minimize the risks to your processes and your equipment. Security should always be carefully evaluated for each installation. Refer to "Appendix F - Security Considerations for Control Systems Networks" for more information.

## Safety Standards

These industrial Ethernet switches meet the following standards plus others:

  	<p><b>Electrical Safety -</b>            CE per Low Voltage Directive and EN61010-1 (IEC1010)            UL recognition per UL508 (UL File #E200031)            CSA per C22.2/14 (cUL File #E200031)  <b>See Warnings on following page</b></p>
	<p>Install the Switches in accordance with local and national electrical codes.</p>
	<p>Lightning Danger: Do not work on equipment during periods of lightning activity.             Do not connect a telephone line into one of the Ethernet RJ45 connectors.</p>
 	<p><b>EMC (emissions and immunity) -</b>  <ul style="list-style-type: none"> <li>• CE per the EMC directive, EN61000-6-2, EN61000-6-4</li> <li>• FCC part 15 and ICES 003; Class B.</li> </ul> <b>See FCC statement on following page.</b></p>
 	<p><b>Marine, maritime and offshore -</b>            These devices, when installed in an appropriately IP rated enclosure. Comply with DNV No. 2.4 and equivalent Lloyds and ABS standards.   <b>For marine and maritime compliance, do not install this product within 5 meters of a standard or a steering magnetic compass.</b></p>
	<p><b>WEEE compliance -</b>            These devices comply with the WEEE directive. Dispose of properly.</p>
	<p><b>RoHS compliance -</b>            These devices comply with the RoHS directive and are considered lead and other hazardous substance free.</p>
 	<p><b>Hazardous Locations -</b>  <ul style="list-style-type: none"> <li>• CE per ATEX directive and EN60079-15 (Zone 2);                EEx nA II T4 X (-40 °C ≤ T<sub>a</sub> ≤ +85 °C)</li> <li>• UL per UL HazLoc (Class 1, Div. 2), Groups A, B, C, D (UL File #E200031)</li> <li>• CSA per C22.2/213 (Class 1, Div.2), Groups A, B, C, D (cUL File #E200031)</li> </ul> <b>See Warnings on following page</b></p>

## Installation and Hazardous Area Warnings



**Warning:** These products should not be used to replace proper safety interlocking. No software-based device (or any other solid-state device) should ever be designed to be responsible for the maintenance of consequential equipment or personnel safety. In particular, AutomationDirect.com disclaims any responsibility for damages, either direct or consequential, that result from the use of this equipment in any application. All power, input and output (I/O) wiring must be in accordance with Class 1, Division 2 wiring methods and in accordance with the authority having jurisdiction.

<b>WARNING (EXPLOSION HAZARD)</b>	SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS 1, DIVISION 2 (ZONE 2).
<b>WARNING (EXPLOSION HAZARD)</b>	WHEN IN HAZARDOUS LOCATIONS, DISCONNECT POWER BEFORE REPLACING OR WIRING UNITS.
<b>WARNING (EXPLOSION HAZARD)</b>	DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS.
<b>WARNING (EXPLOSION HAZARD)</b>	IN HAZARDOUS OR POTENTIALLY HAZARDOUS LOCATIONS, DO NOT SEPARATE ANY PART OF THE UNIT WHEN ENERGIZED. USE THE UNIT FOR INTERNAL CONNECTIONS ONLY.

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help.




**NOTE:** All information in this document is subject to change without notice.

## LED Indicators

### Overview

The *Stride* industrial Ethernet switches have 1 or 2 communication LEDs for each port and a power LED. The managed models also have an “OK” output LED, a status LED and dual power LEDs.



### Status LED

**Managed Models Only:** The Status LED indicates the overall health of the switch. It is normally ON solid indicating that no internal CPU or software problems are detected. It will flash when loading firmware and briefly on power up or reset. Otherwise, if it is OFF or flashing for an extended period of time then a problem is detected. In this case, please contact AutomationDirect for support.

### Power LED

On unmanaged models there is one power LED that is ON if either power input (P1 or P2) has power applied to it. On the managed models there are two Power LEDs that indicate if there is power applied to the respective input.

Explanation of LED Indicators continued on next page.

## ACT/LNK LED

This is the **Yellow** LED on models with two LEDs per RJ45 port.

<b>ON (yellow) (not flashing)</b>	Indicates that there is a proper Ethernet connection (Link) between the port and another Ethernet device, but no communications activity is detected.
<b>ON (yellow) (flashing)</b>	Indicates that there is a proper Ethernet connection (Link) between the port and another Ethernet device, and that there is communications activity.
<b>OFF</b>	Indicates that there is not a proper Ethernet connection (Link) between the port and another Ethernet device. Make sure the cable has been plugged securely into the ports at both ends.

## Speed 10/100 LED

This is the **Green** LED on models with two LED's per RJ45 port.

<b>ON (green)</b>	A 100 Mbps (100BaseT) connection is detected.
<b>OFF</b>	A 10 Mbps (10BaseT) connection is detected.

## ACT/LNK/Speed LED

This is a bi-color (**Green / Yellow**) LED on models with one LED per RJ45 port.

<b>ON Solid (not flashing)</b>	Indicates that there is a proper Ethernet connection (Link) between the port and another Ethernet device, but no communications activity is detected.
<b>Flashing</b>	Indicates that there is a proper Ethernet connection (Link) between the port and another Ethernet device, and that there is communications activity.
<b>Green</b>	On 10/100 ports, a 100 Mbps connection is detected. On 10/100/1000 ports, a 1000 Mbps connection is detected.
<b>Yellow</b>	On 10/100 ports, a 10 Mbps connection is detected. On 10/100/1000 ports, a 10 or 100 Mbps connection is detected.
<b>OFF</b>	Indicates that there is not a proper Ethernet connection (Link) between the port and another Ethernet device. Make sure the cable has been plugged securely into the ports at both ends.

## OK LED

**Managed Models:** This LED indicates the status of the power inputs. There is an output screw terminal that can be connected as shown in the wiring diagram. **The output voltage between the screw terminal marked 'OK' and the terminal marked '-' will be the same as the applied switch input voltage.** The output will be ON when both the PI and P2 terminals have power applied to them. It will be OFF if either input does not have power or the switch software is not running.


# Installation, Plastic Case Switches

## Overview

These industrial Ethernet switches and media converters can be snapped onto a standard 35 mm x 7.5 mm height DIN rail (Standard: CENELEC EN50022). The switches and media converters can be mounted either vertically or horizontally. Refer to the mechanical drawings that follow for proper mounting.



**NOTE:** Make sure to allow enough room to route your Ethernet copper or fiber optic cables.



## DIN Rail Mounting

### DIN rail mounting steps:

1. Hook top back of unit over the DIN rail.
2. Push bottom back onto the DIN rail until it snaps into place.

### DIN rail removal steps:

- A. Insert screwdriver into DIN clip and pry until it releases from the DIN rail.
- B. Unhook top of unit from DIN rail.

## Installation, Metal Case Switches

### Overview


These industrial Ethernet switches can be snapped onto a standard 35 mm x 7.5 mm height DIN rail (Standard: CENELEC EN50022). They can be mounted either vertically or horizontally. Refer to the mechanical drawings that follow for proper mounting.



---

**NOTE:** Make sure to allow enough room to route your Ethernet copper or fiber optic cables.

---



### DIN Rail Mounting

#### DIN rail mounting steps:


1. Hook top back of unit over the DIN rail.
2. Push bottom back onto the DIN rail until it snaps into place.

#### DIN rail removal steps:

- A. Push the unit down to free the bottom of the DIN rail.
- B. Rotate the bottom of the unit away from the DIN rail.
- C. Unhook top of unit from DIN rail.

## Mounting Options

Stride switches with metal cases offer the following optional mounting methods.



### A. Vertical DIN rail mount.

This mounting option allows for quickest installation and optimal utilization of rail space.

### B. Vertical screw to panel mount.

This mounting option gives better shock and vibration resistance.

### C. Flat screw to panel mount.

This mounting option offers a low profile orientation in shallow boxes plus the best shock and vibration resistance. The power connection terminal block is removable for access to the mounting tab.

## Important Notes about Thermal Performance

Stride switches with metal cases use an innovative technique to remove excess heat from the product and its components. This technique effectively utilizes the heavy gauge all-aluminum case as a large heat sink. Therefore, the case may be warm during operation, especially with heavy loads such as all ports linked and active. This is normal operation. For best performance, it is recommended that a DIN rail spacer such as end clamp, part number DN-EB35, be used between the switch and any adjacent device. This will leave an air gap for best heat dissipation off the case.


For best thermal performance when direct panel mounting to a metal surface, thermal compound may be used between the switch and mounting surface. This will reduce any air gaps and optimize the transfer of heat from the case to the mounting surface.



## Mechanical Dimensions for 5 and 8-Port Unmanaged Models in Plastic Case

Inches [mm]


5 or 8 Port – SE-SW5U & SE-SW8U



## Mechanical Dimensions for 5 and 9-Port Unmanaged Models with Fiber in Plastic Case

Inches [mm]


SE-SW5U-ST, SE-SW5U-SC  
SE-SW9U-ST and SE-SW9U-SC



## Mechanical Dimensions for 2-Port Media Converter in Plastic Case

Inches [mm]


Media Converters – SE-MC2U-ST and SE-MC2U-SC



## Mechanical Dimensions for 5 and 8-Port Unmanaged Models in Metal Case


Inches [mm]

5 or 8 Port – SE-SW5U-WT & SE-SW8U-WT



## Mechanical Dimensions for 5 and 9-Port Unmanaged Models with Fiber in Metal Case


Inches [mm]



## Mechanical Dimensions for 5-Port Managed Model



Inches [mm]

SE-SW5M



TOP VIEW

SCREW MOUNTING LOCATIONS	
SCREW SIZE	DIM "A"
#6	5.05 [128.3]
#8	5.10 [129.5]
#10	5.15 [130.8]
#12	5.20 [132.1]




BOTTOM VIEW



## Mechanical Dimensions for 5-Port Managed Models with Fiber

Inches [mm]

### SE-SW5M-2ST and SE-SW5M-2SC




SCREW MOUNTING LOCATIONS		
SCREW SIZE	DIM "A"	
#6	5.05	[128.3]
#8	5.10	[129.5]
#10	5.15	[130.8]
#12	5.20	[132.1]



## Mechanical Dimensions for 8-Port Managed Model



Inches [mm]

SE-SW8M



SCREW MOUNTING LOCATIONS		
SCREW SIZE	DIM "A"	
#6	5.05	[128.3]
#8	5.10	[129.5]
#10	5.15	[130.8]
#12	5.20	[132.1]

TOP VIEW




BOTTOM VIEW

## Mechanical Dimensions for 8-Port Managed Models with Fiber



Inches [mm]

### SE-SW8M-2ST and SE-SW8M-2SC



TOP VIEW

SCREW MOUNTING LOCATIONS		
SCREW SIZE	DIM "A"	
#6	5.05	[128.3]
#8	5.10	[129.5]
#10	5.15	[130.8]
#12	5.20	[132.1]




BOTTOM VIEW

# Mechanical Dimensions for 8-Port Managed Gigabit Switch with Four SFP Ports

Inches [mm]


SE-SW8MG-4P



# Mechanical Dimensions for 10-Port Managed Gigabit Switch with Two SFP Ports

Inches [mm]


SE-SW10MG-2P



## Mechanical Dimensions for 16-Port Managed Model

Inches [mm]


SE-SW16M



## Mechanical Dimensions for SFP Transceiver Modules

Inches [mm]

SFP-4K-FMF, SFP-30K-FSF, SFP-500-GMF, SFP-2K-GMF, SFP-10K-GSF and SFP-30K-GSF



# Power and Alarm Wiring

## Overview

DC voltage in the range of 10 to 30 VDC (3.0W) needs to be applied between the P1 (plus) terminal and the Minus terminal as shown below. To maintain a UL 508 panel listing use a Class 2 power supply. The chassis screw terminal should be tied to panel or chassis ground. To reduce down time resulting from power loss, these industrial Ethernet switches can be powered redundantly with a second power supply as shown below.



**NOTE:** When powering multiple switches from a common power supply, it is most reliable to power the switches sequentially rather than simultaneously. The characteristics of the power supply and the significant startup current of the switches may result in an error in booting the switches when powered simultaneously.

## Screw Torque


When tightening the screws be careful to tighten to a max. torque of 5 lb-in [0.57 Nm]. Wire size should be between 24 AWG and 12 AWG.

**Before performing any wiring to these switches make sure...**


- The area is currently nonhazardous (especially when working in Class 1, Div 2 or Zone 2 hazardous locations).
- Power is off to the switch
- The screw terminal block is unplugged. This is especially important on the aluminum housed units as shown below. Connecting or disconnecting wires to the screw block when its in place and power is turned on can allow the screwdriver to short the power to the case

## Unmanaged Models:

Single DC Power




Redundant DC Power




## Managed Models:

SE-SW5M, SE-SW5M-2ST, SE-SW5M-2SC, SE-SW8M, SE-SW8M-2ST and SE-SW8M-2SC

Single DC Power




Redundant DC Power




**Managed Models:**

SE-SW16M and SE-SW10MG-2P

**Single DC Power**




**Redundant DC Power**




SE-SW8MG-4P

**Single DC Power**



**Redundant DC Power**



# Communication Ports Wiring

## Overview

The industrial Ethernet switches and media converters provide connections to standard Ethernet devices such as PLCs, Ethernet I/O, industrial computers and much more. RJ45 (copper) Ethernet ports and fiber optic Ethernet ports are available depending on model.

## RJ45 Ethernet Wiring

Use data-quality (not voice-quality) twisted pair cable rated category 5e (or better) with standard RJ45 connectors. Straight-through or crossover Ethernet cable can be used for all devices the switch is connected to because all the ports are capable of auto-mdi/mdix-crossover detection.


The RJ45 Ethernet port connector bodies on these products are metallic and connected to the Chassis GND terminal. Therefore, shielded cables may be used to provide further protection. To prevent ground loops, the cable shield should be tied to the metal connector body at one end of the cable only. Electrical isolation is also provided on the Ethernet ports for increased reliability.

Straight-thru Cable Wiring	
Pin 1	Pin 1
Pin 2	Pin 2
Pin 3	Pin 3
Pin 4	Pin 4
Pin 5	Pin 5
Pin 6	Pin 6
Pin 7	Pin 7
Pin 8	Pin 8

Cross-over Cable Wiring	
Pin 1	Pin 3
Pin 2	Pin 6
Pin 3	Pin 1
Pin 4	Pin 4
Pin 5	Pin 5
Pin 6	Pin 2
Pin 7	Pin 7
Pin 8	Pin 8



**NOTE:** For reference only. Either cable wiring will work.



**Ethernet Plug & Connector Pin Positions**

## RJ45 Cable Distance

The maximum cable length for 10/100BaseT is 100 meters (328 ft.).

## Ethernet Fiber Wiring Guidelines

Depending on the model these industrial Ethernet switches may include one, two or four fiber optic ports. All 100 Mbps fiber ports are available with dual SC or ST multimode style connectors. Refer to the technical specifications for details.

All 1000 Mbps fiber ports are provided as SFP (small form pluggable). These accept plug-in fiber transceivers that have an LC style connector. They are available with either multimode or singlemode transceivers. Refer to the technical specifications for details.

For each fiber port there is a transmit (TX) and receive (RX) signal. When making your fiber optic connections, make sure that the transmit (TX) port of the switch connects to the receive (RX) port of the other device, and the receive (RX) port of the switch connects to the transmit (TX) port of the other device.

Use standard fiber optic wiring techniques (not covered by this manual) to make your connections. The corresponding ACT/LNK LED will be ON solid or flashing when you have made a proper connection.



Typical ST connector



Typical SC connector



Typical LC connector on an SFP transceiver

It is important to consider the output power and the receiver sensitivity for each end of each fiber connection, especially when the distances that each fiber transceiver in each switch are specified to support differ or when the transceivers (switches) are separated at a distance different than that which the transceivers are specified to support.

It is important to include in your network design an evaluation of the output power and receiver sensitivity based on:



The fiber cable loss (LF) plus attenuator loss (LR) should be greater than the transmit power (TX) minus the receive power (RX).

So,  $LR = TX1 - RX2 - LF$ , for the attenuator (LR) placed at RX2 and

$LR = TX2 - RX1 - LF$ , for the attenuator (LR) placed at RX1.

## Duplex Operation

The RJ45 ports will auto-sense for Full or Half duplex operation; the fiber ports are configured for full duplex operation. On managed switches the duplex setting is software configurable.



**NOTE:** Fiber devices with half duplex settings will communicate with the switch in most situations.

## Network Device Check

The industrial Ethernet switches and media converters support 10/100BaseT or 10/100/100 Base T on the RJ45 (copper) ports and 100BaseFX or gigabit Ethernet on the fiber optic ports depending on model. Make sure you connect the appropriate devices to each port.




**NOTE:** The following AutomationDirect PLC Ethernet Modules are not compatible with the Stride Ethernet switches and Media Converters with fiber optic connections because the modules have a speed of 10BaseF (fiber optic) only: Ethernet Communications Module, p/n H2-ECOM-F & H4-ECOM-F; Ethernet Base Controller Module, p/n H2-EBC-F & H4-EBC-F; Ethernet Remote Master Module, p/n H2-ERM-F & H4-ERM-F.

## Verifying Connectivity

After all Ethernet and/or fiber connections are made, check the LEDs corresponding to the ports that each of the devices are connected to. Ensure that for each port that is in use, the LED is on or blinking. If a port LED is off, go back and check for connectivity problems between that port and the network device connected to that port. In addition, the color of the LED should indicate the speed at which your device is connected (see prior section on LEDs).

## Serial Console Port Wiring

An optional way to configure the managed switch is through the RJ45 console RS232 port. Wire a serial console cable as shown below to make a connection between a COM port on your PC (DB9 male) and the RS232 port of the managed switch (RJ45 female).



## USB Console Port Wiring

The managed switches also have an USB port alternative to the RS232 port. Use a standard USB cable with a mini-USB plug on one end and an A-type-USB plug on the other end. The A-type plug goes into a standard USB port on a computer. The mini-USB plug goes into the USB port on the switch.

The USB driver is available for download at [automationdirect.com](http://automationdirect.com).



**NOTE:** The RS-232 and/or USB ports may be located on the bottom edge or front face of the switch.

## Technical Specifications

### Technical Specs

Here are the hardware technical specifications for the industrial Ethernet switches and media converters covered by this manual.

<i>General Specifications</i>	
<b>Ethernet switch type</b>	Unmanaged or Managed
<b>Operating mode</b>	Store & forward, wire speed switching, non-blocking
<b>Devices supported</b>	All IEEE 802.3 compliant devices are supported
<b>Protocols (managed models only)</b>	SNMPv1/v2/v3, RMON, DHCP, SNMP, TFTP, STP, RSTP, QoS/CoS/ToS/DS, IGMPv1/v2, VLAN (tag and port based), HTTP, HTTPS (SSL & TLS), Telnet, SSH and more
<b>Industrial Protocols supported</b>	Modbus/TCP, EtherNet/IP, PROFINet, Foundation Fieldbus HSE and others
<b>Standards (depends on model)</b>	IEEE 802.3, 802.3u, 802.3ab/z, 802.3x, 802.1D/w, 802.1p, 802.1Q and others
<b>Management Interfaces (managed models only)</b>	Web, text (Telnet & SSH), CLI (command line interface) and SNMP (see Chapter 2 - Managed Switch Software for supported MIBs)
<b>MAC addresses</b>	1024 on unmanaged models; 2048 on managed models with 5, 8 or 9 ports 8192 on Gigabit models with more than 9 ports
<b>Memory bandwidth</b>	3.2 Gbps on models with 9 or fewer ports 3.2 Gbps on models with more than 9 ports
<b>Latency for 10 Mbps ports*</b>	16 us + frame time (typical)
<b>Latency for 100 Mbps ports*</b>	< 5 us + frame time (typical)
<b>Ethernet isolation</b>	1500 VRMS 1 minute
<b>Management Serial Port (managed models only)</b>	RS232 (TXD, RXD and GND), 9600, 8, N, 1 fixed and/or mini-USB
<i>* Varies on load and settings</i>	

Technical Specifications continued on the next page.

## Technical Specifications (cont'd)

<b>Copper RJ45 Ports: (10/100 Mbps or 10/100/1000 Mbps)</b>	
<b>Copper Ports</b>	Shielded RJ45
<b>Speed</b>	10/100 Mbps or 10/100/1000 Mbps (depending on model)
<b>Protocols supported</b>	All standard IEEE 802.3
<b>Auto-crossover</b>	Yes, allows you to use straight-through or crossover wired cables
<b>Auto-sensing operation</b>	Yes, Full and half duplex
<b>Auto-negotiating</b>	Yes, 10BaseT and 100BaseT
<b>Auto-polarity</b>	Yes, on the TD and RD pair
<b>Flow control</b>	Automatic
<b>Ethernet isolation</b>	1500 VRMS 1 minute
<b>Plug and play</b>	Yes
<b>Cable requirements</b>	Twisted pair (Cat. 5 or better) (shielded recommended)
<b>Max. cable distance</b>	100 meters (328 ft)

Technical Specifications continued on the next page.

## Technical Specifications (cont'd)

<b>SC or ST Fiber Ports: 100BaseF multimode</b>	
<b>100BaseFX ports</b>	1 on some unmanaged switch models 2 on some managed switch models
<b>Fiber port mode</b>	Multimode (mm)
<b>Fiber port connector</b>	Duplex SC or ST
<b>Optimal fiber cable</b>	50/125 or 62.5/125 $\mu$ m for mm; 9/125 $\mu$ m for sm
<b>Center wavelength</b>	1300 nm
<b>Multimode</b>	Links up to 4 km typ.; 1300 nm; use with 50 or 62.5/125 $\mu$ m fiber > Transmitter power (dB): -21 min, -17 typ, -14 max > Receiver sensitivity (dB): -34 typ, -31 max
<b>Nominal max. distance (full duplex) (see web for details)</b>	4 km
<b>Half and Full Duplex</b>	Full duplex
<b>Ethernet Compliance</b>	100BaseF
<b>Eye Safety</b>	IEC 60825-1, Class 1; FDA 21 CFR 1040.10 and 1040.11

<b>SFP (Small Form Factor pluggable) Ports</b>	
<i>Note: On the Gigabit (MG) models these ports are pluggable and accept any SFP Multi-Source Agreement compliant transceiver.</i>	
<b>Gigabit SFP ports</b>	2 or 4 depending on model
<b>Port Types Supported</b>	All SFP Multi-Source Agreement compliant transceivers
<i>Note: 100 Mbps fiber transceiver modules are also supported on these ports.</i>	
<b>Ethernet Compliance</b>	1000BaseT and 1000BaseF (SX/LX/LH)
<b>Eye safety</b>	IEC 60825-1, Class 1; FDA 21 CFR 1040.10 and 1040.11



**NOTE:** Refer to SFP module specifications for details specific to the SFP installed.



**NOTE:** When powering multiple switches from a common power supply, it is most reliable to power the switches sequentially rather than simultaneously. The characteristics of the power supply and the significant startup current of the switches may result in an error in booting the switches when powered simultaneously.

## Technical Specifications (cont'd)

<b><i>"OK" Alarm Output (Managed models only)</i></b>	
<b><i>"OK" Output</i></b>	ON if P1 and P2 have power and switch software is running
<b><i>Voltage</i></b>	Same as switch input voltage
<b><i>Maximum Current Output</i></b>	0.5 Amp

<b><i>Power Input</i></b>	
<b><i>Power Input</i></b>	Redundant Input Terminals
<b><i>Input power (typical with all ports active at 100 Mbps)</i></b>	SE-MC2U-SC - 2.0W SE-MC2U-ST - 2.0W SE-SW5U - 2.0W SE-SW5U-WT - 2.0W SE-SW5U-SC - 3.0W SE-SW5U-SC-WT - 3.0W SE-SW5U-ST - 3.0W SE-SW5U-SC-WT - 3.0W SE-SW8U - 4.0W SE-SW8U-WT - 4.0W SE-SW9U-SC - 5.0W SE-SW9U-SC-WT - 5.0W SE-SW9U-ST - 5.0W SE-SW9U-ST-WT - 5.0W
	SE-SW5M - 3.6W SE-SW5M-2SC - 5.6W SE-SW5M-2ST - 5.6W SE-SW8M - 4.3W SE-SW8M-2SC - 6.3W SE-SW8M-2ST - 6.3W SE-SW8MG-4P - 12.0W - No Fiber SE-SW8MG-4P - 15.0W - With 4 Fiber plugged in SE-SW10MG-2P - 5.0W - No Fiber SE-SW10MG-2P - 7.0W - With 4 Fiber plugged in SE-SW16M - 7.0W
<b><i>Input Voltage (all models)</i></b>	10-30 VDC (continuous)
<b><i>Reverse Power Protection</i></b>	Yes
<b><i>Transient Protection</i></b>	15,000 watts peak
<b><i>Spike Protection</i></b>	5,000 watts (10x for 10 uS)

## Technical Specifications (cont'd)

<i>Environmental</i>	
<b>Storage Temperature Range</b>	-40 to +85 °C (-40 to +185 °F)
<b>Humidity (non-condensing)</b>	5 to 95% RH
<b>Electrical Safety</b>	UL508/GSA C22, EN61010-1, CE
<b>EMC: emissions and immunity</b>	FCC part 15, ICES-003; EN61000-6-2, EN61000-6-4 Typical 8 or 9/125 µm for singlemode (sm)
<b>Hazardous Locations</b>	UL HazLoc, CSA C22.2/213 (Class I, Div.2) ; EN60079-15 (Zone2), CE (ATEX)
<b>Eye Safety (fiber models)</b>	IEC60825-1, Class 1; FDA 21 CFR 1040.10 and 1040.11
<b>RoHS and WEEE</b>	RoHS (Pb free) and WEEE compliant
<b>ISO9001:2000</b>	Certified "Total Quality" company

<i>Mechanical</i>	
<b>Ingress Protection</b>	IP30 for all plastic cased units. IP40 for all metal cased units.
<b>Packaging and Protection</b>	UL94V0 Lexan plastic for all plastic cased units. Aluminum w/ protective finish for all metal cased units.
<b>Dimensions (L x W x H)</b>	See mechanical drawings for details

