OrSense FSD Series Flow Switches





Part No. FSD75-AP-6H

Part No. FSD1-AP-26H

Overview

The ProSense FSD Series flow switches monitor liquid media and provide reliable flow detection for various flow applications.

The ProSense FSD Series sensing principle ensures extremely fast response time and allows for a more precise setpoint setting. The setpoint can be easily set and locked with a setting screw.

The ProSense FSD Series flow switches are ideal for applications with rapid temperature changes or where fast response time is required, such as:

- · Machine tool coolant flow
- HVAC cooling water flow
- Injection molding cooling water flow

Features

- Monitor 0.26 to 26.4 GPM (gallons per minute) in 2 models
- Immune to rapid temperature changes of media
- Fast response time of 10ms: great for cycling applications with a minimum of 10 million switching cycles
- · Easy to set: turn dial to desired setpoint
- Able to be bench set outside the process
- 3/4" or 1" FNPT process connections
- Integrated check valve design allows the sensor to be mounted horizontally or vertically
- 4-pin M12 quick-disconnect
- IP65 / IP67
- LED output status indication
- · 2-year warranty







Click on the thumbnail or go to https://www.automationdirect.com/VID-FL-0001 for a short introductory video on the FSD Series Flow Switches

ProSense FSD Series Flow Switches							
Part No.	Description	Quantity	Weight (lbs)	Price			
<u>FSD75-AP-6H</u>	24VDC, 0.26 to 6.6 GPM setpoint range, rotating dial adjustment with lock screw, 26.4 GPM max flow rate, nickel-plated brass housing with 3/4 in. FNPT process connections, N.O. DC PNP output. Cable sold separately.	1	1.0	\$151.00			
FSD1-AP-26H	24VDC, 1.32 to 26.4 GPM setpoint range, rotating dial adjustment with lock screw, 52.8 GPM max flow rate, nickel-plated brass housing with 1 in. FNPT process connections, N.O. DC PNP output. Cable sold separately.	1	1.6	\$182.00			

ProSense FSD Series Flow Switches Technical Specifications					
Model	<u>FSD75-AP-6H</u>	FSD1-AP-26H			
Operating Voltage	20.4 to 26.4 VDC (must use a Class 2 power supply in order to comply with UL508 requirements)				
Electrical Connection	M12 (note: tightening torque < 0.6 Nm based on cable)				
Connection Pin Material	Gold-plated				
Output Function	Normally open (PNP)				
Output Maximum Load Current	100mA				
Current Consumption	< 15mA				
Voltage Drop	< 2.5 VDC				
Short-Circuit Protection	YES				
Reverse Polarity Protection	YES				
Overload Protection	YES				
Switching Cycles Minimum	10 million				
Response Time	10ms				
Accuracy*	± 5% of full range				
Repeatability	0.06 GPM	0.26 GPM			
Process Connection	3/4" FNPT	1" FNPT			
Medium	liquids (water, glycol solutions, oils)				
Maximum Viscosity	<68 centistokes				
Maximum Flow Rate	< 26.4 GPM	< 52.8 GPM			
Setpoint Range	0.26 – 6.6 GPM	1.32 – 26.4 GPM			
Hysteresis	0.13 – 0.53 GPM	0.8 – 1.58 GPM			
Pressure Rating	362PSI				

^{*} when used with water



FSD Series Flow Switches

ProSense FSD Series Flow Switches Environmental Specifications					
Model	<u>FSD75-AP-6H</u>	<u>FSD1-AP-26H</u>			
Housing Material	Brass chemically nickel plated; aluminum anodized; POM				
Materials (wetted parts)	Stainless steel (304S15); Brass; brass chemically nickel plated*; PP (Polypropylene); Pocan PBT (Polybutylene terephthalate); O-ring: FPM (Viton)				
Operating Temperature	32 to 140°F (0 to 60°C)				
Medium Temperature	32 to 185°F (0 to 85°C)				
Storage Temperature	-40 to 212°F (-40 to 100°C)				
Protection	IP65 / IP67				
Protection Class	III				
Agency Approvals	cULus (#E320431), CE, RoHs				


^{*} The brass contains between 1-2% lead by weight. Not recommended for use in potable water applications.



Note: Check the chemical compatibility of the sensor's wetted parts with the medium to be mesured.

Wiring Diagrams





Cable Assembly Wiring Colors:
Pin 1 - Brown
Pin 2 - White
Pin 3 - Blue
Pin 4 - Black

Note: Wiring colors are based on AutomationDirect CD12L and CD12M 4-pole cable assemblies.

LED Functions


The FSD units monitor the flow of liquid media such as: water, glycol solutions, and oils. The LED functions are as follows:

- Output closed (LED = ON), if volumetric flow quantity M setpoint.
- Output open (LED = OFF), if volumetric flow quantity I setpoint.


There are 4 LEDs (one on each side) on the top connector for easy visibility regardless of installation orientation.

Installation*:

For proper flow switch operation, the sensor should be installed as indicated in the Illustrations below (noting the flow direction arrow on the body of the sensor):



^{*} Integral check valve design allows the sensor to be mounted in any position (horizontally or vertically).




Vertical Mounting




FSD Series Flow Switches

Pressure Loss/Flow Rate*

FSA75-42-6H





FSD1-AP-26H



^{*} when used with water







Part No. FSD75-AP-6H



Click or scan the above QR code to be taken to the installation insert for the FSD75 Series Flow Switches

Click or scan the above QR code to be taken to the installation insert for the FSD1 Series Flow Switches

Part No. FSD1-AP-26H

See our website <u>www.AutomationDirect.com</u> for complete Engineering drawings.




FSD Series Flow Switches

Operation & Setting

The flow sensor utilizes a spring-supported piston that is lifted by the flowing medium. The piston position is detected via an inductive sensor and is output as a binary signal. The spring resets the piston to its initial position with decreasing flow. This allows the sensor to be mounted in any position (horizontally or

vertically) and function as a check valve.





Note: Hysteresis varies based on switch setpoint.


Cutaway View

Setting FSD Series flow switches is quick and easy. There are two ways to set the flow switches - using a desired flow value and adjustment to existing flow.

Setting the ProSense FSD using a desired flow value

- 1. Loosen the locking screw.
- 2. Set the switching point by rotating the Setpoint dial until the desired flow value just becomes visible on the setting scale.
- 3. Tighten the locking screw.

Example in Figure 1: desired value = 2 GPM



Adjustment to existing flow

- 1. Let the normal flow circulate in the installation.
- 2. Loosen the locking screw.
- 3. Set the switching point by rotating the Setpoint dial.
- • If the LED lights before setting: turn the Setpoint dial in the direction [+] until the LED goes out. Then turn in the opposite direction [-] until the LED lights.
- · If the LED does not light before setting: turn the Setpoint dial in the direction [-] until the LED lights.
- 4. Tighten the locking screw.

Correlation between the number of turns of the Setpoint dial and the switching point is that one complete turn of the Setpoint dial corresponds to an approximate gallons per minute rate. This is shown in the table below:

Part Number	Gallons/Minute	Max. Gallons/Minute*
FSD75-AP-6H	0.8 GPM	6.6 GPM
FSD1-AP-26H	3.3 GPM	26.4 GPM



Do not turn the setting screw beyond the maximum value of the setting range to avoid faulty switching.