Table of Contents

Chapter 1: Getting Started

Introduction **1-2**
The Purpose of this Manual 1-2
Supplemental Manuals 1-2
Technical Support 1-2
Conventions Used **1-3**
Key Topics for Each Chapter 1-3
Product Overview **1-4**
Quick Start Steps **1-5**
Step 1 – Unpack and Inspect 1-5
Step 2 – Install Optional Hardware Accessories 1-6
Step 3 – Become Familiar with Available Communication Ports 1-7
Step 4 – Install the Programming Software and Develop a Project 1-8
Step 5 – Connect Touch Panel to Computer 1-9
Step 6 – Provide Power to the Touch Panel 1-10
Step 7 – Access the Touch Panel Setup Screens 1-12
Step 8 – Choose Touch Panel to Device Cables 1-13
Step 9 – Connect Touch Panel to PLC 1-16

Chapter 2: Specifications

Available Models **2-4**
Model Specifications **2-5**
Specifications common to all models 2-6
6-inch Models 2-7
7-inch Models 2-8
8-inch and 10-inch Models 2-9
12-inch and 15-inch Models 2-10

EA9-T6CL-R, EA9-T6CL **2-11**
Dimensions, Inches [mm] 2-11
Ports and Memory Expansion 2-12
EA9-T7CL-R, EA9-T7CL **2-13**
Dimensions, Inches [mm] 2-13
Ports and Memory Expansion 2-14
EA9-T8CL **2-15**
Dimensions, Inches [mm] 2-15
Ports and Memory Expansion 2-16
EA9-T10CL **2-17**
Dimensions, Inches [mm] 2-17
EA9-T10WCL **2-18**
Dimensions, Inches [mm] 2-18
Ports and Memory Expansion 2-19
EA9-T12CL **2-20**
Dimensions, Inches [mm] 2-20
Ports and Memory Expansion 2-21
EA9-T15CL-R, EA9-T15CL **2-22**
Dimensions, Inches [mm] 2-22
Ports and Memory Expansion 2-23
Mounting Clearances **2-25**
EA9-T15CL-R, EA9-T15CL Derating 2-26
Communications Ports **2-27**
Handling External Memory Devices **2-30**
Writing to External Memory Devices 2-30
Memory Device Formatting 2-30
Minimizing Data Errors 2-31
Monitoring Available Memory 2-31
File Name Limitations 2-32
Power Loss Retention 2-32
Chemical Compatibility **2-32**

Chapter 3: Accessories

Accessories Overview **3-2**

AC/DC Power Adapter **3-3**

AC/DC Power Adapter Dimensions 3-5

AC/DC Power Adapter Installation 3-6

EA-ECOM Ethernet Communication Module **3-7**

D-SUB 15-pin to Terminal Block Adapters **3-8**

Non-glare Screen Covers **3-9**

Clear Screen Overlay Installation 3-10

SD Card **3-11**

USB FLASH Drive **3-11**

Chapter 4: Installation and Wiring

Safety Guidelines **4-2**

Introduction **4-3**

UL Requirements **4-4**

EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL Cutout Dimensions **4-5**

EA9-T8CL Cutout Dimensions **4-6**

EA9-T10WCL Cutout Dimensions **4-7**

EA9-T10CL Cutout Dimensions **4-8**

EA9-T12CL Cutout Dimensions **4-9**

EA9-T15CL-R and EA9-T15CL Cutout Dimensions **4-10**

Mounting Clearances **4-11**

EA9-T15CL-R, EA9-T15CL Derating 4-12

Wiring Guidelines **4-13**

Agency Approvals 4-13

Providing Power to the Touch Panel 4-14

C-more LED Status Indicators 4-15

Chapter 5: System Setup Screens

Introduction **5-2**

Accessing the System Setup Screens (no project loaded) **5-3**

Accessing the System Setup Screens (with project loaded) 5-4
System Setup Screens – Enable Password in Software 5-6
System Setup Screens Flowchart 5-12
Main Menu 5-13
Information Menu 5-14
Setting Menu 5-18
Test Menu 5-25
Memory Menu 5-34

Chapter 6: PLC Communications

Introduction 6-2
Direct**LOGIC PLCs Password Protection 6-2**
PLC Protocols 6-3
PLC Communication Cables & Wiring Diagrams 6-5
AutomationDirect PLCs RS-232C Serial 6-7
AutomationDirect PLCs RS-422A/RS-485A 6-10
DirectLOGIC Universal Isolated Network Adapter, p/n FA-ISOCON: 6-16
DirectLOGIC Universal Converter, p/n F2-UNICON: 6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples 6-18
Allen-Bradley 6-22
GE 6-27
GE VersaMax Micro 6-27
Mitsubishi 6-28
Omron 6-30
Modicon Modbus RS-232 6-31
Modicon Micro Series 6-31
Modicon Modbus with RJ45 6-31
Siemens 6-32

Chapter 7: Maintenance

Project Backup 7-2
Check Operating Environment 7-2
Check Operating Voltage 7-2
Check Status Indicators 7-2

Check Physical Conditions 7-3
Run Tests under System Setup Screens 7-3
Check Memory Usage 7-4
Check/Adjust Display Brightness 7-4
Check Error Log 7-4
Adjust Touch Panel 7-4
Cleaning the Display Screen 7-5
Check Project Functionality 7-6
Checks from C-more Programming Software 7-6

Notes: 7-7

Chapter 8: Troubleshooting

Common Problems 8-2
Troubleshooting Flow Chart 8-3
Touch Panel does not Power up 8-4
Display is Blank 8-5
Display is Dim 8-6
No User Program 8-7
Firmware Recovery Tool 8-8
No System Found 8-9
No Communications between Panel and PC (Personal Computer) via USB 8-10
USB Driver Troubleshooting 8-12
No Communications between Panel and PC (Personal Computer) via Ethernet 8-14
No Communications between Panel and PLC 8-18
IP Address in System Setup Screens displays 0.0.0.0 8-21
Difficulty Connecting to the Panel over the Internet (Webserver (Secure HTTPs) and Remote Access features) 8-22
PLC Protocol Error Codes 8-23
Touch Panel Runtime Errors 8-24
Panel Constantly Displays “Initializing” when Powering up 8-25
Data not Logging Problems 8-25
Electrical Noise Problems 8-26

Chapter 9: Replacement Parts

Replacement Parts Overview 9-2

Panel Mounting Clip Replacements – EA9-BRK 9-3
Logo Label Replacement Insert - EA9-LBL 9-4
3-wire Communications Terminal Block – EA9-3TB 9-5
DC Panel Power Connector Replacement – EA-DC-CON 9-5
AC Power Adapter Connector Replacement– EA-AC-CON 9-6
Panel Gasket Replacements – EA9-xx-GSK 9-7
Gasket Replacement Installation Instructions: 9-7

Appendix A: Panel and PLC Error Code Tables

Introduction A-2
C-more **Touch Panel Error Code Table** A-3
Direct**LOGIC – Panel Error Code PLC-499 Explanation** A-5
Direct**LOGIC K-Sequence Protocol – PLC Error Code Table** A-5
Direct**LOGIC** Direct**NET Protocol – PLC Error Codes** A-5
Modbus Protocols Error Code P499 Explanation A-6
AutomationDirect CLICK A-6
AutomationDirect DirectLOGIC - Modbus (Koyo) A-6
Modicon Modbus RTU A-6
Entivity Modbus RTU A-6
Direct**LOGIC ECOM Protocol – PLC Error Codes** A-6
Productivity Error Code P499 ..... A-7
AutomationDirect Do-More Error Codes A-8
Allen-Bradley – Panel Error Code PLC-499 Explanation A-9
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables A-10
Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix A-13
Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables A-17
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables A-21

Generic EtherNet IP Protocol – PLC Error Codes A-26
GE 90-30 – Panel Error Code PLC-499 Explanation A-27
GE 90-30 SNPX Protocol – PLC Error Code Tables A-28
Mitsubishi FX Protocol – PLC Error Codes A-37
Omron – Panel Error Code PLC-499 Explanation A-37
Omron Host Link Protocol – PLC Error Code Table A-38
Omron FINS Protocol – PLC Error Code Table A-39
Omron – Panel Error Code P495 Explanation A-42
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table A-43
Siemens – Panel Error Code P499 Explanation A-44
Siemens PPI Protocol – PLC Error Code Table A-45
Siemens ISO over TCP Protocol – PLC Error Code Table A-46

Appendix B: Touch Panel Runtime Errors

Introduction B-2
Runtime Errors B-3
Log File Naming B-4

Appendix C: Security Considerations for Control Systems Networks

Security Considerations for Control Systems Networks C-2