

TABLE OF CONTENTS



Chapter 1 - Getting Started

Introduction.....	1-2
Conventions Used.....	1-3
Mounting Clips – New Style.....	1-3
Product Overview	1-4
Part Number Key – Touch Panels.....	1-5
EZTouch Conversion and Mounting	1-6
EZTouch Touch Panel Cross Reference to C-more	1-7
Quick Start Steps	1-9
Step 1 – Unpack and Inspect.....	1-9
Step 2 – Assemble Temporary Support Stand.....	1-10
Step 3 – Install Optional Hardware Accessories.....	1-11
Step 4 – Become Familiar with Available Communication Ports.....	1-12
Step 5 – Install the Programming Software and Develop a Project	1-13
Step 6 – Connect Touch Panel to Computer	1-14
Step 7 – Provide Power to the Touch Panel.....	1-15
Step 8 – Access the Touch Panel Setup Screens.....	1-16
Step 9 – Choose Touch Panel to Device Protocol & Cables.....	1-17
Step 10 – Connect Touch Panel to PLC	1-20

Chapter 2 - Specifications

Available Models.....	2-2
Model Specifications	2-3
6" Base Feature Models.....	2-4
6" Full Feature Models	2-5
6" Obsolete Models	2-6
8" and 10" Full Feature Models	2-8

Table of Contents

12" and 15" Full Feature Models	2-9
EA7-S6M-R, S6C-R, T6CL-R, S6M, S6C, T6C, T6CL (Dimensions and Ports & Memory Exp.)	2-10
EA7-T8C (Dimensions and Ports & Memory Exp.)	2-12
EA7-T10C (Dimensions and Ports & Memory Exp.)	2-14
EA7-T12C (Dimensions and Ports & Memory Exp.)	2-16
EA7-T15C (Dimensions and Ports & Memory Exp.)	2-18
Mounting Clearances	2-20
Communications Ports	2-21
Audio WAV File Specifications.....	2-23
Memory Organization	2-24
Handling External Memory Devices.....	2-25
Power Loss Detection and Power Retention Period	2-26
Data Logging Function and Logging Media	2-26
Data Logging - Memory Device Full	2-26
Chemical Compatibility	2-27

Chapter 3 - Accessories

Accessories	3-2
Accessories Overview.....	3-3
Accessories at a Glance	3-4
AC/DC Power Adapter – EA-AC	3-5
Expansion Assembly – EA-EXP-OPT.....	3-9
CF Card Interface Module – EA-CF-IF.....	3-12
CompactFlash Memory – EA-CF-CARD.....	3-14
6" Adapter Plate – EA-6-ADPTR	3-17
D-SUB 15-pin 90 degree Comm Port Adapter – EA-ADPTR-4.....	3-19
D-SUB 15-pin to Terminal Block Adapter – EA-COMCON-3.....	3-20
Non-glare Screen Covers – EA-xx-COV2, xx = 6, 8, 10, 12 or 15	3-22

Chapter 4 - Installation and Wiring

Safety Guidelines	4-2
Introduction	4-3
EA7-S6M-R, S6C-R, T6CL-R, S6M, S6C, T6C, T6CL – Cutout Dimensions	4-4
EA7-T8C – Cutout Dimensions	4-5
EA7-T10C – Cutout Dimensions	4-6
EA7-T12C – Cutout Dimensions	4-7
EA7-T15C – Cutout Dimensions	4-8
6" Adapter Plate – EA-6-ADPTR	4-9
Mounting Clearances	4-11
Wiring Guidelines	4-12
Agency Approvals.....	4-12
Marine Use.....	4-12
Providing Power to the Touch Panel	4-13
DC Wiring Diagram.....	4-13
AC Wiring Diagram (EA-AC)	4-14

Chapter 5 - System Setup Screens

Introduction	5-2
Chapter Organization.....	5-3
Accessing the System Setup Screens (no project loaded)	5-4
Accessing the System Setup Screens (with project loaded)	5-5
System Setup Screens – Enable Password in Software	5-7
System Setup Screens Flowchart	5-13
Main Menu.....	5-14
Information Menu	5-15
Setting Menu	5-19
Test Menu	5-25
Memory Menu	5-35

Table of Contents

Chapter 6 - PLC Communications

Introduction	6-2
DirectLOGIC PLCs Password Protection	6-2
PLC Communication Cables & Wiring Diagrams.....	6-5
AutomationDirect PLCs RS-232C Serial:.....	6-7
AutomationDirect PLCs RS-422A/RS-485A:.....	6-10
Direct LOGIC Universal Isolated Network Adapter, p/n FA-ISOCON:.....	6-16
Direct LOGIC Universal Converter, p/n F2-UNICON:.....	6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples	6-18
Allen-Bradley:	6-22
GE:	6-27
GE VersaMax Micro:	6-27
Mitsubishi:.....	6-27
Omron:	6-29
Modicon ModBus RS-232:.....	6-30
Modicon Micro Series:.....	6-30
Modicon ModBus with RJ45:.....	6-30
Siemens:.....	6-31

Chapter 7 - Maintenance

Project Backup	7-2
Check Operating Environment.....	7-2
Check Operating Voltage	7-2
Check Status Indicators	7-2
Check Physical Conditions.....	7-3
Run Tests under System Setup Screens	7-3
Check Memory Usage via System Setup Screens	7-4
Check/Adjust Display Brightness or Contrast.....	7-4
Check Error Log via System Setup Screens	7-4
Adjust Touch Panel via System Setup Screens	7-4
Replace Battery Periodically	7-5
Cleaning the Display Screen	7-5

Check Project Functionality.....	7-6
Checks from C-more Programming Software	7-6

Chapter 8 - Troubleshooting

Common Problems	8-2
Toubleshooting Flow Chart.....	8-3
Touch Panel does not Power up	8-4
Display is Blank.....	8-5
Display is Dim	8-6
No User Program.....	8-7
No Communications between Panel and PC (Personal Computer) via USB.....	8-8
USB Driver Troubleshooting	8-10
No Communications between Panel and PC (Personal Computer) via Ethernet .	8-12
No Communications between Panel and PLC.....	8-16
IP Address in System Setup Screens displays 0.0.0.0	8-19
Difficulty Connecting to the Panel over the Internet (Web server and Remote Access features)	8-20
PLC Protocol Error Codes	8-21
Touch Panel Runtime Errors.....	8-22
Panel Constantly Displays “Initializing” when Powering up	8-23
Data not Logging Problems.....	8-23
Loss of Date/Time and Retentive Data.....	8-24
Electrical Noise Problems	8-24

Chapter 9 - Replacement Parts

Replacement Parts Overview	9-2
Replacement Parts at a Glance	9-2
Battery Replacement & Installation Instructions.....	9-3
6" Panel Mounting Clip Replacements & Installation.....	9-5
8-15" Panel Mounting Clip Replacements & Installation.....	9-6



Table of Contents

DC Panel Power Connector Replacement	9-7
AC Power Adapter Connector Replacement	9-7
8-15" Panel Backlight Bulb Replacements & Installation	9-8
6-15" Panel Gasket Replacement & Installation.....	9-11
8-15" Panel Bezel Replacement & Installation	9-12
6" Adapter Plate Gasket Replacement & Installation	9-14

Appendix A - Panel & PLC Error Code Tables

Introduction	A-2
C-more Touch Panel Error Code Table	A-3
DirectLOGIC – Panel Error Code PLC-499 Explanation	A-5
DirectLOGIC K-Sequence Protocol – PLC Error Code Table.....	A-5
DirectLOGIC DirectNET Protocol – PLC Error Codes	A-5
Modbus Protocols Error Code P499 Explanation	A-6
AutomationDirect CLICK	A-6
AutomationDirect DirectLOGIC - Modbus (Koyo).....	A-6
Modicon Modbus RTU	A-6
Entivity Modbus RTU.....	A-6
DirectLOGIC ECOM Protocol – PLC Error Codes	A-6
Productivity3000 Error Code P499.....	A-7
Allen-Bradley – Panel Error Code PLC-499 Explanation	A-8
Allen-Bradley Error Code PLC-499 Message Example:.....	A-8
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables	A-9
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables	A-10
Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation	A-11
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix	A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables MicroLogix 1100, 1400 & SLC 5/05, both via native Ethernet port; MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5/03/04/05, all via ENI Adapter.	A-16
Generic EtherNet IP Protocol – PLC Error Codes	A-21

GE 90-30 – Panel Error Code PLC-499 Explanation	A-22
Mitsubishi FX Protocol – PLC Error Codes.....	A-32
Omron – Panel Error Code PLC-499 Explanation	A-32
Omron Host Link Protocol – PLC Error Code Table	A-33
Omron FINS Protocol – PLC Error Code Table	A-34
Omron – Panel Error Code P495 Explanation	A-37
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table.....	A-38
Siemens – Panel Error Code P499 Explanation.....	A-39
Siemens PPI Protocol – PLC Error Code Table.....	A-40
Siemens ISO over TCP Protocol – PLC Error Code Table	A-41

Appendix B - Touch Panel Runtime Errors

Introduction.....	B-2
Runtime Errors.....	B-3

Appendix C - Mounting Clips Prior April 2006

Introduction.....	C-2
EA7-S6M-R, S6C-R, S6M, S6C and T6C Original Mounting Clips.....	C-3
EA7-S6M-R, S6C-R, S6M, S6C and T6C Original Mounting Clips.....	C-4
EA7-T8C Original Mounting Clips	C-5
EA7-T8C Original Mounting Clips	C-6
EA7-T10C Original Mounting Clips	C-7
EA7-T10C Original Mounting Clips	C-8
EA7-T12C Original Mounting Clips	C-9
EA7-T12C Original Mounting Clips	C-10
EA7-T15C Original Mounting Clips	C-11

Appendix D - Security Considerations for Control System Networks

Security Considerations for Control Systems Networks.....	D-2
---	-----

Index

