

# Table of Contents

---

<b>Introduction</b> .....	<b>1</b>
Overview .....	2
Manual Layout .....	3
DCM Hardware .....	4
<b>Applications</b> .....	<b>5</b>
As a <i>Direct</i> NET Interface .....	5
As an Extra Communication Port .....	6
As a Modbus® Network Interface .....	6
<b>Specifications</b> .....	<b>7</b>
Environmental Specifications .....	7
Operating Specifications .....	7
<b>Using Your DCM – Five Steps</b> .....	<b>8</b>
<b>Building the Communication Cable.</b> .....	<b>9</b>
Consideration 1: Physical Configuration .....	10
Consideration 2: Electrical Specification RS232C or RS422 .....	11
Consideration 3: Cable Schematics .....	12
Consideration 4: Cable Specifications .....	16
Consideration 5: Installation Guidelines .....	16
Consideration 6: A Quick Test Cable .....	19
<b>Setting the DCM Switches</b> .....	<b>21</b>
Host Computer or Operator Interface Connection .....	21
<i>Direct</i> NET Interface Connection .....	22
DCM Switch Settings .....	23
Online / Offline Switch .....	25
Address Selection Switch .....	26
<b>Installing the DCM and Starting the Network</b> .....	<b>27</b>
Install the DCM .....	27
Connect the Cables .....	27
If you're using <i>Direct</i> NET... .....	27
If you're using an Operator Interface or Host Computer... .....	28
If you're using Modbus® .....	28
<b>Verification and Troubleshooting.</b> .....	<b>29</b>
<b>Appendix A: RLL Communications Programs</b> .....	<b>A-1</b>
<b>Why do you need a communications program?</b> .....	<b>A-2</b>
The Master Initiates Requests .....	A-2
Why Ladder Logic? .....	A-2
<b>Identifying the master and slave</b> .....	<b>A-4</b>
Location of Master and Slave .....	A-4
<b>Specifying the amount of data</b> .....	<b>A-5</b>
Number of Bytes to Transfer .....	A-5

---

<b>Designating the master station memory area</b> .....	<b>A-6</b>
Memory Area of Master .....	A-6
<b>Identifying the slave station memory area</b> .....	<b>A-7</b>
Memory Area of Slave to Read or Write .....	A-7
<b>Controlling the communications</b> .....	<b>A-8</b>
Communications Special Relays .....	A-8
Multiple Read and Write Interlocks .....	A-9
DL305/405 Cross Reference .....	A-10

---