



# TABLE OF CONTENTS

---

<b>Chapter 1: Getting Started</b> .....	<b>1-1</b>
Introduction.....	1-2
Conventions Used .....	1-3
Mounting Clips – New Style .....	1-3
Product Overview .....	1-4
Part Number Key – Touch Panels .....	1-5
EZTouch Conversion and Mounting .....	1-6
EZTouch Touch Panel Cross Reference to C-more.....	1-7
<b>Quick Start Steps</b> .....	<b>1-9</b>
Step 1 – Unpack and Inspect .....	1-9
Step 2 – Assemble Temporary Support Stand.....	1-10
Step 3 – Install Optional Hardware Accessories.....	1-11
Step 4 – Become Familiar with Available Communication Ports .....	1-12
Step 5 – Install the Programming Software and Develop a Project.....	1-13
Step 6 – Connect Touch Panel to Computer .....	1-14
Step 7 – Provide Power to the Touch Panel .....	1-15
Step 8 – Access the Touch Panel Setup Screens .....	1-16
Step 9 – Choose Touch Panel to PLC Protocol & Cables .....	1-17
Step 10 – Connect Touch Panel to PLC .....	1-20
<b>Chapter 2: Specifications</b> .....	<b>2-1</b>
<b>Available Models</b> .....	<b>2-2</b>
<b>Model Specifications</b> .....	<b>2-3</b>
6" Base Feature Models .....	2-4
6" Full Feature Models .....	2-5
6" Obsolete Models .....	2-6

8" and 10" Full Feature Models . . . . .	2-8
12" and 15" Full Feature Models . . . . .	2-9
<b>EA7-S6M-R, S6C-R, T6CL-R, S6M, S6C, T6C, T6CL (Dimensions and Ports &amp; Memory Exp.) . . . . .</b>	<b>2-10</b>
<b>EA7-T8C (Dimensions and Ports &amp; Memory Exp.) . . . . .</b>	<b>2-12</b>
<b>EA7-T10C (Dimensions and Ports &amp; Memory Exp.) . . . . .</b>	<b>2-14</b>
<b>EA7-T12C (Dimensions and Ports &amp; Memory Exp.) . . . . .</b>	<b>2-16</b>
<b>EA7-T15C (Dimensions and Ports &amp; Memory Exp.) . . . . .</b>	<b>2-18</b>
<b>Mounting Clearances . . . . .</b>	<b>2-20</b>
<b>Communications Ports . . . . .</b>	<b>2-21</b>
<b>Audio WAV File Specifications. . . . .</b>	<b>2-23</b>
<b>Memory Organization . . . . .</b>	<b>2-24</b>
<b>Handling External Memory Devices . . . . .</b>	<b>2-25</b>
<b>Power Loss Detection and Power Retention Period . . . . .</b>	<b>2-26</b>
<b>Data Logging Function and Logging Media . . . . .</b>	<b>2-26</b>
<b>Data Logging - Memory Device Full . . . . .</b>	<b>2-26</b>
<b>Chemical Compatibility . . . . .</b>	<b>2-27</b>
<b>Chapter 3: Accessories . . . . .</b>	<b>3-1</b>
Accessories . . . . .	3-2
Accessories Overview. . . . .	3-3
Accessories at a Glance . . . . .	3-4
AC/DC Power Adapter – EA-AC . . . . .	3-5
Expansion Assembly – EA-EXP-OPT. . . . .	3-9
CF Card Interface Module – EA-CF-IF . . . . .	3-12
CompactFlash Memory – EA-CF-CARD . . . . .	3-14
6" Adapter Plate – EA-6-ADPTR . . . . .	3-17
D-SUB 15-pin 90 degree Comm Port Adapter – EA-ADPTR-4 . . . . .	3-19
D-SUB 15-pin to Terminal Block Adapter – EA-COMCON-3. . . . .	3-20
Non-glare Screen Covers – EA-xx-COV2, xx = 6, 8, 10, 12 or 15 . . . . .	3-22

<b>Chapter 4: Installation and Wiring</b> . . . . .	<b>4-1</b>
Safety Guidelines . . . . .	4-2
Introduction . . . . .	4-3
EA7-S6M-R, S6C-R, T6CL-R, S6M, S6C, T6C, T6CL – Cutout Dimensions . . . . .	4-4
EA7-T8C – Cutout Dimensions . . . . .	4-5
EA7-T10C – Cutout Dimensions . . . . .	4-6
EA7-T12C – Cutout Dimensions . . . . .	4-7
EA7-T15C – Cutout Dimensions . . . . .	4-8
6" Adapter Plate – EA-6-ADPTR . . . . .	4-9
Mounting Clearances . . . . .	4-11
Wiring Guidelines . . . . .	4-12
Agency Approvals . . . . .	4-12
Marine Use . . . . .	4-12
Providing Power to the Touch Panel . . . . .	4-13
DC Wiring Diagram . . . . .	4-13
AC Wiring Diagram (EA-AC) . . . . .	4-14
<b>Chapter 5: System Setup Screens</b> . . . . .	<b>5-1</b>
Introduction . . . . .	5-2
Chapter Organization . . . . .	5-3
Accessing the System Setup Screens (no project loaded) . . . . .	5-4
Accessing the System Setup Screens (with project loaded) . . . . .	5-5
System Setup Screens – Enable Password in Software . . . . .	5-7
System Setup Screens Flowchart . . . . .	5-13
Main Menu . . . . .	5-14
Information Menu . . . . .	5-15
Setting Menu . . . . .	5-19
Test Menu . . . . .	5-25
Memory Menu . . . . .	5-35

<b>Chapter 6: PLC Communications</b> . . . . .	<b>6-1</b>
<b>Introduction</b> . . . . .	<b>6-2</b>
<b>DirectLOGIC PLCs Password Protection</b> . . . . .	<b>6-2</b>
<b>PLC Communication Cables &amp; Wiring Diagrams</b> . . . . .	<b>6-5</b>
<b>PLC Communication Cables &amp; Wiring Diagrams</b> . . . . .	<b>6-6</b>
AutomationDirect PLCs RS-232C Serial: . . . . .	6-7
AutomationDirect PLCs RS-422A/RS-485A: . . . . .	6-10
Direct LOGIC Universal Isolated Network Adapter, p/n FA-ISOCON: . . . . .	6-16
Direct LOGIC Universal Converter, p/n F2-UNICON: . . . . .	6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples . . . . .	6-18
Allen-Bradley: . . . . .	6-22
GE: . . . . .	6-27
GE VersaMax Micro: . . . . .	6-27
Mitsubishi: . . . . .	6-27
Omron: . . . . .	6-29
Modicon ModBus RS-232: . . . . .	6-30
Modicon Micro Series: . . . . .	6-30
Modicon ModBus with RJ45: . . . . .	6-30
Siemens: . . . . .	6-31
 <b>Chapter 7: Maintenance</b> . . . . .	 <b>7-1</b>
<b>Project Backup</b> . . . . .	<b>7-2</b>
<b>Check Operating Environment</b> . . . . .	<b>7-2</b>
<b>Check Operating Voltage</b> . . . . .	<b>7-2</b>
<b>Check Status Indicators</b> . . . . .	<b>7-2</b>
<b>Check Physical Conditions</b> . . . . .	<b>7-3</b>
<b>Run Tests under System Setup Screens</b> . . . . .	<b>7-3</b>
<b>Check Memory Usage via System Setup Screens</b> . . . . .	<b>7-4</b>
<b>Check/Adjust Display Brightness or Contrast</b> . . . . .	<b>7-4</b>
<b>Check Error Log via System Setup Screens</b> . . . . .	<b>7-4</b>
<b>Adjust Touch Panel via System Setup Screens</b> . . . . .	<b>7-4</b>
<b>Replace Battery Periodically</b> . . . . .	<b>7-5</b>

Cleaning the Display Screen .....	7-5
Check Project Functionality .....	7-6
Checks from <i>C-more</i> Programming Software .....	7-6
<b>Chapter 8: Troubleshooting .....</b>	<b>8-1</b>
Common Problems .....	8-2
Toubleshooting Flow Chart .....	8-3
Touch Panel does not Power up .....	8-4
Display is Blank .....	8-5
Display is Dim .....	8-6
No User Program .....	8-7
No Communications between Panel and PC (Personal Computer) via USB .....	8-8
USB Driver Troubleshooting .....	8-10
No Communications between Panel and PC (Personal Computer) via Ethernet .....	8-12
No Communications between Panel and PLC .....	8-16
IP Address in System Setup Screens displays 0.0.0.0 .....	8-19
Difficulty Connecting to the Panel over the Internet (Web server and Remote Access features) .....	8-20
PLC Protocol Error Codes .....	8-21
Touch Panel Runtime Errors .....	8-22
Panel Constantly Displays “Initializing” when Powering up .....	8-23
Data not Logging Problems .....	8-23
Loss of Date/Time and Retentive Data .....	8-24
Electrical Noise Problems .....	8-24
<b>Chapter 9: Replacement Parts .....</b>	<b>9-1</b>
Replacement Parts Overview .....	9-2
Replacement Parts at a Glance .....	9-2
Battery Replacement & Installation Instructions .....	9-3
6” Panel Mounting Clip Replacements & Installation .....	9-5

8-15" Panel Mounting Clip Replacements & Installation . . . . .	9-6
DC Panel Power Connector Replacement . . . . .	9-7
AC Power Adapter Connector Replacement . . . . .	9-7
8-15" Panel Backlight Bulb Replacements & Installation . . . . .	9-8
6-15" Panel Gasket Replacement & Installation. . . . .	9-11
8-15" Panel Bezel Replacement & Installation . . . . .	9-12
6" Adapter Plate Gasket Replacement & Installation . . . . .	9-14
<b>Appendix A: PLC Protocol Error Codes . . . . .</b>	<b>A-1</b>
Introduction. . . . .	A-2
C-more Touch Panel Error Code Table . . . . .	A-3
DirectLOGIC – Panel Error Code PLC-499 Explanation . . . . .	A-5
DirectLOGIC K-Sequence Protocol – PLC Error Code Table. . . . .	A-5
DirectLOGIC DirectNET Protocol – PLC Error Codes . . . . .	A-5
Modbus Protocols Error Code P499 Explanation . . . . .	A-6
AutomationDirect CLICK . . . . .	A-6
AutomationDirect DirectLOGIC - Modbus (Koyo). . . . .	A-6
Modicon Modbus RTU . . . . .	A-6
Entivity Modbus RTU . . . . .	A-6
DirectLOGIC ECOM Protocol – PLC Error Codes . . . . .	A-6
Productivity3000 Error Code P499 . . . . .	A-7
Allen-Bradley – Panel Error Code PLC-499 Explanation . . . . .	A-8
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables . . . . .	A-9
Allen-Bradley EtherNet/IP Protocol –Panel Error Code PLC-496, 497 and 498 Explanation . . . . .	A-11
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code TablesControlLogix, CompactLogix, & FlexLogix. . . . .	A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code TablesMicroLogix 1100, 1400 & SLC 5/05, both via native Ethernet port;MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5/03/04/05, all via ENI Adapter. . . . .	A-16
Generic EtherNet IP Protocol – PLC Error Codes . . . . .	A-21
GE 90-30 – Panel Error Code PLC-499 Explanation . . . . .	A-22

GE 90-30 SNPX Protocol – PLC Error Code Tables . . . . .	A-23
Mitsubishi FX Protocol – PLC Error Codes . . . . .	A-32
Omron – Panel Error Code PLC-499 Explanation . . . . .	A-32
Omron Host Link Protocol – PLC Error Code Table . . . . .	A-33
Omron FINS Protocol – PLC Error Code Table . . . . .	A-34
Omron – Panel Error Code P495 Explanation . . . . .	A-37
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table . . . . .	A-38
Siemens – Panel Error Code P499 Explanation. . . . .	A-39
Siemens PPI Protocol – PLC Error Code Table . . . . .	A-40
Siemens ISO over TCP Protocol – PLC Error Code Table . . . . .	A-41
<b>Appendix B: Touch Panel Runtime Errors . . . . .</b>	<b>B-1</b>
Introduction. . . . .	B-2
Runtime Errors. . . . .	B-3
<b>Appendix C: Mounting Clips Prior April 2006 . . . . .</b>	<b>C-1</b>
Introduction. . . . .	C-2
EA7-S6M-R, S6C-R, S6M, S6C & T6C. . . . .	C-3
EA7-T8C . . . . .	C-5
EA7-T10C . . . . .	C-7
EA7-T12C . . . . .	C-9
EA7-T15C . . . . .	C-11
<b>Index</b>	