

# USER MANUAL TABLE OF CONTENTS

---



## NITRA PAL USER MANUAL

NITRA Pneumatic Automation Link User Manual . . . . .	CF-1
Warnings and Trademarks . . . . .	W-1
~ WARNING ~ . . . . .	W-1
Trademarks. . . . .	W-1
~ ADVERTENCIA ~ . . . . .	W-2
Marcas Registradas . . . . .	W-2
~ AVERTISSEMENT ~ . . . . .	W-3
Marques de commerce . . . . .	W-3
NITRA Pneumatic Automation Link User Manual Revision History. . . . .	H-1
NITRA Pneumatic Automation Link (PAL) Table of Contents . . . . .	TOC-1
Chapter 1: Getting Started . . . . .	1-1
Manual Overview . . . . .	1-2
Overview of This Publication . . . . .	1-2
Who Should Read This Manual . . . . .	1-2
Supplemental Publications . . . . .	1-2
Technical Support . . . . .	1-2
Special Symbols . . . . .	1-2
PAL System Introduction . . . . .	1-3
Overview of the System . . . . .	1-3
General Specifications . . . . .	1-4
Components Overview. . . . .	1-5
Assembly. . . . .	1-10
Required Tools . . . . .	1-10
Assembling the Bank. . . . .	1-10
Assembling the I/O Modules . . . . .	1-12
Replacing the fittings . . . . .	1-14
Replacing the Valves . . . . .	1-15
Mounting the Bank to DIN Rail . . . . .	1-16
Electrical Connections. . . . .	1-17
Power Wiring . . . . .	1-17
PAL-EIP Connections. . . . .	1-19
Chapter 2: Conventional Electrical Modules . . . . .	2-1
Conventional Electrical Modules. . . . .	2-2
Cables . . . . .	2-2
Specifications. . . . .	2-3
Chapter 3: EtherNet/IP Modules . . . . .	3-1
Overview . . . . .	3-2

EtherNet/IP Modules . . . . .	3-2
Specifications . . . . .	3-2
System Setup For EtherNet/IP Assemblies . . . . .	3-3
Initial Hardware Configuration . . . . .	3-3
Configuring the PAL Network Settings . . . . .	3-3
NITRA Pneumatic Automation Link (PAL) Configuration Software . . . . .	3-6
EtherNet/IP Connections and Data Mapping . . . . .	3-7
<b>Chapter 4: I/O Modules . . . . .</b>	<b>4-1</b>
Overview . . . . .	4-2
PAL-S01 8-point Discrete Input . . . . .	4-2
Wiring Diagram. . . . .	4-2
Parameter Configuration. . . . .	4-3
Specifications . . . . .	4-3
PAL-S02 8-point Discrete Output . . . . .	4-4
Wiring Diagram. . . . .	4-4
Parameter Configuration. . . . .	4-4
PAL-S03 6-point Discrete Output + additional power connection . . . . .	4-5
Wiring Diagram. . . . .	4-5
Parameter Configuration. . . . .	4-5
Specifications . . . . .	4-6
PAL-S04 4-point Analog Input . . . . .	4-6
Wiring Diagram. . . . .	4-7
Parameter Configuration. . . . .	4-7
Analog Input Data Format. . . . .	4-8
PAL-S05 4-point Analog Output . . . . .	4-8
Wiring Diagram. . . . .	4-8
Parameter Configuration. . . . .	4-9
Specifications . . . . .	4-10
PAL-S06 16-point Discrete Input. . . . .	4-10
Wiring Diagram. . . . .	4-10
Parameter Configuration. . . . .	4-11
PAL-S07 16-point Discrete Output. . . . .	4-12
Wiring Diagram. . . . .	4-12
Parameter Configuration. . . . .	4-12
Specifications . . . . .	4-13
PAL-S08 4-point Analog Temperature Input . . . . .	4-14
Wiring Diagram. . . . .	4-14
Parameter Configuration. . . . .	4-15
Specifications . . . . .	4-17
Closed End Spacer Module. . . . .	4-18
Installation . . . . .	4-18
<b>Chapter 5: Pneumatic Modules . . . . .</b>	<b>5-1</b>
Overview . . . . .	5-2
Primary Air Inlet / Exhaust Module . . . . .	5-2
Intermediate Air modules. . . . .	5-3
Modular Valve Bases . . . . .	5-5

Solenoid Valves . . . . .	5-6
Valve Components and Materials of Construction . . . . .	5-6
3-way valves . . . . .	5-6
5-way valves . . . . .	5-7
Special Purpose valve . . . . .	5-8
Valve Flow Rates . . . . .	5-8
Solenoid Valves Software Configuration Settings . . . . .	5-8
PAL-Y38 Fitting . . . . .	5-9
End Plates . . . . .	5-10
PAL-C3 Wiring . . . . .	5-10
Local Expansion Cables . . . . .	5-10
Accessories and Replacement Parts . . . . .	5-12
Air Connection Modules Accessories and Replacement Parts . . . . .	5-12
Valve Base Accesories and Replacement Part . . . . .	5-12
End Plate Accessory . . . . .	5-12
Chapter 6: Stand-Alone Valve Bases . . . . .	6-1
Overview . . . . .	6-2
Port Connections . . . . .	6-3
Wiring . . . . .	6-4
Control Cables . . . . .	6-4
Stand-Alone vs. PAL Assembly Comparison . . . . .	6-5
Typical Stand-Alone Base Configuration . . . . .	6-5
Comparable PAL Assembly Configuration . . . . .	6-5
Mounting Options . . . . .	6-6
DIN Rail Mounting . . . . .	6-6
Bracket Mounting . . . . .	6-6
LED Status Lights and Diagnostics . . . . .	6-7
Chapter 7: Diagnostics / Troubleshooting . . . . .	7-1
LED Status . . . . .	7-2
Node Errors . . . . .	7-3
System Diagnostics . . . . .	7-4
Module LED Diagnostics . . . . .	7-7
Solenoid Valve LED . . . . .	7-7
Digital Input Module LEDs . . . . .	7-7
Digital Output Module LEDs . . . . .	7-7
Analog Input Module LEDs . . . . .	7-7
Analog Output Module LEDs . . . . .	7-8
Temperature Input Module LEDs . . . . .	7-8

BLANK  
PAGE