

# Table of Contents

---



## Introduction

Is this Manual Right for You? .....	1
Additional Manuals .....	1
How the OP-9001 Communicates .....	2
<b>Using the Communications Master...5 Easy Steps .....</b>	<b>3</b>
Step 1: Plan Your System of Panels (Pages 4–7) .....	3
Step 2: Install the Panels and the OP-9001 (Pages 8–16) .....	3
Step 3: Configure the System and the Individual Panels (Pages 17–22) .....	3
Step 4: Download the Configurations to Each Panel (Page 21) .....	3
Step 5: Download the System to the OP-9001 Master (Page 22) .....	3

## Planning Your Memory Mapping

<b>Memory Consumption for Mapping Process .....</b>	<b>5</b>
<b>Using a Memory Planner .....</b>	<b>6</b>

## Installing the Panel

<b>Panel Specifications: .....</b>	<b>8</b>
Physical Specifications .....	8
CPUs Supported .....	8
Environmental Specifications .....	8
Operating Specifications .....	8
<b>Dimensions .....</b>	<b>9</b>
<b>Power and Cabling Requirements .....</b>	<b>10</b>
Assessing Your Application Needs? .....	10
<b>Connecting a Power Supply to the OP-9001 .....</b>	<b>11</b>
Power Supply Connections .....	11
<b>Pinout Diagrams for Cabling .....</b>	<b>12</b>
<b>Choosing Your Connecting Cables .....</b>	<b>13</b>
<b>Custom Cables for Connecting Panels to the OP-9001 .....</b>	<b>14</b>
<b>Setting the Panel DIP Switches and OP-9001 Jumper .....</b>	<b>15</b>
Assigning Addresses to the Panels Connected to the OP-9001 .....	15
How to Set the Operator Panel Addresses .....	15
<b>Communication LED Indicators .....</b>	<b>16</b>

---

# Configuring Multiple Panels with the OPEditor

System Requirements .....	16
How to Install .....	16
<b>Step-by-Step Procedure .....</b>	<b>17</b>
Step 1: Load the OPEditor and Complete the Editor Setup .....	17
Step 2: Select the LPT and COM ports .....	17
Step 3: Select Multi-Panel Configuration .....	17
Step 4: Select the Source for your Configuration .....	18
Step 5: Enter the Correct PLC Brand and Type .....	18
Step 6A: Select Configure Protocol and the PLC Subtype .....	18
Step 6B: Set the Baud Rate, Parity and Stop Bits .....	19
Step 6C: Set the Timeout .....	19
Step 6D: Set the PLC Address for the Port Used .....	19
Step 7: Add the Panel to the System .....	19
Step 8: Select Panel to be Configured or Upload Existing Panel Configuration .....	20
Step 11: Repeat Steps 8-10 for each OP-panel .....	21
Step 12: Download the System Configuration to the OP-9001 .....	21
<b>Troubleshooting</b>	
Observing the LEDs on the OP-9001 .....	22
Requesting Data from PLC But No Response .....	22
OP-9001 Not Communicating Properly with the Panels .....	22
Trouble Communicating with Computer During Configuration .....	23

---