


TABLE OF CONTENTS



Chapter 1 - Getting Started	1-1
Productivity Suite System Requirements.....	1-3
Step 1: Install Programming Software.....	1-4
Step 2: Launch Programming Software.....	1-8
Step 3: Install Hardware.....	1-10
Step 4: Apply Power to CPU.....	1-13
Step 5: Establish PC to CPU Communications.....	1-14
Step 6: Open/Read Hardware Configuration.....	1-15
Step 7: Create a Project.....	1-17
Step 8: Save Project.....	1-23
Step 9: Write Project to CPU.....	1-24
Step 10: Place CPU in RUN Mode.....	1-25
Step 11: Test the Project Using Monitor Mode or Simulator.....	1-26
 Chapter 2 - Specifications	 2-1
Overview.....	2-3
P2-04B, P2-07B, P2-11B, P2-15B Bases.....	2-4
P2-01AC, P2-01DCAC, P2-01DC and P2-02DC Power Supplies.....	2-6
P2-550 CPU Module.....	2-12
P2-RS Remote Slave Module.....	2-23
I/O Modules Overview.....	2-32
Discrete I/O Modules.....	2-33
P2-08SIM Input Simulator Module.....	2-34

Table of Contents

P2-08ND3-1 Sinking/Sourcing DC Input	2-35
P2-16ND3-1 Sinking/Sourcing DC Input.....	2-38
P2-32ND3-1 24VDC Sinking/Sourcing Input.....	2-41
P2-08NE3 AC/DC Sinking/Sourcing Input.....	2-44
P2-16NE3 AC/DC Sinking/Sourcing Input.....	2-47
P2-32NE3 AC/DC Sinking/Sourcing Input.....	2-50
P2-08NAS Isolated AC Input.....	2-53
P2-16NA AC Input.....	2-56
P2-08TD1S Isolated Sinking DC Output.....	2-59
P2-08TD2S Isolated Sourcing DC Output	2-62
P2-15TD1 Sinking DC Output.....	2-65
P2-15TD2 Sourcing DC Output.....	2-68
P2-08TD1P Sinking Protected DC Output	2-71
P2-08TD2P Sourcing Protected DC Output.....	2-74
P2-16TD1P Sinking Protected DC Output.....	2-77
P2-16TD2P Sourcing Protected DC Output.....	2-80
P2-32TD1P Sinking Protected DC Output	2-83
P2-32TD2P Sourcing Protected DC Output.....	2-86
P2-08TAS Isolated AC Output	2-89
P2-16TA AC Output	2-92
P2-08TRS Isolated Relay Output.....	2-95
P2-16TR Relay Output.....	2-98
Chapter 3 - Analog I/O Specifications	3-1
Analog I/O Modules Overview.....	3-3
Analog I/O Modules.....	3-4
Analog I/O Modules.....	3-5
P2-04AD Analog Input.....	3-6
P2-04AD-1 Analog Input.....	3-12
P2-04AD-2 Analog Input.....	3-17

P2-08AD-1 Analog Input.....	3-22
P2-08AD-2 Voltage Analog Input.....	3-27
P2-08ADL-1 Current Analog Input	3-32
P2-08ADL-2 Voltage Analog Input.....	3-36
P2-16AD-1 Current Analog Input.....	3-40
P2-16AD-2 Voltage Analog Input	3-45
P2-16ADL-1 Current Analog Input.....	3-50
P2-16ADL-2 Voltage Analog Input	3-54
P2-06RTD Analog Input.....	3-58
P2-08THM Analog Input.....	3-65
P2-08NTC Thermistor	3-72
P2-04DA Analog Output.....	3-76
P2-04DA-1 Analog Output	3-82
P2-04DA-2 Analog Output.....	3-87
P2-04DAL-1 Analog Output	3-92
P2-04DAL-2 Analog Output.....	3-96
P2-08DA-1 Current Analog Output.....	3-100
P2-08DA-2 Voltage Analog Output	3-105
P2-08DAL-1 Current Analog Output.....	3-110
P2-08DAL-2 Voltage Analog Output	3-114
P2-16DA-1 Current Analog Output.....	3-118
P2-16DA-2 Voltage Analog Output.....	3-123
P2-16DAL-1 Current Analog Output.....	3-128
P2-16DAL-2 Voltage Analog Output.....	3-132
P2-8AD4DA-1 Current Analog Input/Output	3-136
P2-8AD4DA-2 Voltage Analog Input/Output.....	3-142
Chapter 4 - Specialty Module Specifications	4-1
Specialty Modules Overview.....	4-2
P2-HSI High-Speed Pulse Input Module	4-4

Table of Contents

P2-HSO High-Speed Output Module	4-13
High-Speed Module Tester Utility.....	4-22
P2-02HSC High-Speed Counter Module	4-23
P2-04PWM Module.....	4-29
P2-SCM Module.....	4-33
P2-SCM Module Communications.....	4-35
Chapter 5 - Installation and Wiring.....	5-1
Safety Guidelines	5-2
Introduction	5-5
Dimensions and Installation	5-6
Mounting Guidelines	5-7
Wiring Guidelines	5-14
I/O Module Wiring Options.....	5-16
System Wiring Strategies.....	5-22
Chapter 6 - Communications	i
Communications	6-1
Communications: Connectivity	6-8
Communications: Ethernet.....	6-16
Communications Modbus Functionality.....	6-20
EtherNet/IP for the Productivity Series	6-35
Communications: Remote I/O and GS-Drives.....	6-50
Communications: Port Configuration.....	6-58
Communications: Error Codes.....	6-66
Hardware Maintenance.....	7-2
Diagnostics	7-3
CPU Indicators.....	7-4
PWR Indicator.....	7-5
Run Indicator	7-7

CPU Indicator..... 7-7

Communications Problems 7-7

I/O Module Troubleshooting 7-8

Noise Troubleshooting 7-10

Run Time vs Stop Mode Transfer Instruction..... 7-11

Forcing I/O Points..... 7-14

Appendix A - European Union Directives (CE)..... A-1

 European Union (EU) Directives..... A-2

 Basic EMC Installation Guidelines A-4

Appendix B - Productivity® 2000 Error Codes..... B-1

Appendix C - Security Considerations for Control Systems Networks..... C-1

 Security Considerations for Control Systems Networks..... C-2