# Schmersal Configurable Safety Relays



#### **SRB-E Electronic Safety Relays**

The SRB-E modules are a series of multi-functional, configurable electronic safety relays. Each module can be adjusted to one of multiple preset configurations, which include selecting the type of reset, activating or deactivating cross-wire monitoring, and selecting the monitored contact configuration – all via the rotary dial on the front of the unit.

The SRB-E series provides a higher level of diagnostic capabilities with LEDs for both controller status as well as error fault codes, assisting with troubleshooting safety circuits.

Once the configurations have been set, the lid may be closed and sealed to prevent tampering with the settings.

### SCHMERSAL

#### Features

- Modules with safe PNP outputs
- Modules with safe relay outputs
- Modules with monitoring of two-hand controls
- Modules with monitored input expansion up to Cat 4 PLe
- Fast cycle times (60 switching cycles/ min)
- Modules with high 5.5A PNP switching capacity
- Snap-in blank equipment labels
- Removable terminal blocks for easy wiring

	S	chmers	al S	RB-	E Elo	ectr	onic	Saf	ety	Rela	ays	Sele	ctio	n Cł	nart						
			Emergency stop monitoring	Safety guard monitoring	Pull wire emergency stop	Magnetic safety sensors	Light curtains	Input expander module for up to 4 sensors	Two hand control panels	Input signals: 1 channel	Input signals: 2 channel	Input signals: antivalent	Cross-wire detection	Start button/ autostart	Start button with edge detection	Safe Stop 0 dry contact	Safe Stop 0 semiconductor	Safe Stop 1 dry contact	Safe Stop 1 semiconductor	Not safe dry contact	Not safe semiconductor
Part Number	Price	Drawing			Арј	olicatio	ons					LLOW/ Signals		Sta Cond	art itions		0	utput C	Contac	ts	
SRB-E-201LC	\$171.00	PDF	✓	✓	✓	✓	✓			✓	✓	✓	✓		✓		2				1
SRB-E-201ST	\$257.00	PDF	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		✓		2				1
SRB-E-201ST-CC	\$269.00	PDF	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		✓		2				1
SRB-E-301ST	\$216.00	PDF	✓	$\checkmark$	✓	✓	✓			✓	✓	✓	✓	✓	✓	3				1	
SRB-E-301ST-CC	\$228.00	<u>PDF</u>	✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	3				1	
<u>SRB-E-402EM</u>	\$191.00	<u>PDF</u>	✓	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	4				2	
<u>SRB-E-232ST</u>	\$366.00	<u>PDF</u>	✓	$\checkmark$	✓	✓	✓			✓	✓	✓	✓		✓		2	3		1	1
SRB-E-232ST-CC	\$378.00	<u>PDF</u>	✓	$\checkmark$	✓	✓	✓			✓	✓	✓	✓		✓		2	3		1	1
<u>SRB-E-322ST</u>	\$366.00	<u>PDF</u>	✓	$\checkmark$	✓	✓	✓			✓	✓	✓	✓		✓	3			2	1	1
<u>SRB-E-322ST-CC</u>	\$378.00	<u>PDF</u>	✓	✓	✓	✓	✓			✓	✓	✓	✓		✓	3			2	1	1
<u>SRB-E-204ST</u>	\$272.00	<u>PDF</u>	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓		✓		2				4
SRB-E-204ST-CC	\$284.00	<u>PDF</u>	✓	✓	✓	✓	✓	✓		~	✓	✓	✓		$\checkmark$		2				4
<u>SRB-E-204PE</u>	\$147.00	PDF	✓	$\checkmark$	✓	✓	✓	✓		✓	$\checkmark$	✓	$\checkmark$	$\checkmark$			2				4
			C	ombi	natior	n Mod	lule f	or Tw	o Pro	tectiv	re Dei	vices									
<u>SRB-E-402ST</u>	\$338.00	<u>PDF</u>	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		✓	2	2			1	1
SRB-E-402ST-CC	\$350.00	PDF	✓	✓	✓	$\checkmark$	✓		$\checkmark$	✓	✓	$\checkmark$	✓		$\checkmark$	2	2			1	1

#### Notes:

Stop Category 0 (Stop 0) means immediate loss of power. This is often referred to as an uncontrolled stop.

Stop Category 1 (Stop 1) means there is a delay before the loss of power. The control system should bring the machine to a stop prior to the loss of power. This is often referred to as a controlled stop with removal of power.

## Schmersal SRB-E-204 Configurable Safety Relays





#### Features

- Pluggable screw terminals or cage clamps
- 2 safety outputs
- 4 signal outputs
- Cascadable to add additional inputs to a safety system

Safety Data Values per EN ISO 13849-1, EN 62061, IEC 61508							
Performance Level	Up to e						
DC Average	High						
SIL CL	Up to 3						
HFT (Hardware Failure Tolerance)	1						
PFH(D)	≤ 2.66x10 <sup>-9</sup> /h						

Schmersal SRB-E-204 Selection Chart											
Part Number	Price	Туре	Voltage	Connection	Configurations	Safety Input	Safety Output	Monitoring Outputs	Drawing		
SRB-E-204ST	\$272.00	Safety relay Safety input extension	24 VDC	Pluggable screw terminals	14	4 pair digital	2 OSSD	4 status	PDF		
SRB-E-204ST-CC	\$284.00		24 VDC	Push-in cage clamp	14				PDF		
<u>SRB-E-204PE</u>	\$147.00		24 VDC	Pluggable screw terminals	15				PDF		


Schmersal SRB-E-204 Specifications						
Input/Output Specifications						
Operating Temperature	-25°C [-13°F] to 60°C [140°F]					
Storage Temperature	-40°C [-40°F] to 85°C [185°F]					
Altitude	2000m [6562ft] max					
Vibration Resistance	Tested to EN 60068-2-6					
Degree of Protection	IP40					
Housing	Glass-fiber reinforced thermoplastic, ventilated					
Weight	150g [5.29 oz]					
Agency Approvals and Standards	CE, UL (listed number E57648)					
Terminal Designation per EN 50005	EN 60947-1					
Wire Fixing	Plug-in terminals					
Cable Section Min/Max	0.25 mm <sup>2</sup> [24 AWG] - 2.5 mm <sup>2</sup> [14 AWG]					
Switching Frequency, Max	1 Hz					
	Input/Output Specifications					
Operating Voltage Range	19.2 to 28.8 VDC					
Maximum Consumption	3W (plus load of semiconductor outputs)					
Overvoltage Protection	Category III					
Control Voltage on S11 etc.	24VDC					
Control Current Over S12 etc.	8mA					
Mechanical Life	10 <sup>7</sup> operations					
Contact Type	Ag-Ni, self-cleaning, positive drive					
Operating Delay (Pull-In Delay)	<150ms					
Release Delay (Drop-Out Delay)	<10ms					
Switching Capacity	Safety outputs Q: 24VDC, max 2A Y1 through Y4: 24VDC / 100mA					



### Schmersal SRB-E-204 Configurable Safety Relays

Terr	Terminal Descriptions						
Pin	Function						
A1	Operating voltage +24VDC						
A2	Operating voltage 0VDC						
X2	Input of start circuit / cascading						
<b>X</b> 3	Input feedback circult / cascading						
S11/S21 S31/S41 S51/S61	Test pulse outputs						
S12 S22	Input channel 1 Input channel 2						
S32 S42	Input channel 1 Input channel 2						
S52 S62	Input channel 1 Input channel 2						
S72 S82	Input channel 1 Input channel 2						
¥1	Signalling output, sensor 1						
Y2	Signalling output, sensor 2						
Y3	Signalling output, sensor 3						
Y4	Signalling output, sensor 4						
Q1/Q2	Safety outputs						

LED Indication Descriptions					
LED	Function				
RUN	Operating voltage OK – RUN mode				
ERR	Error code				
In 1/2	High level at S12 / S22				
In 3/4	High level at S32 / S42				
In 5/6	High level at S52 / S62				
In 7/8	High level at S72 / S82				
Out	Outputs activated				
NOTE: For flash codes, refer to product manual					






SRB-E-204PE

### SCHMERSAL

### Schmersal SRB-E-204ST Configurable Safety Relays

#### Application Example for <u>SRB-E-204ST</u>



#### Key

- a) Safety inputs
- b) Safety outputs
- c) Signalling outputs
- d) Clock outputs
- e) Processing
- f) Power
- g) Safety modules

Safe signal processing, e.g. by PROTECT SRB-E-series with start and reset functions as well as feedback circuit monitoring

		Conf	iguration Sele	ction				
Rotary Knob Position	Reset Button	Cross-Wire Monitoring Active	Input Number	Input / Sensor Configuration	Monitoring of Sensor Channels For Synchronization	Function Signalling Outputs Y1 - Y4		
С			Configur	ation Mode				
1	Trailing Edge	Yes	1-4	NC / NC	Yes			
2	Trailing Edge	Yes	1-4	NC / NC	No			
3	Trailing Edge	No	1-4	NC / NC	Yes			
4	Trailing Edge	No	1-4	NC / NC	No			
5	Trailing Edge	Yes	1-4	NC / NO	Yes			
6	Autostart	Yes	1-4	NC / NO	No			
7	Autostart	Yes	1-4	NC / NC	Yes			
8	Autostart	Yes	1-4	NC / NC	No			
9	Autostart	No	1-4	NC / NC	Yes			
10	Autostart	No	1-4	NC / NC	No			
	Trailing Edge	Yes	1					
		Yes	2	NC / NC		NO Sensor = 0 Output = 0 Sensor = 1 Output = 1		
11		No	3		No			
		No	4					
	Autostart	Yes	1		No			
40		Yes	2					
12		No	3	NC / NC				
		No	4					
		Yes	1		No			
40		Yes	2					
13	Trailing Edge	Yes	3	NC / NC				
		No	4					
		Yes	1					
	Autostart	Yes	2					
14		Yes	3	NC / NC	No			
		No	4					

### **Safety Products**



Warning: Safety products sold by AutomationDirect are Safety components only. The purchaser/installer is solely responsible for the application of these components and ensuring all necessary steps have been taken to assure each application and use meets all performance and applicable safety requirements and/or local, national and/or international safety codes as required by the application. AutomationDirect cannot certify that our products, used solely or in conjunction with other AutomationDirect or other vendors' products, will assure safety for any application. Any person using or applying any products sold by AutomationDirect is responsible for learning the safety requirements for their individual application and applying them, and therefore assumes all risks, and accepts full and complete responsibility, for the selection and suitability of the product for their respective application.

AutomationDirect does not provide design or consulting services, and cannot advise whether any specific application or use of our products would ensure compliance with the safety requirements for any application.