


## XBF-HD02A Counter Input Module

| Part Number      | Price    | Classification | Description   | # of Channels | Drawing |
|------------------|----------|----------------|---|---------------|---------|
| <b>XBF-HD02A</b> | \$253.00 | Counter Input  | LS Electric XGB counter input module, 500 kHz maximum switching frequency, 2 high-speed input point(s), 5-24 VDC, sinking, 2-channel, differential encoder input(s), 2 high-speed output point(s), 5-24 VDC, sinking, external 24 VDC required. | 2             | PDF     |

| General Specifications    |               | XBF-HD02A   |
|---------------------------|---------------|---|
| Count Input Signal        | Signal        | A-phase, B-phase  |
|                           | Input Type    | Differential input (Line Drive)   |
|                           | Signal Level  | RS-422A Line Drive/HTL LEVEL Line Drive   |
| Maximum Coefficient Speed |               | 500kpps (HTL input: 250kpps)  |
| Number of Channels        |               | 2   |
| Coefficient Range         |               | Signed 32-bit (-2,147,483,648 to +2,147,483,647)  |
| Count Mode                |               | Linear Count (when 32-bit range exceeded, carry/borrow occurs, the count value stopped)<br>Ring Count (repeated count within setting range)   |
| Input Pulse Mode          |               | 1-phase input<br>2-phase input<br>CW/CCW  |
| Up/Down Setting           | 1-phase Input | Increasing/decreasing operation setting by B-phase input<br>Increasing/decreasing operation setting by program  |
|                           | 2-phase Input | Automatic setting by difference in phase  |
|                           | CW/CCW        | A-phase input: increasing operation<br>B-phase input: decreasing operation  |
| Multiplication Function   | 1-phase Input | 1/2 multiplication  |
|                           | 2-phase Input | 1/2/4 multiplication  |
|                           | CW/CCW        | 1-multiplication  |
| Control Input             | Signal        | Preset instruction input, auxiliary mode instruction input  |
|                           | Signal Level  | 5/12/24 VDC (by terminal selection) input type  |
|                           | Signal Type   | Voltage   |
| External Output           | Output Points | 2-point/channel (for each channel): terminal output available   |
|                           | Type          | Select single-compared (>, ≥, =, ≤, <) or section compared output (included or excluded)  |
|                           | Output Type   | Open collector output (sink)  |
| Operation Status Display  | Input Signal  | A-phase input, B-phase input, preset instruction input, auxiliary mode instruction input  |
|                           | Output Signal | External output 0, external output 1  |
|                           | Ready Status  | Module Ready  |
| Count Enable              |               | Set through program (count available only in enable status)   |
| Preset Function           |               | Set through terminal or program   |
| Auxiliary Mode Function   |               | Count clear, count latch, section count (time setting value: 0-60,000 ms), measurement of input frequency (for respective input phase), measurement of counts per hour (time setting value: 0-60,000 ms), count prohibited function |
| Terminal                  |               | 40-pin connector  |
| I/O Points Occupied       |               | Fixed point: 512  |
| Internal Consumed Current |               | 260mA   |
| Weight                    |               | 90g   |



## XBF-HD02A Counter Input Module Wiring

| XBF-HD02A Circuit Configuration |                         |                  |            |     |                                    |  |  |
|---------------------------------|-------------------------|------------------|------------|-----|------------------------------------|--|--|
| Circuit Configuration           | Internal Circuit Number | XTB-40H Terminal | Pin Number |     | Signal Name                        | Driver Type  |  |
|                                 |                         |                  | CH0        | CH1 |                                    |  |  |
|                                 | 1                       | AI+              | B20        | A20 | A I phase differentiation input +  | RS-422A line driver  |  |
|                                 | 2                       | AI+              | B19        | A19 | A II phase differentiation input + | HTL level line driver  |  |
|                                 | 3                       | AI-              | B18        | A18 | A I phase differentiation input -  | RS-422A line driver  |  |
|                                 | 4                       | AI-              | B17        | A17 | A II phase differentiation input - | HTL level line driver  |  |
|                                 | 1                       | BI+              | B16        | A16 | B I phase differentiation input +  | RS-422A line driver  |  |
|                                 | 2                       | BI+              | B15        | A15 | B II phase differentiation input + | HTL level line driver  |  |
|                                 | 3                       | BI-              | B14        | A14 | B I phase differentiation input -  | RS-422A line driver  |  |
|                                 | 4                       | BI-              | B13        | A13 | B II phase differentiation input - | HTL level line driver  |  |
|                                 | 5                       | P24V             | B12        | A12 | Preset input 24V                   | User terminal per appropriate external power source voltage (5, 12, or 24 VDC) |  |
|                                 | 6                       | P12V             | B11        | A11 | Preset input 12V                   |  |  |
|                                 | 7                       | P5V              | B10        | A10 | Preset input 5V                    |  |  |
|                                 | 8                       | PCOM             | B09        | A09 | Preset input COM                   |  | n/a  |
|                                 |                         | 5                | G24V       | B08 | A08                                | Auxiliary function input 24V   | User terminal per appropriate external power source voltage (5, 12, or 24 VDC) |
|                                 |                         | 6                | G12V       | B07 | A07                                | Auxiliary function input 12V   |  |
|                                 |                         | 7                | G5V        | B06 | A06                                | Auxiliary function input 5V  |  |
|                                 |                         | 8                | GCOM       | B05 | A05                                | Auxiliary function input COM   |  |
|                                 | 9                       | OUT0             | B04        | A04 | Comp. output 0                     | n/a  |  |
|                                 | 10                      | OUT1             | B03        | A03 | Comp. output 1                     |  |  |
|                                 | 11                      | 24V              | B02        | A02 | External power input 24V           |  |  |
|                                 | 12                      | 24G              | B01        | A01 | External power input GND           |  |  |


Note: AI+, AI-, BI+, BI- are 5V line driver input terminal. AI+, AI-, BI+, BI- are 24V line driver input terminal.

## XBF-HD02A Counter Input Module Wiring


When connecting cable to your XBF-HD02A:

- Take precautions to shield high-speed input wiring from external noise sources.
- Use grounded twisted pair shielded cable (Class3)
- Keep input wiring clear of power or I/O wiring to prevent noise.
- For single-phase applications, connection only to the A-phase input points.
- Ensure wiring length does not exceed the maximum distance specified from the pulse generator.
- Download module specific XTB-40H Terminal Label Printouts here: [Download Printouts](#)

### Terminal Wiring



### Module Connection





# XGB Motion Modules

## XBF-HD02A Counter Input Module Configuration

Learn how to Register and Configure this counter input module by viewing the LS PLC Interactive Guide:

[High Speed Counter Setup - HO02A, HD02A Based](#)

### Direct Variables

XGB series high speed counter modules are assigned 32 words in the "U" memory area based on the slot number assignment. (%UW0.z.0 - %UW0.z.31, z = slot number). The actual memory address used within the 32 word block are specific to each module. See the table below for Direct Variable assignments.

For Direct Variable nomenclature explanation, see [Direct Variable User Programming Memory](#).

### Symbolic Variables

Symbolic variables for the analog module can be automatically created in XG5000 software by using the top MENU bar: Edit > Register Module Variable Comments.

Symbolic variables and direct variables for XBF-HD02A are as follows (z refers to module slot number (2 to 8)).

| Type | Scope          | Variable<br>(Symbolic) | Address<br>(Direct Variable Alias) | Data Type | Comment   |
|------|----------------|------------------------|------------------------------------|-----------|---|
| Tag  | GlobalVariable | _000z_CH0_CNT          | %UD0.z.1                           | DINT      | HSC Module: CH0 Count Data                          |
| Tag  | GlobalVariable | _000z_CH0_LTH          | %UD0.z.2                           | DINT      | HSC Module: CH0 Latch Count Data                    |
| Tag  | GlobalVariable | _000z_CH0_RNG          | %UD0.z.3                           | DINT      | HSC Module: CH0 Sampling Count Data                 |
| Tag  | GlobalVariable | _000z_CH0_FRQ          | %UD0.z.4                           | UDINT     | HSC Module: CH0 Input Frequency Data                |
| Tag  | GlobalVariable | _000z_CH0_RPU          | %UD0.z.5                           | UDINT     | HSC Module: CH0 Rev./Unit Time Data                 |
| Tag  | GlobalVariable | _000z_CH0_AUXEN        | %UX0.z.371                         | BOOL      | HSC Module: CH0 Auxiliary Function Request          |
| Tag  | GlobalVariable | _000z_CH0_AUXING       | %UX0.z.5                           | BOOL      | HSC Module: CH0 Auxiliary Function Status           |
| Tag  | GlobalVariable | _000z_CH0_BRW          | %UX0.z.4                           | BOOL      | HSC Module: CH0 Borrow Flag                         |
| Tag  | GlobalVariable | _000z_CH0_CMPEN        | %UX0.z.372                         | BOOL      | HSC Module: CH0 Enable Compare Function             |
| Tag  | GlobalVariable | _000z_CH0_CMPOUT0      | %UX0.z.6                           | BOOL      | HSC Module: CH0 Compare 0 Output Status             |
| Tag  | GlobalVariable | _000z_CH0_CMPOUT1      | %UX0.z.7                           | BOOL      | HSC Module: CH0 Compare 1 Output Status             |
| Tag  | GlobalVariable | _000z_CH0_CNTEN        | %UX0.z.368                         | BOOL      | HSC Module: CH0 Enable Counter                      |
| Tag  | GlobalVariable | _000z_CH0_CRY          | %UX0.z.3                           | BOOL      | HSC Module: CH0 Carry Flag                          |
| Tag  | GlobalVariable | _000z_CH0_CRYBRW_RST   | %UX0.z.378                         | BOOL      | HSC Module: CH0 Carry/Borrow Reset Request          |
| Tag  | GlobalVariable | _000z_CH0_DN           | %UX0.z.0                           | BOOL      | HSC Module: CH0 Count Direction Status              |
| Tag  | GlobalVariable | _000z_CH0_DWNCNT       | %UX0.z.370                         | BOOL      | HSC Module: CH0 Count Direction Select              |
| Tag  | GlobalVariable | _000z_CH0_EQ0RST       | %UX0.z.374                         | BOOL      | HSC Module: CH0 Compare 0 EQUAL Reset(Edge) Command |
| Tag  | GlobalVariable | _000z_CH0_EQ1RST       | %UX0.z.375                         | BOOL      | HSC Module: CH0 Compare 1 EQUAL Reset(Edge) Command |
| Tag  | GlobalVariable | _000z_CH0_ERR          | %UX0.z.14                          | BOOL      | HSC Module: CH0 Error Flag                          |
| Tag  | GlobalVariable | _000z_CH0_EXTAUX_EN    | %UX0.z.380                         | BOOL      | HSC Module: CH0 Enable Aux-Func Ext. Input          |
| Tag  | GlobalVariable | _000z_CH0_EXTPRE       | %UX0.z.1                           | BOOL      | HSC Module: CH0 Preset Ext. Input Flag              |
| Tag  | GlobalVariable | _000z_CH0_EXTPST_EN    | %UX0.z.379                         | BOOL      | HSC Module: CH0 Preset Ext. Input Enable            |
| Tag  | GlobalVariable | _000z_CH0_EXTPST_RST   | %UX0.z.381                         | BOOL      | HSC Module: CH0 Preset Ext. Input Reset Request     |
| Tag  | GlobalVariable | _000z_CH0_OUTEN        | %UX0.z.373                         | BOOL      | HSC Module: CH0 Enable Compare Output Signal        |
| Tag  | GlobalVariable | _000z_CH0_PREEN        | %UX0.z.369                         | BOOL      | HSC Module: CH0 Enable Preset                       |



# XGB Motion Modules

## XBF-HD02A Counter Input Module Configuration, *continued*

| Type | Scope         | Variable<br>(Symbolic) | Address<br>(Direct Variable Alias) | Data Type | Comment   |
|------|---------------|------------------------|------------------------------------|-----------|---|
| Tag  | GobalVariable | ._000z_CH1_CNT         | %UD0.z.6                           | DINT      | HSC Module: CH1 Count Data                          |
| Tag  | GobalVariable | ._000z_CH1_LTH         | %UD0.z.7                           | DINT      | HSC Module: CH1 Latch Count Data                    |
| Tag  | GobalVariable | ._000z_CH1_RNG         | %UD0.z.8                           | DINT      | HSC Module: CH1 Sampling Count Data                 |
| Tag  | GobalVariable | ._000z_CH1_FRQ         | %UD0.z.9                           | UDINT     | HSC Module: CH1 Input Frequency Data                |
| Tag  | GobalVariable | ._000z_CH1_RPU         | %UD0.z.10                          | UDINT     | HSC Module: CH1 Rev./Unit Time Data                 |
| Tag  | GobalVariable | ._000z_CH1_DN          | %UX0.z.16                          | BOOL      | HSC Module: CH1 Count Direction Status              |
| Tag  | GobalVariable | ._000z_CH1_EXTPRE      | %UX0.z.17                          | BOOL      | HSC Module: CH1 Preset Ext. Input Flag              |
| Tag  | GobalVariable | ._000z_CH1_CRY         | %UX0.z.19                          | BOOL      | HSC Module: CH1 Carry Flag                          |
| Tag  | GobalVariable | ._000z_CH1_BRW         | %UX0.z.20                          | BOOL      | HSC Module: CH1 Borrow Flag                         |
| Tag  | GobalVariable | ._000z_CH1_AUXING      | %UX0.z.21                          | BOOL      | HSC Module: CH1 Auxiliary Function Status           |
| Tag  | GobalVariable | ._000z_CH1_CMPOUT0     | %UX0.z.22                          | BOOL      | HSC Module: CH1 Compare 0 Output Status             |
| Tag  | GobalVariable | ._000z_CH1_CMPOUT1     | %UX0.z.23                          | BOOL      | HSC Module: CH1 Compare 1 Output Status             |
| Tag  | GobalVariable | ._000z_CH1_ERR         | %UX0.z.30                          | BOOL      | HSC Module: CH1 Error Flag                          |
| Tag  | GobalVariable | ._000z_CH1_CNTEN       | %UX0.z.384                         | BOOL      | HSC Module: CH1 Enable Counter                      |
| Tag  | GobalVariable | ._000z_CH1_PREEN       | %UX0.z.385                         | BOOL      | HSC Module: CH1 Enable Preset                       |
| Tag  | GobalVariable | ._000z_CH1_DWNCNT      | %UX0.z.386                         | BOOL      | HSC Module: CH1 Count Direction Select              |
| Tag  | GobalVariable | ._000z_CH1_AUXEN       | %UX0.z.387                         | BOOL      | HSC Module: CH1 Auxiliary Function Request          |
| Tag  | GobalVariable | ._000z_CH1_CMPEN       | %UX0.z.388                         | BOOL      | HSC Module: CH1 Enable Compare Function             |
| Tag  | GobalVariable | ._000z_CH1_OUTEN       | %UX0.z.389                         | BOOL      | HSC Module: CH1 Enable Compare Output Signal        |
| Tag  | GobalVariable | ._000z_CH1_EQ0RST      | %UX0.z.390                         | BOOL      | HSC Module: CH1 Compare 0 EQUAL Reset(Edge) Command |
| Tag  | GobalVariable | ._000z_CH1_EQ1RST      | %UX0.z.391                         | BOOL      | HSC Module: CH1 Compare 1 EQUAL Reset(Edge) Command |
| Tag  | GobalVariable | ._000z_CH1_CRYBRW_RST  | %UX0.z.394                         | BOOL      | HSC Module: CH1 Carry/Borrow Reset Request          |
| Tag  | GobalVariable | ._000z_CH1_EXTPST_EN   | %UX0.z.395                         | BOOL      | HSC Module: CH1 Preset Ext. Input Enable            |
| Tag  | GobalVariable | ._000z_CH1_EXTAUX_EN   | %UX0.z.396                         | BOOL      | HSC Module: CH1 Enable Aux-Func Ext. Input          |
| Tag  | GobalVariable | ._000z_CH1_EXTPST_RST  | %UX0.z.397                         | BOOL      | HSC Module: CH1 Preset Ext. Input Reset Request     |
| Tag  | GobalVariable | ._000z_RDY             | %UX0.z.15                          | BOOL      | HSC Module: Ready Flag                              |



# XGB Series PLC Family

## Environmental Specifications, all XGB Series Modules

| Item  |                                      | Specification                                | Reference  |                              |
|---|--------------------------------------|--|--|------------------------------|
| Ambient Operating Temperature                       |                                      | 0–55°C (32–131°F)                            | -  |                              |
| Storage Temperature                                 |                                      | -25–70°C (-13–158°F)                         |  |                              |
| Ambient Operating Humidity                          |                                      | 5–95% relative humidity (non-condensing)     |  |                              |
| Storage Humidity                                    |                                      | 5–95% relative humidity (non-condensing)     |  |                              |
| Vibration <sup>1</sup>                              | Occasional Vibration                 | 5 ≤ f < 8.4 Hz                               | IEC61131-3-2                                     |                              |
|   |                                      | 8.4 ≤ f < 150Hz                              |  |                              |
|   | Continuous Vibration                 | 5 ≤ f < 8.4 Hz                               |  |                              |
|   |                                      | 8.4 ≤ f < 150Hz                              |  |                              |
| Shocks  |                                      | Peak Acceleration                            |  | 147 m/s <sup>2</sup> (15G)   |
|   |                                      | Duration                                     |  | 11ms                         |
|   |                                      | Pulse Wave Type                              | Half-sine (3 times each direction per each axis) |                              |
| Noise Resistance                                    | Square Wave Impulse Noise            |  | 1,500VAC<br>900VDC                               | LS Electric standard         |
|   | Electrostatic Discharge              |  | Voltage: 4kV (contact discharge)                 | IEC61131-3-2<br>IEC61000-4-2 |
|   | Radiated Electromagnetic Field Noise |  | 80–1,000 MHz, 10 V/m                             | IEC61131-3-2<br>IEC61000-4-3 |
|   | Fast Transient / Burst Noise         | Classification                               | Voltage  | IEC61131-3-2<br>IEC61000-4-4 |
|   |                                      | Power Supply                                 | 2kV  |                              |
| Digital/Analog Input/Output Communication Interface |                                      | 1kV  |  |                              |
| Environment   |                                      | Free from corrosive gases and excessive dust | -  |                              |
| Attitude  |                                      | Less than 2,000m                             |  |                              |
| Pollution Degree                                    |                                      | Less than 2 (see note 2)                     |  |                              |
| Cooling Method                                      |                                      | Air-cooling                                  |  |                              |

1 - Vibration of 10 times each direction (X, Y, and Z)

2 - Normally only nonconductive pollution occurs. Temporary conductivity caused by condensation is to be expected.



# XGB Series PLC Family

## Available I/O Modules

| XGB Series I/O Modules           |          |   |               |                |              |               |        |                        |                     |
|----------------------------------|----------|---|---------------|----------------|--------------|---------------|--------|------------------------|---------------------|
| Part Number                      | Price    | Description   | Digital Input | Digital Output | Analog Input | Analog Output | Motion | Bus Coupler Compatible | Smart Link Required |
| <b>Digital</b>                   |          |   |               |                |              |               |        |                        |                     |
| <a href="#"><u>XBE-DC08A</u></a> | \$59.00  | LS Electric XGB discrete input module, 8-point, 24 VDC, sinking/sourcing, 1 common(s), 8 point(s) per common. Removable terminal block included.  | ✓             |                |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-DC16A</u></a> | \$70.00  | LS Electric XGB discrete input module, 16-point, 24 VDC, sinking/sourcing, 1 common(s), 16 point(s) per common. Removable terminal blocks included.   | ✓             |                |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-DC16B</u></a> | \$78.00  | LS Electric XGB discrete input module, 16-point, 12-24 VDC, sinking/sourcing, 1 common(s), 16 point(s) per common. Removable terminal blocks included.  | ✓             |                |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-DC32A</u></a> | \$97.00  | LS Electric XGB discrete input module, 32-point, 24 VDC, sinking/sourcing, 1 common(s), 32 point(s) per common. Requires XTB-40H terminal block and C40HH-xxSB-XBI cable.   | ✓             |                |              |               |        | ✓                      | ✓                   |
| <a href="#"><u>XBE-AC08A</u></a> | \$88.00  | LS Electric XGB discrete input module, 8-point, 120 VAC, 2 common(s), 4 point(s) per common. Removable terminal blocks included.  | ✓             |                |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-RY08A</u></a> | \$80.00  | LS Electric XGB relay output module, 8-point, 125 VDC/250 VAC, (8) Form A, 1 common(s), 8 point(s) per common, 2A/point, 5A/common. Removable terminal block included.  |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-RY08B</u></a> | \$95.00  | LS Electric XGB relay output module, 8-point, 125 VDC/250 VAC, (8) Form A, 8 isolated common(s), 1 point(s) per common, 2A/point. Removable terminal blocks included.   |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-RY16A</u></a> | \$110.00 | LS Electric XGB relay output module, 16-point, 125 VDC/250 VAC, (16) Form A, 2 isolated common(s), 8 point(s) per common, 2A/point, 5A/common. Removable terminal blocks included.  |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-TN08A</u></a> | \$60.00  | LS Electric XGB discrete output module, 8-point, 12-24 VDC, sinking, 1 common(s), 8 point(s) per common, 0.5A/point, 2A/common. Removable terminal blocks included.   |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-TN16A</u></a> | \$78.00  | LS Electric XGB discrete output module, 16-point, 12-24 VDC, sinking, 1 common(s), 16 point(s) per common, 0.5A/point, 2A/common. Removable terminal blocks included.   |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-TN32A</u></a> | \$109.00 | LS Electric XGB discrete output module, 32-point, 12-24 VDC, sinking, 1 common(s), 32 point(s) per common, 0.2A/point, 2A/common. Requires XTB-40H terminal block and C40HH-xxSB-XBI cable.   |               | ✓              |              |               |        | ✓                      | ✓                   |
| <a href="#"><u>XBE-TP08A</u></a> | \$62.00  | LS Electric XGB discrete output module, 8-point, 12-24 VDC, sourcing, 1 common(s), 8 point(s) per common, 0.5A/point, 2A/common. Removable terminal blocks included.  |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-TP16A</u></a> | \$88.00  | LS Electric XGB discrete output module, 16-point, 12-24 VDC, sourcing, 1 common(s), 16 point(s) per common, 0.5A/point, 2A/common. Removable terminal blocks included.  |               | ✓              |              |               |        | ✓                      |                     |
| <a href="#"><u>XBE-TP32A</u></a> | \$93.00  | LS Electric XGB discrete output module, 32-point, 12-24 VDC, sourcing, 1 common(s), 32 point(s) per common, 0.2A/point, 2A/common. Requires XTB-40H terminal block and C40HH-xxSB-XBI cable.  |               | ✓              |              |               |        | ✓                      | ✓                   |
| <a href="#"><u>XBE-DN32A</u></a> | \$172.00 | LS Electric XGB discrete combo module, Input: 16-point, 24 VDC, sinking/sourcing, Output: 16-point, 12-24 VDC, sinking, 0.2A/point, 2A/common. Requires XTB-40H terminal block and C40HH-xxSB-XBI cable.  | ✓             | ✓              |              |               |        | ✓                      | ✓                   |
| <a href="#"><u>XBE-DR16A</u></a> | \$97.00  | LS Electric XGB discrete combo module, Input: 8-point, 24 VDC, sinking/sourcing, Output: 8-point, 125 VDC/250 VAC, relay, (8) Form A (SPST) relays, 2A/point, 5A/ common. Removable terminal blocks included.   | ✓             | ✓              |              |               |        | ✓                      |                     |
| <b>Motion</b>                    |          |   |               |                |              |               |        |                        |                     |
| <a href="#"><u>XBF-PN04B</u></a> | \$350.00 | LS Electric XGB 4-axis positioning module, EtherCAT Master, 1 high-speed input point(s), sinking/line driver (differential), 1-channel, differential and single-ended encoder input(s), (1) Ethernet 100Base-TX (RJ45) port(s). For use with LS Electric XEM-DxxxHx PLCs. |               |                |              |               | ✓      |                        |                     |
| <a href="#"><u>XBF-PN08B</u></a> | \$395.00 | LS Electric XGB 8-axis positioning module, EtherCAT Master, 1 high-speed input point(s), sinking/line driver (differential), 1-channel, differential and single-ended encoder input(s), (1) Ethernet 100Base-TX (RJ45) port(s). For use with LS Electric XEM-DxxxHx PLCs. |               |                |              |               | ✓      |                        |                     |
| <a href="#"><u>XBF-HO02A</u></a> | \$176.00 | LS Electric XGB counter input module, 200 kHz maximum switching frequency, 2 high-speed input point(s), 5-24 VDC, sinking, 2-channel, single-ended encoder input(s), 2 high-speed output point(s), 5-24 VDC, sinking, external 24 VDC required.                           |               |                |              |               | ✓      | ✓                      | ✓                   |
| <a href="#"><u>XBF-HD02A</u></a> | \$253.00 | LS Electric XGB counter input module, 500 kHz maximum switching frequency, 2 high-speed input point(s), 5-24 VDC, sinking, 2-channel, differential encoder input(s), 2 high-speed output point(s), 5-24 VDC, sinking, external 24 VDC required.                           |               |                |              |               | ✓      | ✓                      | ✓                   |

Note: See "Smart Link I/O System" on page tLSE-125 for the XTB-40H terminal block and cables. See "XGB PLC Replacement Terminals" on page tLSE-124 for replacement removable terminal blocks.

Continued on next page





# XGB Accessories

## Smart Link I/O System

The Smart Link I/O system is a breakout wiring system used for high density I/O modules in the LS Electric XGB PLC series. The system is required for all modules with a 40-pin connection, and consists of a Smart Link cable with an XTB-40H terminal block.

Download module specific XTB-40H Terminal Label Printouts here: [Terminal Printouts](#)




| Part Number                           | Price   | Description   | Length | Compatible With   |
|---------------------------------------|---------|---|--------|---|
| <a href="#"><u>XTB-40H</u></a>        | \$20.00 | LS Electric XGB terminal block, 40-pin screw type. For use with LS Electric XGB series high-density modules.  | n/a    | All LS XGB series PLCs and modules with 40-pin connectors |
| <a href="#"><u>XTB-40H-LABEL</u></a>  | \$3.00  | AutomationDirect terminal label sheet, printed with terminal names for LS Electric XGB series modules. Package of 8. For use with XTB-40H terminal block. | n/a    |   |
| <a href="#"><u>C40HH-05SB-XBI</u></a> | \$22.00 | LS Electric XGB PLC I/O cable, 1.6ft/0.5m cable length, 40-pin connector to 40-pin connector. For use with LS Electric XGB series high-density modules.   | 0.5 m  |   |
| <a href="#"><u>C40HH-10SB-XBI</u></a> | \$25.00 | LS Electric XGB PLC I/O cable, 3.2ft/1m cable length, 40-pin connector to 40-pin connector. For use with LS Electric XGB series high-density modules.     | 1m     |   |
| <a href="#"><u>C40HH-15SB-XBI</u></a> | \$29.00 | LS Electric XGB PLC I/O cable, 4.9ft/1.5m cable length, 40-pin connector to 40-pin connector. For use with LS Electric XGB series high-density modules.   | 1.5 m  |   |
| <a href="#"><u>C40HH-20SB-XBI</u></a> | \$36.00 | LS Electric XGB PLC I/O cable, 6.5ft/2m cable length, 40-pin connector to 40-pin connector. For use with LS Electric XGB series high-density modules.     | 2m     |   |
| <a href="#"><u>C40HH-30SB-XBI</u></a> | \$42.00 | LS Electric XGB PLC I/O cable, 9.8ft/3m cable length, 40-pin connector to 40-pin connector. For use with LS Electric XGB series high-density modules.     | 3m     |   |

| XTB-40H Specifications |  |               |
|------------------------|--|---------------|
| Number of Pins         | 40 pin                                   |               |
| Terminal Pitch         | 7.0 mm                                   |               |
| Connector Type         | MIL-C-83503<br>(50P polarity guide: 2EA) |               |
| Applicable Wires       | AWG22-16 (1.5mm <sup>2</sup> /MAX)       |               |
| Insulation Resistance  | 100MΩ (500VDC)                           |               |
| Dielectric Strength    | 500VAC 1 minute                          |               |
| Screw                  | M3 x 8L                                  |               |
| Screw Torque           | 1.2N•m (12kgf•cm)                        |               |
| Ambient Temperature    | -10°C to +50°C (no freezing)             |               |
| Material               | Case                                     | Modified PPO  |
|                        | Protective Cover                         | Polycarbonate |
|                        | PCB                                      | Epoxy 1.6t    |



## Smart Link I/O System, Terminals and Cable Connections

| Module to Cable to Terminal Pinouts |   |                  |
|-------------------------------------|---|------------------|
| Module Pins                         | C40HH-xxSB-XBI  | XTB-40H Terminal |
| B20                                 | <p>HIROSE<br/>HIF3BA-40D-2.54R</p> <p>HIROSE<br/>HIF3BA-40D-2.54R</p> | A1               |
| B19                                 |   | B1               |
| B18                                 |   | A2               |
| B17                                 |   | B2               |
| B16                                 |   | A3               |
| B15                                 |   | B3               |
| B14                                 |   | A4               |
| B13                                 |   | B4               |
| B12                                 |   | A5               |
| B11                                 |   | B5               |
| B10                                 |   | A6               |
| B09                                 |   | B6               |
| B08                                 |   | A7               |
| B07                                 |   | B7               |
| B06                                 |   | A8               |
| B05                                 |   | B8               |
| B04                                 |   | A9               |
| B03                                 |   | B9               |
| B02                                 |   | A10              |
| B01                                 |   | B10              |
| A20                                 | A11   |                  |
| A19                                 | B11   |                  |
| A18                                 | A12   |                  |
| A17                                 | B12   |                  |
| A16                                 | A13   |                  |
| A15                                 | B13   |                  |
| A14                                 | A14   |                  |
| A13                                 | B14   |                  |
| A12                                 | A15   |                  |
| A11                                 | B15   |                  |
| A10                                 | A16   |                  |
| A09                                 | B16   |                  |
| A08                                 | A17   |                  |
| A07                                 | B17   |                  |
| A06                                 | A18   |                  |
| A05                                 | B18   |                  |
| A04                                 | A19   |                  |
| A03                                 | B19   |                  |
| A02                                 | A20   |                  |
| A01                                 | B20   |                  |



HIROSE HIF3BA-40D-2.54R

