Capacitive Sensors
BCS M30B4M2-PPM20C-S04G
Order Code: BCS004T

BALLUFF

1) Sensing surface, 2) Housing, 3) Cover, 4) Potentiometer, 5) NO or NC selectable, 6) LED function indicator

Basic features

Approval/Conformity	CE
	cULus
	WEEE
Basic standard	IEC 60947-5-2
Scope of delivery	Nut (2x)
	Screwdriver
	Short guide
Sensitivity	Switching distance adjustable
Series	M30

Display/Operation

Function indicator	yes
Power indicator	yes

Electrical connection

Connection	M12x1-Male, 4-pin, A-coded
Polarity reversal protected	yes
Protection against device mix-ups	yes
Short-circuit protection	yes

Electrical data

No-load current Io max. at Ue	18 mA
Operating voltage Ub	10...35 VDC
Rated insulation voltage Ui	75 V DC
Rated operating current Ie	300 mA
Rated operating voltage Ue DC	24 V
Ripple max. (% of Ue)	10 %
Switching frequency	100 Hz
Utilization category	DC -13
Voltage drop static max.	1.8 V

Environmental conditions

Ambient temperature	-30...70 °C
Contamination scale	1
IP rating	IP66, IP64 at connector output

Functional safety

MTTF (40 °C)	455 a

Interface

Switching output	PNP NO/NC programmable

Material

Cover material	PBT
	PE
Housing material	1.4301 stainless steel
Material sensing surface	PBT

Capacitive Sensors
BCS M30B4M2-PPM20C-S04G
Order Code: BCS004T

BALLUFF

Mechanical data

Dimension	Ø 30 x 87 mm
Installation	for flush mounting
Size	M30x1.5
Thread (A)	M30x1.5
Tightening torque	90 Nm

Range/Distance

|	
Hysteresis H max. (% of Sr)	15.0 %
Measuring range	1...20 mm
Rated operating distance Sn	20 mm
Repeat accuracy max. (% of Sr)	5.0 %
Temperature drift max. (% of Sr)	20 %

Remarks

The potentiometer does not have a fixed stop, but can be turned endlessly without destroying anything.

If no change in the switching signal is detected, the potentiometer should be turned forwards or backwards until a signal change occurs at the output.

For more information about MTTF and B10d see MTTF / B10d Certificate

Indication of the MTTF- / B10d value does not represent a binding composition and/or life expectancy assurance; these are simply experiential values with no warranty implications. These declared values also do not extend the expiration period for defect claims or affect it in any way.

Connector Drawings

Wiring Diagrams

Installation remarks

1) Machine GND