General Specifications		
Operating Temperature	0° to 60°C (32° to 140°F)	
Storage Temperature	-20° to 85°C (-4° to 185°F)	
Humidity	5 to 95% (non-condensing)	
Environmental Air	No corrosive gases permitted	
Vibration	IEC60068-2-6 (Test Fc)	
Shock	IEC60068-2-27 (Test Ea)	
Enclosure Type	Open Equipment	
	UL61010-2 - UL File # E185989 Canada and USA	
Agency Approvals	CE Compliant EN61131-2*	
Noise Immunity	NEMA ICS3-304	
EU Directive	See the "EU Directive" topic in the Help File	
Weight	169g (6 oz)	
*Maata EMC and Cafety rac	wiromanta. Saa tha D.O.C. far dataila	

*Meets EMC and Safety requirements. See the D.O.C. for details.

Power Supply Specific	ations
Nominal Voltage Range*	12–24 VDC
Input Voltage Range (Tolerance)*	10–36 VDC
Maximum Input Voltage Ripple	<+/- 10%
Maximum Input Power	14W
Cold Start Inrush Current	5A, 2ms
Maximum Inrush Current (Hot Start)	5A, 2ms
Internal Input Protection	Reverse Polarity Protection and Undervoltage
Heat Dissipation	7.4W Max
Voltage Withstand (dielectric)	1500VAC Power Inputs to Ground applied for 1 minute
*Class 2 or LPS Power Supply require	4


*Class 2 or LPS Power Supply required.

CPU Specifications			
Program Memory Type	FLASH memory		
User Data Memory Type	Battery Backed RAM, User configurable		
Pluggable Option Module	RS-232, RS-485, Ethernet 10/100 BASE-T (1Mbps throughput max), USB 2.0 Type B		
Expansion Modules	2 expansion modules max		
Real Time Clock Accuracy	±2.6s per day typical at 25°C ±8s per day max at 60°C		
Programming Software	Do-more Designer – Ver. 2.0 or higher		
Programming Cable Options	BX-PGM-CBL		

Terminal Block Connection Options BX-RTB10 Terminal Block Kit, 90-degree screw type, Fits all BRX 10-point PLCs and

	16 point Expansion I/O Modules. Kit includes (2) 10-pin 3.8mm plugs.	
BX-RTB10-1	Terminal Block Kit, 180-degree spring clamp type, Fits all BRX 10-point PLCs and 16 point Expansion I/O Modules. Kit includes (2) 10-pin 3.8mm plugs.	
BX-RTB10-2	Terminal Block Kit, 180-degree screw type, Fits all BRX 10-point PLCs and 16 point Expansion I/O Modules. Kit includes (2) 10-pin 3.8mm plugs.	
ZL-BX-CBL20	ZIP Link PLC I/O cable, 20-position terminal block to 24-pin connector, 24AWG, cable length 0.5meter (1.6ft).	
ZL-BX-CBL20-1 ZIPLink PLC I/O cable, 20-position terminal block to 24-pin connector 24AWG, cable length 1meter (3.3ft).		
ZL-BX-CBL20-2	ZIP Link PLC I/O cable, 20-position terminal block to 24-pin connector, 24AWG, cable length 2meter (6.6ft).	
ZL-BX-CBL20-1P	ZIP Link PLC I/O cable, 20-position terminal block to pigtail connection, 24AWG, cable length 1meter (3.3ft).	
ZL-BX-CBL20-2P	ZIP Link PLC I/O cable, 20-position terminal block to pigtail connection, 24AWG, cable length 2meter (6.6ft).	
ZL-RTB20	ZIPLink Two Level Feedthrough Module, 20-pole, 35mm, DIN mount.	
ZL-RTB20-1	ZIPLink Three Level Feedthrough Module, 20-pole, 35mm, DIN mount.	

Port Name	RS-232/RS-485 Serial Port
Description*	Non-isolated serial port that can communicate via RS-232 or RS-485 (software selectable). Includes ESD protection and built-in surge protection.
Supported Protocols	Do-more Protocol (Default) Modbus RTU (Master & Slave) K-Sequence (Slave) ASCII (In & Out)
Data Rates	1200, 2400, 4800, 9600, 19200, 38400, 57600, ar 115200
Default Settings	RS-232, 115200 bps, No Parity, 8 Data Bits, 1 Sto Bit, Station #1
Port Type	3-pin terminal strip 3.5mm pitch
Port Status LED	Green LED is illuminated when active for TXD and RXD
RS-485 Station Addresses	1-247
Cable Recommendations	RS-232 use L19772-XXX from AutomationDirect.c
Cable Recommendations	RS-485 use L19827-XXX from AutomationDirect.c
Replacement Connector	ADC Part # BX-RTB03S





Removable connector included.

* NOTE: When using RS-485, a terminator resistor is built-in and software selectable.


CPU Mode Switch Functions		
RUN position CPU is forced into RUN Mode if no errors are encour		CPU is forced into RUN Mode if no errors are encountered.
	TERM position	RUN, PROGRAM and DEBUG modes are available. In this position, the mode of operation can be changed through the Do-more Designer Software.
	STOP position	CPU is forced into STOP Mode.

Dimensional Information





Mounting Restrictions



Terminal	Block Con	nector Sp	ecificatio	ns
Part Number	BX-RTB03S	BX-RTB10	BX-RTB10-1	BX-RTB10-2
Connector Type	Screw Type-90°	Screw Type-90°	Spring Clamp Type-180°	Screw Type- 180°
Wire Exit	180°	180°	180°	180°
Pitch	3.5mm	3.81mm	3.81mm	3.81mm
Screw Size	M2	M2	N/A	M2
Recommended Screw torque	<1.77 lb∙in (0.2 N∙m)	<1.77 lb∙in (0.2 N∙m)	N/A	<1.77 lb∙in (0.2 N∙m)
Screwdriver Blade Width	2.5mm	2.5mm	2.5mm	2.5mm
Wire Gauge (Single Wire)	28-16 AWG	28-16 AWG	28-18 AWG	30-16 AWG
Wire Gauge (Dual Wire)	28-16 AWG	28-16 AWG	30-20 AWG (Dual Wire Ferrule Required)	30-18 AWG
Wire Strip Length	0.24in (6mm)	0.24in (6mm)	0.35in (9mm)	0.26in (6.5mm)
Equiv. Dinkle part #	EC350V-03P-BK	EC381V-10P-BK	ESC381V-10-BK	EC381F-10P-BK

CPU St	CPU Status Indicators		
Indicator	Status	Description	
	OFF	Base Power OFF	
PWR	Green	Base Power ON	
	Yellow	Low Battery	
	OFF	CPU is in STOP Mode	
RUN	Green	CPU is in RUN Mode	
	Yellow	Forces are Active	
	OFF	No ROM Activity, No SD Card	
MEM	Yellow	ROM Activity (Flash or SD Card)	
	Green	SD Card Installed and Mounted	
	Red	SD Card Installed and Not Mounted	
ERR	OFF	CPU is functioning normally	
	Red	CPU Fatal Hardware Error or Software Watchdog Error	

Do-more BRX Manual available at www.automationdirect.com/pn/doc/ manual/BX-DM1-10ED2-D







BX-DM1-10ED2-D

BRX MPU with Do-more! DM1 technology 24 VDC required, serial port, microSD slot, Discrete Input: 6-point, sink / source, Discrete Output: 4-point, sourcing.

I/O Terminal Blocks sold separately.

	(See Terminal Block Connection Options table).		
	Document Name	Edition/Revision	Date
	BX-DM1-10ED2-D	1st Ed. RevD	9/8/2021
Convright 2021 AutomationDirect com Incornorated/All Rights Reserved Worldwide			

WARNING: To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and it is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call Technical Support at 770-844-4200.


This publication is based on information that was available at the time it was printed. At AutomationDirect.com[®] we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.



Hot-Swapping Information

Note: This device cannot be Hot Swapped.

Terminal and Front Panel Layout



6 1 2	Battery Replacement
	Coin Battery CR2032
of the	ADC Part # D0-MC-BAT.
00	Replacement batteries do
7	with topo. To oppiet with fur

Coin Battery CR2032 ADC Part # D0-MC-BAT. Replacement batteries do not come with tape. To assist with future battery removal, reuse tape from the original battery or add new tape.

R20

NOTE: Do not

remove tape from battery.

NOTE: DIP switches located in this compartment are used for debug and recovery functions only. Please refer to the BRX User Manual for full instructions on using these switches.

> POM Modules BX-P-SER2-TERM 3-Pin Serial RS-232 BX-P-SER2-RJ12 RJ12 Serial RS-232 BX-P-SER4-TERM 3-Pin Serial RS-485 BX-P-USB-B USB Type B BX-P-USB-B USB Type B BX-P-ECOMLT Ethernet 10/100 BASE-T NOTE: Only POM modules can be hot-swapped.

Discrete Input	Specifications
Input Type	Sink/Source
Total Inputs per Module	6 High Speed – All inputs may be used as standard inputs
Commons	2 (3 points/common) Isolated
Nominal Voltage Rating	12–24 VAC/DC
Input Voltage Range	9–30 VAC/DC
Maximum Voltage	30 VAC/DC
DC Frequency	0–250kHz - High Speed
Minimum Pulse Width	0.5 μs - High Speed
AC Frequency	47–63 Hz (60–240Hz filter must be set in software for AC operation)
Input Impedance	3kΩ @ 24VDC
Input Current (typical)	6mA @ 24 VAC/DC
Maximum Input Current	12mA @ 30 VAC/DC
Maximum OFF Current	2.0 mA
ON Voltage Level	> 9.0 VAC/VDC
OFF Voltage Level	< 2.0 VAC/VDC
Status Indicators	Logic Side, Green

Discrete Output	Specifications		
Output Type	Sourcing		
Total Outputs per Module	4 Total – 2 High Speed (Y0Y1)* 2 Standard (Y2Y3) *All outputs may be used as standard outputs		
Commons	2 (2 points/common) Isolated		
Maximum Current per Common	1A 12–24 VDC 5–36 VDC 36VDC 0.1mA @ 24VDC 0.5A per output, no derating over temperature range 10μA		
Nominal Voltage Rating			
Operating Voltage Range			
Maximum Voltage			
Minimum Output Current			
Maximum Output Current			
Maximum Leakage Current			
Maximum Switching	1m cable	250KHz	
Frequency	10m cable	100KHz	
Status Indicators	Logic Side, Green		

High Speed Input (HSI) Functions 10/ 18/ 36/ 10E 18E 36E Inputs Input Function Required¹ Up counters 1 High-Speed Counting Position Scaling Down counters 1 2 Up/Down counters Pulse/Direction (Bidirectional) counters 2 Frequency Measurement 2 Quadrature (A and B) counters Up to (3) 3 Quadrature (A and B with Z) counters 1 Single Input (Edge) timers Interval Measurement Dual Input (Dual Edge) timers 2 Duration 1 Single Input (Edge) timers Measurement Table-Driven Programmable limit switches Output(s)² Preset tables 4 Input interrupts Up to (4) Interrupt(s) 0 Timer interrupts 0 Match register interrupts

 Standard inputs may be used with high-speed functions, but at lower response frequencies of approximately 120Hz.

 Table Driven Output(s) are triggered by an Axis Position or a high-speed counter/timer accumulator value. It requires the selection of 1 discrete output. (see HSO Note 1 below)

High Speed Output (HSO) Functions					
	Outputs Required ¹	Function ²	10/ 10E	18/ 18E	36 36
Pulse Mode	0	Virtual axis	4	4	4
	2	PTO linear step/direction outputs	2	3	3
	2	PTO rotary clockwise/counter- clockwise (CW/CCW) outputs	2	3	3
	2	PTO quadrature (A and B) output	2	3	3
	1	PWM pulse width modulation outputs	4	4	4
Axis Profile	Relative/Absolute positioning, Velocity mode, Trapezoid, S-curve, Electronic gearing, Camming, Following, Homing, Jogging				
1. Standard outputs may be used for high-speed functions, but at lower response frequencies of					

approximately 110Hz. Use of fead outputs is not recommended. 2. This is the total number of functions. A combination of high-speed outputs and standard out-

 This is the total number of functions. A combination of high-speed outputs and standard ou puts may be used up to this total.

