



# TABLE OF CONTENTS

---

## Chapter 1 - Getting Started

|   |      |
|---|------|
| Introduction.....                                   | 1-2  |
| Conventions Used.....                               | 1-3  |
| Before you begin.....                               | 1-4  |
| Step 1: Install Software.....                       | 1-5  |
| Step 2: Launch Programming Software .....           | 1-7  |
| Step 3: Set Up User Account.....                    | 1-9  |
| Step 4: Create a Project.....                       | 1-10 |
| Step 5: Compile and Save Project.....               | 1-16 |
| Step 6: Apply Power .....                           | 1-17 |
| Step 7: Establish PC to PLC Communications.....     | 1-18 |
| Step 8: Write Project into PLC.....                 | 1-30 |
| Step 9: Place PLC in RUN Mode .....                 | 1-31 |
| Step 10: Test Project using Data View Monitor ..... | 1-32 |
| Step 11: Y001 Output On?.....                       | 1-33 |
| Step 12: Test Project Using Remote PLC App.....     | 1-34 |
| Additional Training Resources .....                 | 1-38 |

## Chapter 2 - Specifications

|  |     |
|--|-----|
| Overview of PLC System .....             | 2-2 |
| Regulatory and Standards Compliance..... | 2-3 |
| CLICK PLUS PLC Units .....               | 2-4 |
| Option Slot I/O Modules .....            | 2-6 |
| Option Slot Intelligent Modules .....    | 2-8 |

|   |       |
|---|-------|
| Stackable I/O Modules .....                         | 2-9   |
| Power Budgeting .....                               | 2-13  |
| PLC Unit Specifications .....                       | 2-16  |
| Option Slot I/O Module Specifications .....         | 2-31  |
| Option Slot Intelligent Module Specifications ..... | 2-84  |
| Stackable I/O Module Specifications.....            | 2-87  |
| Power Supply Specifications.....                    | 2-123 |
| Programming Software .....                          | 2-126 |
| Data Types, Memory, and Numbering System .....      | 2-127 |
| PLC Operation.....                                  | 2-131 |
| Accessories.....                                    | 2-135 |

## Chapter 3 - Installation and Wiring

|   |      |
|---|------|
| Safety Guidelines.....                                    | 3-2  |
| Introduction to the CLICK PLUS PLC Mechanical Design..... | 3-5  |
| Mounting Guidelines .....                                 | 3-10 |
| Installing the CLICK PLUS PLC .....                       | 3-19 |
| Wiring Guidelines.....                                    | 3-21 |
| I/O Wiring Checklist .....                                | 3-29 |
| System Wiring Strategies .....                            | 3-30 |
| LAN Provisioning over Bluetooth .....                     | 3-41 |
| Option Slot Analog I/O Configuration.....                 | 3-45 |
| High-Speed Input/Output Configuration.....                | 3-52 |
| Setting Up and Using an SD Card.....                      | 3-57 |

## Chapter 4 - PLC Communications

|  |     |
|--|-----|
| Introduction.....                            | 4-2 |
| PLC Communication Ports Specifications ..... | 4-3 |
| LED Status Indicators.....                   | 4-4 |
| Remote PLC App Configuration and Use.....    | 4-6 |

C2-DCM Intelligent Module Communication Ports Specifications ..... 4-7

3 Steps to Using the CLICK PLC Communications ..... 4-8

Typical Communication Applications ..... 4-9

W-1: USB Port Wiring ..... 4-13

W-2: Com Port 2 (RS-232) Wiring ..... 4-14

W-3: Com Port 1 (Ethernet) Wiring ..... 4-18

W-4: Com Port 3 Wiring ..... 4-20

W-5: C2-DCM Com Port RS-232 Wiring ..... 4-21

W-6: C2-DCM Com Port RS-485 Wiring ..... 4-22

C-1: USB Port Setup ..... 4-23

C-2: Com Port 1 (Ethernet) Setup ..... 4-24

C-3: Wireless LAN (WLAN) Setup ..... 4-25

C-4: Bluetooth Setup ..... 4-26

C-5: Com Port 2 Setup (Modbus RTU) ..... 4-27

C-6: Com Port 2 Setup (ASCII) ..... 4-28

C-7: Com Port 3 Setup (Modbus RTU) ..... 4-29

C-8: Com Port 3 Setup (ASCII) ..... 4-30

C-9: C2-DCM Com Port 1 or 2 Setup (ASCII) ..... 4-31

C-10: C2-DCM Com Port 1 or 2 Setup (Modbus RTU) ..... 4-32

P-1: Modbus Slave (Server) Programming ..... 4-33

P-2: Modbus Master Programming (Modbus RTU) ..... 4-37

P-3: Modbus Client (Modbus TCP) Programming ..... 4-42

P-4: ASCII Receive Programming ..... 4-48

P-5: ASCII Send Programming ..... 4-51

**Chapter 5 - Maintenance**

PLC Maintenance ..... 5-2

**Chapter 6 - Troubleshooting**

Troubleshooting Direction ..... 6-2

## Table of Contents

---

|  |      |
|--|------|
| PLC unit Troubleshooting .....                 | 6-3  |
| Bluetooth Troubleshooting .....                | 6-5  |
| Wireless LAN Troubleshooting .....             | 6-6  |
| USB Troubleshooting .....                      | 6-7  |
| SD Card Troubleshooting .....                  | 6-8  |
| Power Supply Troubleshooting.....              | 6-9  |
| I/O Module Troubleshooting .....               | 6-10 |
| Resetting to Factory Defaults.....             | 6-14 |
| Troubleshooting Electrical Noise Problems..... | 6-15 |
| Error Codes.....                               | 6-16 |

## Appendix A - Security Considerations for Control Systems Networks

|   |     |
|---|-----|
| Security Considerations for Control Systems Networks..... | A-2 |
|---|-----|