


# CONFIGURATION GUIDE



# CR6000

Configuration barcodes generated based on current firmware versions  
D036894\_01 CR6000 Configuration Guide  
4-29-2020



[www.codecorp.com](http://www.codecorp.com)



User Manual



[YouTube.com/codecorporation](https://YouTube.com/codecorporation)

**code**  
ADVANCED BARCODE READERS

# Table of Contents

<b>Direct Part Mark Reading Mode Setting.....</b>	<b>7</b>
DPM Auto Mode - Default.....	7 (A2)
DPM Dark Field (Dot Peen 15-45 Degrees).....	7 (A3)
DPM Dark Field (Dot Peen 15-45 Degrees/Laser-Etched 90 Degrees).....	7 (A4)
DPM Dark Field (Laser-Etched 90 Degrees).....	7 (B1)
DPM Diffuse Bright Field (Dot Peen 90 Degrees).....	7 (B2)
DPM Diffuse Bright Field (Dot Peen/Laser-Etched 90 Degrees).....	7 (B3)
DPM Diffuse Bright Field (Laser-Etched 90 Degrees).....	7 (B4)
DPM Curved Surface Mode (Dot Peen/Laser-Etched 90 Degrees).....	7 (C1)
DPM Direct Bright Field (Paper Label).....	7 (C2)
DPM Motion Detection Dark Field - Default.....	7 (C3)
DPM Motion Detection Diffuse Bright Field.....	7 (C4)
DPM Motion Detection Direct Bright Field.....	7 (D1)
<b>General Reading Mode Settings.....</b>	<b>7-8</b>
Continuous Scan On.....	7 (D3)
Continuous Scan Off - Default.....	7 (D4)
Motion Detection On when In Stand and Trigger Out of Stand - Default.....	7 (E1)
Motion Detection On In and Out of Stand.....	7 (E2)
Optimize Motion Detection for Bright Environments - Default.....	7 (E3)
Optimize Motion Detection for Dark Environments.....	7 (E4)
No Motion Detection Delay - Default.....	8 (A1)
500ms Motion Detection Delay.....	8 (A2)
Motion Detection Off In and Out of Stand.....	8 (A3)
Mirroring On.....	8 (A4)
Mirroring Off - Default.....	8 (B1)
Targeting On - Default.....	8 (B2)
Targeting Off.....	8 (B3)
<b>Data Formatting (Prefix/Suffix) Settings.....</b>	<b>8-9</b>
Turn on Timestamp Prefix.....	8 (C2)
Turn off Timestamp Prefix - Default.....	8 (C3)
Convert output to lowercase.....	8 (C4)
Erase Prefix & Suffix Data - Default.....	8 (D1)
Erase Prefix Data - Default.....	8 (D2)
Erase Suffix Data - Default.....	8 (D3)
Prefix AIM ID On.....	8 (D4)
Prefix AIM ID Off - Default.....	8 (E1)
Prefix Carriage Return Line Feed (RS232 Mode Only).....	8 (E2)
Prefix Comma.....	8 (E3)
Prefix Space.....	8 (E4)
Prefix Tab (USB Keyboard Mode Only).....	9 (A1)
Prefix Tab (RS232 Mode Only).....	9 (A2)
Suffix Carriage Return (RS232 Mode Only).....	9 (A3)
Suffix Carriage Return Line Feed (RS232 Mode Only).....	9 (A4)
Suffix Comma.....	9 (B1)
Suffix Enter (USB Keyboard Mode Only).....	9 (B2)
Suffix Line Feed (RS232 Mode Only).....	9 (B3)
Suffix Space.....	9 (B4)
Suffix Tab (USB Keyboard Mode Only).....	9 (C1)
Suffix Tab (RS232 Mode Only).....	9 (C2)
Translate all Characters to Uppercase On.....	9 (C3)
Translate all Characters to Uppercase Off - Default.....	9 (C4)
<b>Symbology Settings.....</b>	<b>9-16</b>
Australian Post On.....	9 (D2)
Australian Post Off - Default.....	9 (D3)
Aztec On - Default.....	9 (D4)
Aztec Inverse On.....	9 (E1)
Aztec Inverse & Normal On.....	9 (E2)
Aztec Off.....	9 (E3)

## Table of Contents

Codabar On - Default.....	9 (E4)
Codabar Off.....	10 (A1)
Remove Codabar Start and Stop Delimiters.....	10 (A2)
Keep Codabar Start and Stop Delimiters - Default.....	10 (A3)
Codablock F On.....	10 (A4)
Codablock F Off - Default.....	10 (B1)
Code 11 On.....	10 (B2)
Code 11 Off - Default.....	10 (B3)
Code 11 Checksum Stripped from Result On.....	10 (B4)
Code 32 (Italian Pharmacode) On.....	10 (C1)
Code 32 (Italian Pharmacode) Off - Default.....	10 (C2)
Code 39 Off.....	10 (C3)
Code 39 On - Default.....	10 (C4)
Code 39 Checksum On.....	10 (D1)
Code 39 Checksum Off - Default.....	10 (D2)
Code 39 Checksum Stripped from Result On.....	10 (D3)
Code 39 Extended Full ASCII Off - Default.....	10 (D4)
Code 39 Extended Full ASCII On.....	10 (E1)
Code 49 On.....	10 (E2)
Code 49 Off - Default.....	10 (E3)
Code 93 On - Default.....	10 (E4)
Code 93 Off.....	11 (A1)
Code 128 On.....	11 (A2)
Code 128 Off.....	11 (A3)
Composite On.....	11 (A4)
Composite Off - Default.....	11 (B1)
Data Matrix Inverse On - Default.....	11 (B2)
Data Matrix Inverse Off.....	11 (B3)
Data Matrix Rectangular On & Rectangular Extended On.....	11 (B4)
Data Matrix Rectangular On & Rectangular Extended Off - Default.....	11 (C1)
Data Matrix Rectangular & Rectangular Extended Off.....	11 (C2)
Grid Matrix On.....	11 (C3)
Grid Matrix Off - Default.....	11 (C4)
All GS1 DataBar On - Default.....	11 (D1)
All GS1 DataBar Off.....	11 (D2)
GS1 DataBar Limited On.....	11 (D3)
GS1 DataBar Limited Off.....	11 (D4)
GS1 DataBar Expanded On.....	11 (E1)
GS1 DataBar Expanded Off.....	11 (E2)
GS1 DataBar Expanded Stacked On.....	11 (E3)
GS1 DataBar Expanded Stacked Off.....	11 (E4)
GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional On.....	12 (A1)
GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional Off.....	12 (A2)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated On.....	12 (A3)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off.....	12 (A4)
Han Xin On.....	12 (B1)
Han Xin Off - Default.....	12 (B2)
Hong Kong 2 of 5 Off - Default.....	12 (B3)
Hong Kong 2 of 5 On.....	12 (B4)
Int 2 of 5 On - Default.....	12 (C1)
Int 2 of 5 Off.....	12 (C2)
Int 2 of 5 Checksum Stripped from Result On.....	12 (C3)
Int 2 of 5 Checksum On.....	12 (C4)
Int 2 of 5 Checksum Off.....	12 (D1)
Japan Post On.....	12 (D2)
Japan Post Off - Default.....	12 (D3)
KIX (Dutch Post) Code On.....	12 (D4)
KIX (Dutch Post) Code Off - Default.....	12 (E1)
Korean Post On.....	12 (E2)
Korean Post Off - Default.....	12 (E3)
Maxicode On.....	12 (E4)

## Table of Contents

Maxicode Off - Default.....	13 (A1)
Matrix 2 of 5 On.....	13 (A2)
Matrix 2 of 5 Off - Default.....	13 (A3)
Micro PDF417 On.....	13 (A4)
Micro PDF417 Off - Default.....	13 (B1)
MSI Plessey On.....	13 (B2)
MSI Plessey Off - Default.....	13 (B3)
NEC 2 of 5 On.....	13 (B4)
NEC 2 of 5 Off - Default.....	13 (C1)
PDF417 On - Default.....	13 (C2)
PDF417 Off.....	13 (C3)
Pharmacode On.....	13 (C4)
Pharmacode Reverse Barcode Decoding (Right to Left).....	13 (D1)
Pharmacode Normal Barcode Decoding (Left to Right).....	13 (D2)
Pharmacode Off.....	13 (D3)
All QR Code On.....	13 (D4)
Standard QR Code On - Default.....	13 (E1)
All QR Code Off.....	13 (E2)
Straight 2 of 5 On.....	13 (E3)
Straight 2 of 5 Off - Default.....	13 (E4)
Telepen On.....	14 (A1)
Output Telepen as ASCII.....	14 (A2)
Output Telepen as Numeric - Default.....	14 (A3)
Telepen Off - Default.....	14 (A4)
Trioptic On.....	14 (B1)
Trioptic - Enable Reverse Order option (Bit 3).....	14 (B2)
Trioptic - Disable Reverse Order option (Bit 3) - Default.....	14 (B3)
Trioptic Off - Default.....	14 (B4)
UK Plessey On.....	14 (C1)
UK Plessey Off - Default.....	14 (C2)
UK Royal Mail On.....	14 (C3)
UK Royal Mail Off - Default.....	14 (C4)
UPC Off.....	14 (D1)
UPC On - Default.....	14 (D2)
UPC Supplemental On.....	14 (D3)
Transmit UPC-A Number System Off.....	14 (D4)
UPC Supplemental Off - Default.....	14 (E1)
Transmit UPC-A Check Digit On - Default.....	14 (E2)
Transmit UPC-A Check Digit Off.....	14 (E3)
Transmit UPC-A Number System On - Default.....	14 (E4)
Convert UPC-A to EAN-13 On.....	15 (A1)
Convert UPC-A to EAN-13 Off - Default.....	15 (A2)
UPC-E Expansion On.....	15 (A3)
UPC-E Expansion Off - Default.....	15 (A4)
Transmit UPC-E Check Digit On - Default.....	15 (B1)
Transmit UPC-E Check Digit Off.....	15 (B2)
Transmit UPC-E Number System On - Default.....	15 (B3)
Transmit UPC-E Number System Off.....	15 (B4)
Transmit EAN-8 Check Digit On - Default.....	15 (C1)
Transmit EAN-8 Check Digit Off.....	15 (C2)
Convert EAN-8 to EAN-13 On.....	15 (C3)
Convert EAN-8 to EAN-13 Off - Default.....	15 (C4)
Transmit EAN-13 Check Digit On - Default.....	15 (D1)
Transmit EAN-13 Check Digit Off.....	15 (D2)
Convert Bookland EAN-13 to ISBN On.....	15 (D3)
Convert Bookland EAN-13 to ISBN Off - Default.....	15 (D4)
Convert Bookland EAN-13 to ISSN On.....	15 (E1)
Convert Bookland EAN-13 to ISSN Off - Default.....	15 (E2)
UPU ID-Tag On.....	15 (E3)
UPU ID-Tag Off - Default.....	15 (E4)
USPS Intelligent Mail/IMB/ 4-State CB On.....	16 (A1)

## Table of Contents



















USPS Intelligent Mail/IMB/ 4-State CB Off - Default.....	16 (A2)
USPS Planet On.....	16 (A3)
USPS Planet Off - Default.....	16 (A4)
USPS Postnet On.....	16 (B1)
USPS Postnet Off - Default.....	16 (B2)
Grid Matrix & Grid Matrix Inverse Decoding On.....	16 (B3)
Grid Matrix & Grid Matrix Mirror Decoding On.....	16 (B4)
Grid Matrix, Grid Matrix Inverse & Grid Matrix Mirror Decoding.....	16 (C1)
GoCode & GoCode Inverse Decoding.....	16 (C2)
GoCode & GoCode Mirror Decoding On.....	16 (C3)
GoCode, GoCode Inverse & GoCode Mirror Decoding On.....	16 (C4)
Code 11 Decoding with one checksum digit checked, and remove checksum from output On.....	16 (D1)
<b>Keyboard Language Settings.....</b>	<b>16-17</b>
Keyboard Support: French Keyboard Mapping for Apple.....	16 (D3)
Keyboard Support: USInternational (Universal) Keyboard Mapping for Windows.....	16 (D4)
English (US) Keyboard Mapping for Windows.....	16 (E1)
English (UK) Keyboard Mapping for Windows.....	16 (E2)
Belgian French Keyboard Mapping for Windows.....	16 (E3)
French Keyboard Mapping for Windows.....	16 (E4)
German Keyboard Mapping for Windows.....	17 (A1)
Japanese Keyboard Mapping for Windows.....	17 (A2)
Latin American Keyboard Mapping for Windows.....	17 (A3)
Spanish Keyboard Mapping for Windows.....	17 (A4)
Swiss German Keyboard Mapping for Windows.....	17 (B1)
English Keyboard Mapping for Apple.....	17 (B2)
Keyboard Support: Spanish Keyboard Mapping for Apple.....	17 (B3)
Italian Keyboard Mapping for Apple.....	17 (B4)
German-Swiss Keyboard Mapping for Apple.....	17 (C1)
German Keyboard Mapping for Apple.....	17 (C2)
Russian Keyboard Mapping for Windows.....	17 (C3)
Control Character Input - Ctrl + Character.....	17 (C4)
Control Character Input - Alt + Keypad.....	17 (D1)
Control Character Input -Alt + Leading Zero.....	17 (D2)
Control Character Input - Language - Default.....	17 (D3)
Data Encoding: Raw ASCII to Keyboard XML File Lookup - Default.....	17 (D4)
Data Encoding: UTF8 to Unicode Codepoint - Alt Sequences for Windows.....	17 (E1)
Shift-JIS Mode for Japanese Windows OS.....	17 (E2)
Shift-JIS Mode for English Windows OS.....	17 (E3)
<b>Operating System Settings.....</b>	<b>18</b>
Alternative Operating System (Linux/Mac) On.....	18 (A2)
Alternative Operating System (Linux/Mac) Off - Default.....	18 (A3)
<b>USB Settings.....</b>	<b>18</b>
Reader - USB Virtual COM CDC Raw Mode.....	18 (B2)
Reset to USB Factory Defaults.....	18 (B3)
USB Keyboard Mode.....	18 (B4)
USB Downloader Mode.....	18 (C1)
USB HID POS Mode (Terminal ID 131).....	18 (C2)
USB Native Two Way Mode.....	18 (C3)
USB Virtual COM One Way Mode.....	18 (C4)
USB Virtual COM Multiple Ports.....	18 (D1)
USB Virtual COM Common Ports.....	18 (D2)
USB Speed High Speed - Default.....	18 (D3)
USB Speed Full Speed.....	18 (D4)
<b>RS232 Settings.....</b>	<b>18-19</b>
Reader - Enable RS232 OPOS/JPoS.....	18 (E2)
Reset to RS232 Factory Defaults.....	18 (E3)
RS232 Interface 1200 Baud Rate.....	18 (E4)

# Table of Contents

RS232 Interface 2400 Baud Rate.....	19 (A1)
RS232 Interface 4800 Baud Rate.....	19 (A2)
RS232 Interface 9600 Baud Rate.....	19 (A3)
RS232 Interface 19200 Baud Rate.....	19 (A4)
RS232 Interface 38400 Baud Rate.....	19 (B1)
RS232 Interface 57600 Baud Rate.....	19 (B2)
RS232 Interface 115200 Baud Rate - Default.....	19 (B3)
RS232 Interface 7 Data Bits.....	19 (B4)
RS232 Interface 8 Data Bits - Default.....	19 (C1)
RS232 Interface Stop Bits 1 - Default.....	19 (C2)
RS232 Interface Stop Bits 2.....	19 (C3)
RS232 Interface Even Parity.....	19 (C4)
RS232 Interface Odd Parity.....	19 (D1)
RS232 Interface No Parity - Default.....	19 (D2)
RS232 Interface Flow Control Off - Default.....	19 (D3)
RS232 Interface Flow Control - Hardware.....	19 (D4)
RS232 Packet Mode.....	19 (E1)
RS232 Raw Mode - Default.....	19 (E2)
<b>Reader Feedback Settings.....</b>	<b>19-20</b>
Beep On Vibrate On - Default.....	19 (E4)
Beep Off Vibrate Off.....	20 (A1)
Beep Off Vibrate On .....	20 (A2)
Beep On Vibrate Off .....	20 (A3)
Beep Volume 100% - Default.....	20 (A4)
Beep Volume 67%.....	20 (B1)
Beep Volume 33%.....	20 (B2)
Beep Volume 0%.....	20 (B3)
Output Good Read on RTS line Off - Default.....	20 (B4)
Output Good Read on RTS line - Active Low.....	20 (C1)
Output Good Read on RTS line - Active High.....	20 (C2)
<b>Scan Delay Settings.....</b>	<b>20</b>
Duplicate Scan Disabled - Default.....	20 (C4)
1 Second Duplicate Scan Delay.....	20 (D1)
2 Second Duplicate Scan Delay.....	20 (D2)
3 Second Duplicate Scan Delay.....	20 (D3)
5 Second Duplicate Scan Delay.....	20 (D4)
10 Second Duplicate Scan Delay.....	20 (E1)
30 Second Duplicate Scan Delay.....	20 (E2)
1 Hour Duplicate Scan Delay.....	20 (E3)
1 Day Duplicate Scan Delay.....	20 (E4)
<b>Miscellaneous Settings.....</b>	<b>21</b>
Locked Reader Accept Host Commands - Default.....	21 (A2)
Locked Reader Reject Host Commands.....	21 (A3)
<b>Reader/Modem Command Settings.....</b>	<b>21</b>
Reader ID and Firmware Version.....	21 (B2)
Reader Text Commands On.....	21 (B3)
Reader Text Commands Off - Default.....	21 (B4)
<b>Reset, Clear and Save Reader Settings.....</b>	<b>21</b>
Clear All JavaScript Rules.....	21 (C2)
Clear All Stored Data and Images.....	21 (C3)
Save All Reader Settings.....	21 (C4)
Reboot Reader.....	21 (D1)

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<b>Direct Part Mark Reading Mode Setting</b>	<b>DPM Auto Mode - Default</b>  M10375_01 <b>A2</b>	<b>DPM Dark Field (Dot Peen 15-45 Degrees)</b>  M10378_01 <b>A3</b>	<b>DPM Dark Field (Dot Peen 15-45 Degrees/Laser-Etched 90 Degrees)</b>  M10379_01 <b>A4</b>	
	<b>DPM Dark Field (Laser-Etched 90 Degrees)</b>  M10377_01 <b>B1</b>	<b>DPM Diffuse Bright Field (Dot Peen 90 Degrees)</b>  M10382_01 <b>B2</b>	<b>DPM Diffuse Bright Field (Dot Peen/Laser-Etched 90 Degrees)</b>  M10376_01 <b>B3</b>	<b>DPM Diffuse Bright Field (Laser-Etched 90 Degrees)</b>  M10381_01 <b>B4</b>
	<b>DPM Curved Surface Mode (Dot Peen/Laser-Etched 90 Degrees)</b>  M10383_01 <b>C1</b>	<b>DPM Direct Bright Field (Paper Label)</b>  M10380_01 <b>C2</b>	<b>DPM Motion Detection Dark Field - Default</b>  M10384_01 <b>C3</b>	<b>DPM Motion Detection Diffuse Bright Field</b>  M10385_01 <b>C4</b>
	<b>DPM Motion Detection Direct Bright Field</b>  M10386_01 <b>D1</b>	<b>Continuous Scan Off - Default</b>		<b>Continuous Scan On</b>  M10012_02 <b>D3</b>
<b>Continuous Scan Off - Default</b>  M10011_01 <b>D4</b>	<b>Motion Detection On when In Stand and Trigger Out of Stand - Default</b>  M10403_02 <b>E1</b>	<b>Motion Detection On In and Out of Stand</b>  M10404_02 <b>E2</b>	<b>Optimize Motion Detection for Bright Environments - Default</b>  M10014_03 <b>E3</b>	
<b>Optimize Motion Detection for Dark Environments</b>  M10015_03 <b>E4</b>				

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>No Motion Detection Delay - Default</p>  <p>M10016_03</p> <p style="text-align: right;"><b>A1</b></p>	<p>500ms Motion Detection Delay</p>  <p>M10017_03</p> <p style="text-align: right;"><b>A2</b></p>	<p>Motion Detection Off In and Out of Stand</p>  <p>M10013_02</p> <p style="text-align: right;"><b>A3</b></p>	<p>Mirroring On</p>  <p>M10125_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>Mirroring Off - Default</p>  <p>M10124_02</p> <p style="text-align: right;"><b>B1</b></p>	<p>Targeting On - Default</p>  <p>M10153_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Targeting Off</p>  <p>M10154_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Intentionally Blank</p> <p style="text-align: right;"><b>B4</b></p>
<p style="text-align: center;"><b>Data Formatting (Prefix/Suffix) Settings</b></p>	<p>Turn on Timestamp Prefix</p>  <p>M10342_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>Turn off Timestamp Prefix - Default</p>  <p>M10343_02</p> <p style="text-align: right;"><b>C3</b></p>	<p>Convert output to lowercase</p>  <p>M10439_01</p> <p style="text-align: right;"><b>C4</b></p>
	<p>Erase Prefix &amp; Suffix Data - Default</p>  <p>M10135_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>Erase Prefix Data - Default</p>  <p>M10126_01</p> <p style="text-align: right;"><b>D2</b></p>	<p>Erase Suffix Data - Default</p>  <p>M10130_01</p> <p style="text-align: right;"><b>D3</b></p>
<p>Prefix AIM ID Off - Default</p>  <p>M10198_01</p> <p style="text-align: right;"><b>E1</b></p>	<p>Prefix Carriage Return Line Feed (RS232 Mode Only)</p>  <p>M10405_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>Prefix Comma</p>  <p>M10127_01</p> <p style="text-align: right;"><b>E3</b></p>	<p>Prefix Space</p>  <p>M10128_01</p> <p style="text-align: right;"><b>E4</b></p>




# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Prefix Tab (USB Keyboard Mode Only)</p>  <p>M10129_01</p> <p style="text-align: right;"><b>A1</b></p>	<p>Prefix Tab (RS232 Mode Only)</p>  <p>M10319_01</p> <p style="text-align: right;"><b>A2</b></p>	<p>Suffix Carriage Return (RS232 Mode Only)</p>  <p>M10320_01</p> <p style="text-align: right;"><b>A3</b></p>	<p>Suffix Carriage Return Line Feed (RS232 Mode Only)</p>  <p>M10322_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>Suffix Comma</p>  <p>M10131_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>Suffix Enter (USB Keyboard Mode Only)</p>  <p>M10134_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Suffix Line Feed (RS232 Mode Only)</p>  <p>M10321_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Suffix Space</p>  <p>M10132_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>Suffix Tab (USB Keyboard Mode Only)</p>  <p>M10133_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>Suffix Tab (RS232 Mode Only)</p>  <p>M10323_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>Translate all Characters to Uppercase On</p>  <p>M10220_03</p> <p style="text-align: right;"><b>C3</b></p>	<p>Translate all Characters to Uppercase Off - Default</p>  <p>M10426_02</p> <p style="text-align: right;"><b>C4</b></p>
<p><b>Symbology Settings</b></p>	<p>Australian Post On</p>  <p>M10288_02</p> <p style="text-align: right;"><b>D2</b></p>	<p>Australian Post Off - Default</p>  <p>M10289_02</p> <p style="text-align: right;"><b>D3</b></p>	<p>Aztec On - Default</p>  <p>M10018_01</p> <p style="text-align: right;"><b>D4</b></p>
	<p>Aztec Inverse On</p>  <p>M10020_01</p> <p style="text-align: right;"><b>E1</b></p>	<p>Aztec Inverse &amp; Normal On</p>  <p>M10021_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>Aztec Off</p>  <p>M10019_01</p> <p style="text-align: right;"><b>E3</b></p>

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Codabar Off</p>  <p>M10023_01</p> <p>A1</p>	<p>Remove Codabar Start and Stop Delimiters</p>  <p>M10537_01</p> <p>A2</p>	<p>Keep Codabar Start and Stop Delimiters - Default</p>  <p>M10538_01</p> <p>A3</p>	<p>Codablock F On</p>  <p>M10027_01</p> <p>A4</p>
<p>Codablock F Off - Default</p>  <p>M10026_01</p> <p>B1</p>	<p>Code 11 On</p>  <p>M10029_02</p> <p>B2</p>	<p>Code 11 Off - Default</p>  <p>M10028_02</p> <p>B3</p>	<p>Code 11 Checksum Stripped from Result On</p>  <p>M10031_02</p> <p>B4</p>
<p>Code 32 (Italian Pharmacode) On</p>  <p>M10239_02</p> <p>C1</p>	<p>Code 32 (Italian Pharmacode) Off - Default</p>  <p>M10238_02</p> <p>C2</p>	<p>Code 39 Off</p>  <p>M10034_02</p> <p>C3</p>	<p>Code 39 On - Default</p>  <p>M10033_02</p> <p>C4</p>
<p>Code 39 Checksum On</p>  <p>M10036_01</p> <p>D1</p>	<p>Code 39 Checksum Off - Default</p>  <p>M10035_01</p> <p>D2</p>	<p>Code 39 Checksum Stripped from Result On</p>  <p>M10037_01</p> <p>D3</p>	<p>Code 39 Extended Full ASCII Off - Default</p>  <p>M10038_01</p> <p>D4</p>
<p>Code 39 Extended Full ASCII On</p>  <p>M10039_01</p> <p>E1</p>	<p>Code 49 On</p>  <p>M10458_01</p> <p>E2</p>	<p>Code 49 Off - Default</p>  <p>M10459_01</p> <p>E3</p>	<p>Code 93 On - Default</p>  <p>M10042_01</p> <p>E4</p>

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Code 93 Off</p>  <p>M10043_01</p> <p>A1</p>	<p>Code 128 On</p>  <p>M10044_01</p> <p>A2</p>	<p>Code 128 Off</p>  <p>M10045_01</p> <p>A3</p>	<p>Composite On</p>  <p>M10047_02</p> <p>A4</p>
<p>Composite Off - Default</p>  <p>M10046_01</p> <p>B1</p>	<p>Data Matrix Inverse On - Default</p>  <p>M10051_03</p> <p>B2</p>	<p>Data Matrix Inverse Off</p>  <p>M10050_03</p> <p>B3</p>	<p>Data Matrix Rectangular On &amp; Rectangular Extended On</p>  <p>M10470_01</p> <p>B4</p>
<p>Data Matrix Rectangular On &amp; Rectangular Extended Off - Default</p>  <p>M10049_01</p> <p>C1</p>	<p>Data Matrix Rectangular &amp; Rectangular Extended Off</p>  <p>M10048_01</p> <p>C2</p>	<p>Grid Matrix On</p>  <p>M10535_01</p> <p>C3</p>	<p>Grid Matrix Off - Default</p>  <p>M10536_01</p> <p>C4</p>
<p>All GS1 DataBar On - Default</p>  <p>M10054_01</p> <p>D1</p>	<p>All GS1 DataBar Off</p>  <p>M10055_01</p> <p>D2</p>	<p>GS1 DataBar Limited On</p>  <p>M10056_03</p> <p>D3</p>	<p>GS1 DataBar Limited Off</p>  <p>M10354_02</p> <p>D4</p>
<p>GS1 DataBar Expanded On</p>  <p>M10059_03</p> <p>E1</p>	<p>GS1 DataBar Expanded Off</p>  <p>M10417_02</p> <p>E2</p>	<p>GS1 DataBar Expanded Stacked On</p>  <p>M10357_02</p> <p>E3</p>	<p>GS1 DataBar Expanded Stacked Off</p>  <p>M10356_02</p> <p>E4</p>

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional On</p>  <p>M10058_03</p> <p style="text-align: right;"><b>A1</b></p>	<p>GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional Off</p>  <p>M10353_03</p> <p style="text-align: right;"><b>A2</b></p>	<p>GS1 DataBar Omnidirectional and GS1 DataBar Truncated On</p>  <p>M10057_03</p> <p style="text-align: right;"><b>A3</b></p>	<p>GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off</p>  <p>M10355_02</p> <p style="text-align: right;"><b>A4</b></p>
<p>Han Xin On</p>  <p>M10248_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>Han Xin Off - Default</p>  <p>M10249_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Hong Kong 2 of 5 Off - Default</p>  <p>M10078_02</p> <p style="text-align: right;"><b>B3</b></p>	<p>Hong Kong 2 of 5 On</p>  <p>M10079_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>Int 2 of 5 On - Default</p>  <p>M10060_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>Int 2 of 5 Off</p>  <p>M10061_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>Int 2 of 5 Checksum Stripped from Result On</p>  <p>M10065_01</p> <p style="text-align: right;"><b>C3</b></p>	<p>Int 2 of 5 Checksum On</p>  <p>M10235_01</p> <p style="text-align: right;"><b>C4</b></p>
<p>Int 2 of 5 Checksum Off</p>  <p>M10234_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>Japan Post On</p>  <p>M10292_02</p> <p style="text-align: right;"><b>D2</b></p>	<p>Japan Post Off - Default</p>  <p>M10293_02</p> <p style="text-align: right;"><b>D3</b></p>	<p>KIX (Dutch Post) Code On</p>  <p>M10290_02</p> <p style="text-align: right;"><b>D4</b></p>
<p>KIX (Dutch Post) Code Off - Default</p>  <p>M10291_02</p> <p style="text-align: right;"><b>E1</b></p>	<p>Korean Post On</p>  <p>M10358_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>Korean Post Off - Default</p>  <p>M10359_01</p> <p style="text-align: right;"><b>E3</b></p>	<p>Maxicode On</p>  <p>M10067_02</p> <p style="text-align: right;"><b>E4</b></p>

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Maxicode Off - Default</p>  <p>M10066_01</p> <p>A1</p>	<p>Matrix 2 of 5 On</p>  <p>M10069_01</p> <p>A2</p>	<p>Matrix 2 of 5 Off - Default</p>  <p>M10068_01</p> <p>A3</p>	<p>Micro PDF417 On</p>  <p>M10073_01</p> <p>A4</p>
<p>Micro PDF417 Off - Default</p>  <p>M10072_01</p> <p>B1</p>	<p>MSI Plessey On</p>  <p>M10076_01</p> <p>B2</p>	<p>MSI Plessey Off - Default</p>  <p>M10077_01</p> <p>B3</p>	<p>NEC 2 of 5 On</p>  <p>M10082_01</p> <p>B4</p>
<p>NEC 2 of 5 Off - Default</p>  <p>M10083_01</p> <p>C1</p>	<p>PDF417 On - Default</p>  <p>M10070_01</p> <p>C2</p>	<p>PDF417 Off</p>  <p>M10071_01</p> <p>C3</p>	<p>Pharmacode On</p>  <p>M10275_02</p> <p>C4</p>
<p>Pharmacode Reverse Barcode Decoding (Right to Left)</p>  <p>M10280_02</p> <p>D1</p>	<p>Pharmacode Normal Barcode Decoding (Left to Right)</p>  <p>M10281_02</p> <p>D2</p>	<p>Pharmacode Off</p>  <p>M10274_03</p> <p>D3</p>	<p>All QR Code On</p>  <p>M10101_02</p> <p>D4</p>
<p>Standard QR Code On - Default</p>  <p>M10095_04</p> <p>E1</p>	<p>All QR Code Off</p>  <p>M10351_03</p> <p>E2</p>	<p>Straight 2 of 5 On</p>  <p>M10241_01</p> <p>E3</p>	<p>Straight 2 of 5 Off - Default</p>  <p>M10240_01</p> <p>E4</p>



















# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Telepen On</p>  <p>M10103_01</p> <p style="text-align: right;"><b>A1</b></p>	<p>Output Telepen as ASCII</p>  <p>M10521_01</p> <p style="text-align: right;"><b>A2</b></p>	<p>Output Telepen as Numeric - Default</p>  <p>M10520_01</p> <p style="text-align: right;"><b>A3</b></p>	<p>Telepen Off - Default</p>  <p>M10104_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>Trioptic On</p>  <p>M10041_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>Trioptic - Enable Reverse Order option (Bit 3)</p>  <p>M10446_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Trioptic - Disable Reverse Order option (Bit 3) - Default</p>  <p>M10445_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Trioptic Off - Default</p>  <p>M10040_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>UK Plessey On</p>  <p>M10237_02</p> <p style="text-align: right;"><b>C1</b></p>	<p>UK Plessey Off - Default</p>  <p>M10236_02</p> <p style="text-align: right;"><b>C2</b></p>	<p>UK Royal Mail On</p>  <p>M10294_02</p> <p style="text-align: right;"><b>C3</b></p>	<p>UK Royal Mail Off - Default</p>  <p>M10295_02</p> <p style="text-align: right;"><b>C4</b></p>
<p>UPC Off</p>  <p>M10106_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>UPC On - Default</p>  <p>M10105_01</p> <p style="text-align: right;"><b>D2</b></p>	<p>UPC Supplemental On</p>  <p>M10110_01</p> <p style="text-align: right;"><b>D3</b></p>	<p>Transmit UPC-A Number System Off</p>  <p>M10478_01</p> <p style="text-align: right;"><b>D4</b></p>
<p>UPC Supplemental Off - Default</p>  <p>M10109_01</p> <p style="text-align: right;"><b>E1</b></p>	<p>Transmit UPC-A Check Digit On - Default</p>  <p>M10475_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>Transmit UPC-A Check Digit Off</p>  <p>M10476_01</p> <p style="text-align: right;"><b>E3</b></p>	<p>Transmit UPC-A Number System On - Default</p>  <p>M10477_01</p> <p style="text-align: right;"><b>E4</b></p>




















# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Convert UPC-A to EAN-13 On</p>  <p>M10490_01</p> <p style="text-align: right;"><b>A1</b></p>	<p>Convert UPC-A to EAN-13 Off - Default</p>  <p>M10489_01</p> <p style="text-align: right;"><b>A2</b></p>	<p>UPC-E Expansion On</p>  <p>M10108_01</p> <p style="text-align: right;"><b>A3</b></p>	<p>UPC-E Expansion Off - Default</p>  <p>M10107_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>Transmit UPC-E Check Digit On - Default</p>  <p>M10479_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>Transmit UPC-E Check Digit Off</p>  <p>M10480_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Transmit UPC-E Number System On - Default</p>  <p>M10481_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Transmit UPC-E Number System Off</p>  <p>M10482_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>Transmit EAN-8 Check Digit On - Default</p>  <p>M10485_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>Transmit EAN-8 Check Digit Off</p>  <p>M10486_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>Convert EAN-8 to EAN-13 On</p>  <p>M10488_01</p> <p style="text-align: right;"><b>C3</b></p>	<p>Convert EAN-8 to EAN-13 Off - Default</p>  <p>M10487_01</p> <p style="text-align: right;"><b>C4</b></p>
<p>Transmit EAN-13 Check Digit On - Default</p>  <p>M10483_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>Transmit EAN-13 Check Digit Off</p>  <p>M10484_01</p> <p style="text-align: right;"><b>D2</b></p>	<p>Convert Bookland EAN-13 to ISBN On</p>  <p>M10492_01</p> <p style="text-align: right;"><b>D3</b></p>	<p>Convert Bookland EAN-13 to ISBN Off - Default</p>  <p>M10491_01</p> <p style="text-align: right;"><b>D4</b></p>
<p>Convert Bookland EAN-13 to ISSN On</p>  <p>M10494_01</p> <p style="text-align: right;"><b>E1</b></p>	<p>Convert Bookland EAN-13 to ISSN Off - Default</p>  <p>M10493_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>UPU ID-Tag On</p>  <p>M10360_02</p> <p style="text-align: right;"><b>E3</b></p>	<p>UPU ID-Tag Off - Default</p>  <p>M10361_02</p> <p style="text-align: right;"><b>E4</b></p>

# CR6000 Configuration Guide




















NOTE: Configuration changes will take effect immediately and be saved to memory

















<p>USPS Intelligent Mail/IMB/ 4-State CB On</p>  <p>M10286_02</p> <p style="text-align: right;"><b>A1</b></p>	<p>USPS Intelligent Mail/IMB/ 4-State CB Off - Default</p>  <p>M10287_02</p> <p style="text-align: right;"><b>A2</b></p>	<p>USPS Planet On</p>  <p>M10284_02</p> <p style="text-align: right;"><b>A3</b></p>	<p>USPS Planet Off - Default</p>  <p>M10285_02</p> <p style="text-align: right;"><b>A4</b></p>
<p>USPS Postnet On</p>  <p>M10282_02</p> <p style="text-align: right;"><b>B1</b></p>	<p>USPS Postnet Off - Default</p>  <p>M10283_02</p> <p style="text-align: right;"><b>B2</b></p>	<p>Grid Matrix &amp; Grid Matrix Inverse Decoding On</p>  <p>M10544_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Grid Matrix &amp; Grid Matrix Mirror Decoding On</p>  <p>M10545_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>Grid Matrix, Grid Matrix Inverse &amp; Grid Matrix Mirror Decoding</p>  <p>M10546_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>GoCode &amp; GoCode Inverse Decoding</p>  <p>M10547_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>GoCode &amp; GoCode Mirror Decoding On</p>  <p>M10548_01</p> <p style="text-align: right;"><b>C3</b></p>	<p>GoCode, GoCode Inverse &amp; GoCode Mirror Decoding On</p>  <p>M10549_01</p> <p style="text-align: right;"><b>C4</b></p>
<p>Code 11 Decoding with one checksum digit checked, and remove checksum from output On</p>  <p>M10550_01</p> <p style="text-align: right;"><b>D1</b></p>	<p style="text-align: center;"><b>Keyboard Support: USInternational (Universal) Keyboard Mapping for Windows</b></p>	<p>Keyboard Support: French Keyboard Mapping for Apple</p>  <p>M10420_02</p> <p style="text-align: right;"><b>D3</b></p>	<p>Keyboard Support: USInternational (Universal) Keyboard Mapping for Windows</p>  <p>M10469_01</p> <p style="text-align: right;"><b>D4</b></p>
<p>English (US) Keyboard Mapping for Windows</p>  <p>M10460_02</p> <p style="text-align: right;"><b>E1</b></p>	<p>English (UK) Keyboard Mapping for Windows</p>  <p>M10471_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>Belgian French Keyboard Mapping for Windows</p>  <p>M10461_02</p> <p style="text-align: right;"><b>E3</b></p>	<p>French Keyboard Mapping for Windows</p>  <p>M10462_02</p> <p style="text-align: right;"><b>E4</b></p>



# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>German Keyboard Mapping for Windows</p>  <p>M10463_02 <b>A1</b></p>	<p>Japanese Keyboard Mapping for Windows</p>  <p>M10464_02 <b>A2</b></p>	<p>Latin American Keyboard Mapping for Windows</p>  <p>M10465_02 <b>A3</b></p>	<p>Spanish Keyboard Mapping for Windows</p>  <p>M10472_01 <b>A4</b></p>
<p>Swiss German Keyboard Mapping for Windows</p>  <p>M10466_02 <b>B1</b></p>	<p>English Keyboard Mapping for Apple</p>  <p>M10419_02 <b>B2</b></p>	<p>Keyboard Support: Spanish Keyboard Mapping for Apple</p>  <p>M10424_02 <b>B3</b></p>	<p>Italian Keyboard Mapping for Apple</p>  <p>M10423_02 <b>B4</b></p>
<p>German-Swiss Keyboard Mapping for Apple</p>  <p>M10422_02 <b>C1</b></p>	<p>German Keyboard Mapping for Apple</p>  <p>M10421_02 <b>C2</b></p>	<p>Russian Keyboard Mapping for Windows</p>  <p>M10418_02 <b>C3</b></p>	<p>Control Character Input - Ctrl + Character</p>  <p>M10442_01 <b>C4</b></p>
<p>Control Character Input - Alt + Keypad</p>  <p>M10443_01 <b>D1</b></p>	<p>Control Character Input -Alt + Leading Zero</p>  <p>M10444_01 <b>D2</b></p>	<p>Control Character Input - Language - Default</p>  <p>M10441_01 <b>D3</b></p>	<p>Data Encoding: Raw ASCII to Keyboard XML File Lookup - Default</p>  <p>M10514_01 <b>D4</b></p>
<p>Data Encoding: UTF8 to Unicode Codepoint - Alt Sequences for Windows</p>  <p>M10515_01 <b>E1</b></p>	<p>Shift-JIS Mode for Japanese Windows OS</p>  <p>M10552_02 <b>E2</b></p>	<p>Shift-JIS Mode for English Windows OS</p>  <p>M10553_01 <b>E3</b></p>	<p>Intentionally Blank</p> <p><b>E4</b></p>

Operating System Settings	Alternative Operating System (Linux/Mac) On	Alternative Operating System (Linux/Mac) Off - Default	Intentionally Blank
	 M10123_02 <b>A2</b>	 M10122_02 <b>A3</b>	<b>A4</b>
USB Settings	Reader - USB Virtual COM CDC Raw Mode	Reset to USB Factory Defaults	USB Keyboard Mode
	 M10438_01 <b>B2</b>	 M10002_02 <b>B3</b>	 M10200_01 <b>B4</b>
USB Downloader Mode	USB HID POS Mode (Terminal ID 131)	USB Native Two Way Mode	USB Virtual COM One Way Mode
 M10004_02 <b>C1</b>	 M10425_01 <b>C2</b>	 M10006_02 <b>C3</b>	 M10005_01 <b>C4</b>
USB Virtual COM Multiple Ports	USB Virtual COM Common Ports	USB Speed High Speed - Default	USB Speed Full Speed
 M10431_01 <b>D1</b>	 M10432_01 <b>D2</b>	 M10160_01 <b>D3</b>	 M10161_01 <b>D4</b>
RS232 Settings	Reader - Enable RS232 OPOS/IPOS	Reset to RS232 Factory Defaults	RS232 Interface 1200 Baud Rate
	 M10467_01 <b>E2</b>	 M10389_03 <b>E3</b>	 M10392_01 <b>E4</b>

# CR6000 Configuration Guide






NOTE: Configuration changes will take effect immediately and be saved to memory

<p>RS232 Interface 2400 Baud Rate</p>  <p>M10393_01</p> <p style="text-align: right;"><b>A1</b></p>	<p>RS232 Interface 4800 Baud Rate</p>  <p>M10394_01</p> <p style="text-align: right;"><b>A2</b></p>	<p>RS232 Interface 9600 Baud Rate</p>  <p>M10395_01</p> <p style="text-align: right;"><b>A3</b></p>	<p>RS232 Interface 19200 Baud Rate</p>  <p>M10396_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>RS232 Interface 38400 Baud Rate</p>  <p>M10397_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>RS232 Interface 57600 Baud Rate</p>  <p>M10398_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>RS232 Interface 115200 Baud Rate - Default</p>  <p>M10399_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>RS232 Interface 7 Data Bits</p>  <p>M10390_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>RS232 Interface 8 Data Bits - Default</p>  <p>M10391_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>RS232 Interface Stop Bits 1 - Default</p>  <p>M10406_01</p> <p style="text-align: right;"><b>C2</b></p>	<p>RS232 Interface Stop Bits 2</p>  <p>M10407_01</p> <p style="text-align: right;"><b>C3</b></p>	<p>RS232 Interface Even Parity</p>  <p>M10400_01</p> <p style="text-align: right;"><b>C4</b></p>
<p>RS232 Interface Odd Parity</p>  <p>M10401_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>RS232 Interface No Parity - Default</p>  <p>M10402_01</p> <p style="text-align: right;"><b>D2</b></p>	<p>RS232 Interface Flow Control Off - Default</p>  <p>M10408_01</p> <p style="text-align: right;"><b>D3</b></p>	<p>RS232 Interface Flow Control - Hardware</p>  <p>M10409_01</p> <p style="text-align: right;"><b>D4</b></p>
<p>RS232 Packet Mode</p>  <p>M10388_02</p> <p style="text-align: right;"><b>E1</b></p>	<p>RS232 Raw Mode - Default</p>  <p>M10387_01</p> <p style="text-align: right;"><b>E2</b></p>	<p><b>Reader Feedback Settings</b></p>	
			<p>Beep On Vibrate On - Default</p>  <p>M10140_01</p> <p style="text-align: right;"><b>E4</b></p>

# CR6000 Configuration Guide

NOTE: Configuration changes will take effect immediately and be saved to memory

<p>Beep Off Vibrate Off</p>  <p>M10143_02</p> <p style="text-align: right;"><b>A1</b></p>	<p>Beep Off Vibrate On</p>  <p>M10141_02</p> <p style="text-align: right;"><b>A2</b></p>	<p>Beep On Vibrate Off</p>  <p>M10142_01</p> <p style="text-align: right;"><b>A3</b></p>	<p>Beep Volume 100% - Default</p>  <p>M10197_01</p> <p style="text-align: right;"><b>A4</b></p>
<p>Beep Volume 67%</p>  <p>M10196_01</p> <p style="text-align: right;"><b>B1</b></p>	<p>Beep Volume 33%</p>  <p>M10195_01</p> <p style="text-align: right;"><b>B2</b></p>	<p>Beep Volume 0%</p>  <p>M10194_01</p> <p style="text-align: right;"><b>B3</b></p>	<p>Output Good Read on RTS line Off - Default</p>  <p>M10522_01</p> <p style="text-align: right;"><b>B4</b></p>
<p>Output Good Read on RTS line - Active Low</p>  <p>M10523_01</p> <p style="text-align: right;"><b>C1</b></p>	<p>Output Good Read on RTS line - Active High</p>  <p>M10524_01</p> <p style="text-align: right;"><b>C2</b></p>	<p><b>Scan Delay Settings</b></p>	<p>Duplicate Scan Disabled - Default</p>  <p>M10144_01</p> <p style="text-align: right;"><b>C4</b></p>
<p>1 Second Duplicate Scan Delay</p>  <p>M10145_01</p> <p style="text-align: right;"><b>D1</b></p>	<p>2 Second Duplicate Scan Delay</p>  <p>M10146_01</p> <p style="text-align: right;"><b>D2</b></p>	<p>3 Second Duplicate Scan Delay</p>  <p>M10147_01</p> <p style="text-align: right;"><b>D3</b></p>	<p>5 Second Duplicate Scan Delay</p>  <p>M10148_01</p> <p style="text-align: right;"><b>D4</b></p>
<p>10 Second Duplicate Scan Delay</p>  <p>M10149_01</p> <p style="text-align: right;"><b>E1</b></p>	<p>30 Second Duplicate Scan Delay</p>  <p>M10150_01</p> <p style="text-align: right;"><b>E2</b></p>	<p>1 Hour Duplicate Scan Delay</p>  <p>M10151_01</p> <p style="text-align: right;"><b>E3</b></p>	<p>1 Day Duplicate Scan Delay</p>  <p>M10152_01</p> <p style="text-align: right;"><b>E4</b></p>

Miscellaneous Settings	Locked Reader Accept Host Commands - Default	Locked Reader Reject Host Commands	Intentionally Blank
	 M10527_01	 M10528_01	
	A2	A3	A4
Reader/Modem Command Settings	Reader ID and Firmware Version	Reader Text Commands On	Reader Text Commands Off - Default
	 M10157_01	 M10137_01	 M10136_01
	B2	B3	B4
Reset, Clear and Save Reader Settings	Clear All JavaScript Rules	Clear All Stored Data and Images	Save All Reader Settings
	 M10139_02	 M10138_02	 M10159_01
	C2	C3	C4
Reboot Reader	Intentionally Blank	Intentionally Blank	Intentionally Blank
 M10296_01			
D1	D2	D3	D4
Intentionally Blank	Intentionally Blank	Intentionally Blank	Intentionally Blank
E1	E2	E3	E4