



- (1) PLACE DRIP SHIELD ON ENCLOSURE AND MARK DRILLING LOCATIONS.
- (2) REMOVE DRIP SHIELD AND DRILL HOLES USING A 9/32" DIAMETER DRILL BIT.
- (3) REMOVE ANY BURRS AND TOUCH UP WITH PAINT.
- (4) INSTALL DRIP SHIELD UTILIZING HARDWARE PROVIDED AS SHOWN ABOVE.

REPLACES DWG.# MS820524

—NOTICE—
 This drawing is the property of WIEGMANN
 A Division of Hubbell Incorporated
 (Delaware). It is loaned to you and must
 not be used in any way detrimental to
 the interests of WIEGMANN.



WIEGMANN

FREEBURG, ILLINOIS, USA

PART NUMBER 33023		DESCRIPTION: DRIP SHIELD INSTALLATION FOR DK12 THRU DK72	
TOLERANCES (EXCEPT AS NOTED)		DRAWN BY: SLS	
DECIMAL	± .031"	CHK'D BY: HJL	REL. PROD:
FRACTIONAL	± 1/32"	APP'D BY: HJL	REL. DESIGN: 11/19/97
ANGULAR	± 1/2°	MATERIAL:	SCALE: NONE
		DWG. NO. HW00068	REV. —
		PROJECT:	SHEET 1 OF 1