


SECTION X-X


SECTION Y-Y

THE MINIMUM AMOUNT FOR THIS DIMENSION DEPENDS ON THE STYLE OF THE ENCLOSURE (MAKE CERTAIN THAT THE HOLES DO NOT INTERFERE WITH CLAMPS, HINGE, ETC.)



1. DETERMINE THE BEST POSITION FOR MOUNTING THE SWING PANEL SO THAT THE BRACKETS DO NOT INTERFERE WITH ANY CLAMPS, LATCHES, OR THE HINGE.
2. THE PANEL CAN BE HINGED IN EITHER DIRECTION. DRILL EIGHT HOLES .188 DIA. IN THE LOCATIONS SHOWN. USE THESE HOLES TO MOUNT THE BRACKETS USING PAN HEAD SCREWS WITH PLASTIC WASHERS BENEATH THE SCREW HEADS.
3. SECURE THE PANEL TO THE BRACKETS USING THE SCREWS AND LOCKWASHERS PROVIDED. BE CERTAIN THAT THE PANEL DOES NOT INTERFERE WITH THE OPENING OF THE ENCLOSURE.
4. INSTALL THE THUMB SCREWS THROUGH THE PANEL AND SECURE THEM WITH THE RETAINING RINGS PROVIDED.

**-NOTICE-**  
 This drawing is the property of WIEGMANN a division of Hubbell incorporated (Delaware). It is loaned to you and must not be used in any way detrimental to the interests of WIEGMANN.

 <b>WIEGMANN</b> FREEBURG, ILLINOIS, USA	
PART NUMBER WAJCDFK	DESCRIPTION: DEAD FRONT KIT INSTALLATION INSTRUCTIONS
TOLERANCES (EXCEPT AS NOTED)	DRAWN BY: TLW    REL PROD:
DECIMAL $\pm .031"$	CHK'D BY: HJL    REL DESIGN: 11/29/99
FRACTIONAL $\pm 1/32"$	APP'D BY: HJL    SCALE: NONE
ANGULAR $\pm 1/2^\circ$	MATERIAL:    DWG. NO.    REV.
	PROJECT:    SHEET 1 OF 1