



WIEGMANN
FREEBURG, ILLINOIS, USA

HUBBELL ELECTRICAL PRODUCTS
A Division of HUBBELL
INCORPORATED (Delaware)
501 West Apple
Freeburg, IL 62243 USA
For Customer Service: 618-539-3193

DWG. NO. HWIHF33025

P.N. HFW33025

DATE 7/9/14

AFFECTED P.N. WA7230SOF19, WA7236SOF19, WA9036SOF19


INSTALLATION, OPERATION, & MAINTENANCE DATA SHEET

CAUTION: Before installing, make sure you are compliant with area classifications - as failure to do so may result in bodily injury, death and property damage. Do not attempt installation until you are familiar with the following procedures. All installation must comply with the applicable Electrical Code(s). Make sure that all supply circuits are de-energized before starting installation or maintenance. Verify that the installation is grounded. Failure to ground will create electrical shock hazards, which can cause serious injury and or death.

Important: Please read these instructions carefully before installing or maintaining this equipment. Safe electrical practices should be followed at all times and this data should be used as a guide only. Maintain the environmental integrity of this enclosure by closing all openings w/UL listed or recognized components that have the same environmental rating as the enclosure.

INSTRUCTIONS:

1. SLIDE SPRING NUTS INTO TOP AND BOTTOM MOUNTING CHANNELS OF ENCLOSURE (2 PER CHANNEL).
2. INSTALL BOTTOM SUPPORT TO THE BOTTOM MOUNTING CHANNELS AS SHOWN BELOW (SHIM AS NEEDED).
3. INSTALL THE NYLON WASHER ON THE SWING POST AS SHOWN.
4. USING TWO PEOPLE INSTALL THE SWING FRAME ONTO THE BOTTOM SUPPORT BY SETTING THE BOTTOM SWING FRAME MOUNTING HOLE OVER THE BOTTOM SWING POST.
5. WHILE ONE PERSON IS HOLDING SWING FRAME IN PLACE, INSTALL THE TOP SUPPORT BY FIRST INSERTING THE TOP SWING POST INTO THE TOP SWING FRAME MOUNTING HOLE. THEN BOLT THE TOP SUPPORT TO THE SPRING NUTS AS SHOWN BELOW (SHIM AS NEEDED).
6. INSURE THAT ALL BOLTS ARE PROPERLY INSTALLED, TIGHTENED DOWN USING A 9/16" WRENCH (OR EQUIVALENT), AND LOCK WASHERS ARE COMPRESSED.



TOOLS NEEDED:

9/16" WRENCH OR EQUIVALENT

KIT INCLUDES

- 1) SWING FRAME
- 1) BOTTOM SUPPORT
- 1) TOP SUPPORT
- 1) NYLON WASHER
- 6) SHIMS
- 8) 3/8-16 SPRING NUT
- 8) 3/8-16 X 1 BOLTS
- 8) INTERNAL STAR LOCK WASHER
- 8) FLAT WASHER