Absolute Encoder Series

TRD-NA OPERATION MANUAL

Thank you for purchasing this Series TRD-NA Absolute Encoder. Please read this Operation Manual carefully before applying this product.

KEEP THIS MANUAL IN A SAFE PLACE.



Sales: 800-633-0405 Tech Support: 770-844-4200

TRD-NA_DS - 2nd Ed, Rev D - 07/2019 - sheet 1 of 1 ES-M0220-5

■ Safety Considerations



When you see the "exclamation mark" icon in the left-hand margin, the paragraph to its immediate right will be a WARNING. This information could prevent injury, loss of property, or even death (in extreme cases)



When you see the "notepad" icon in the left-hand margin, the PARAGRAPH TO ITS IMMEDIATE RIGHT WILL BE A SPECIAL NOTE WHICH PRESENTS INFORMATION THAT MAY MAKE YOUR WORK QUICKER OR

WARNINGS: Operating environment and conditions



Do not use in a combustible or explosive atmosphere. Otherwise personal injury or fire may be caused.



Do not use this product for applications related to human safety. Use is assumed in an application where an accident or incorrect use will not immediately cause danger to humans.

CAUTIONS: Operating environment and conditions



USE AND STORE THE EQUIPMENT WITHIN THE SCOPE OF THE ENVIRON-MENT (VIBRATIONS, IMPACT, TEMPERATURE, HUMIDITY, ETC.) SPECIFIED IN THE SPECIFICATIONS. OTHERWISE FIRE OR PRODUCT DAMAGE MAY BE



READ THIS OPERATION MANUAL, AND UNDERSTAND THIS PRODUCT

WARNINGS: Installation and Wiring



Use only with the power supply voltage listed in the specifications. Otherwise fire, electric shock, or accidents may be caused.



Use only with the wiring and layout specified in the specifications. Otherwise fire, electric shock, or accidents may be caused.



Do not apply any kind of stress to the wires. Otherwise fire or electric shock may be caused.

- Floctrical Specifications

Electrical	Specifications	TRD-NAxxxxNWD
Power Supply	Operating voltage *	10.8–26.4 VDC
	Allowable ripple	3% rms max
	Current consumption	70mA max
Output Waveform	Output code **	Gray binary
	Max response frequency	20kHz
	Operating speed	(Maximum response frequency / resolution) x 60 or 3000 rpm, whichever is less
	Accuracy	(360 / (resolution x 2)) degrees
	Rotation direction***	Normal: clockwise (cw) Reversed: counterclockwise (ccw)
Output	Rising/falling time ****	2.0 μs max (@ 1kΩ load resistance)
	Output configuration	NPN open collector
	Output logic	Negative logic (active low)
	Sinking current	32mA max
	Residual voltage	0.4 V max @ ≤16mA 1.5 V max @ >16mA to 32mA
	Load power supply voltage	35VDC max
	Short-circuit protection	Not protected

To be supplied by a class II source.

Resolution: 180 Excess gray codes: 38 Resolution: 360 Excess gray codes: 76 Resolution: 720 Excess gray codes: 152

As viewed looking from the shaft. *** With a cable of 2m or less

Pin

■ Mechanical Specifications

Mechanical Specifications						
Starting torque	Э	0.03 N•m (20°C) max				
Shaft Moment	of Inertia	2x10 ⁻⁶ kg•m ²				
Max allowable	Radial	50N				
shaft load	Axial	30N				
Max allowable	speed *	3000 rpm (continuous) 5000 rpm (momentary)				
Cable conduc	tor size	26 AWG				
Weight **		approx 300g [10.6 oz]				
M3 screws tor	que	0.45 N•m [4.0 lb•in]				

Highest speed that can support mechanical integrity of the encoder.

With 2m cable.

■ Environmental Specifications

•				
Environmental Conditions				
Ambient Temperature	Operation	-10 to 60 °C [14 to 140 °F]		
	Store	-25 to 85 °C [-13 to 185 °F]		
Ambient Humidity		25 to 85 %RH (non-condensing)		
Insulation Resistance		10MΩ min		
Vibration Resistance *		10 to 55 Hz with 0.75 mm half amplitude		
Shock Resistance **		11ms with 980 m/s ²		
Mounting Orientation		Can be mounted in any orientation		
Protective Construction		IP65		
Agency Approvals		_C UL _{US} (E189395)		
* Durable for one (d) hour clone 2 even (Net averanteed for continuous von				

Durable for one (1) hour along 3 axes. (Not guaranteed for continuous use.) Applied 3 times 3 axes. (Not guaranteed for continuous use.)

■ WARNINGS for Use

- Do not wire the cable in parallel with other power lines, and do not share a wiring duct with other cables
- · Use capacitors or surge absorption elements to remove the sparks caused by relays and switches in the control panel • Connect all wires properly. (Incorrect wiring can damage the internal circuitry.)
- - Erroneous pulses may be caused at the time of power ON and power OFF. After power ON, wait at least a 0.5 second before use. • Do not dissasemble the product.

 - · Use care when handling and mounting the rotary encoder. (It is made of precision components that can be damaged by physical

Wire color 1024 / 720 | 512 / 360 | 256 / 180 32 2048 Blue 0V Brown 2 12/24V Black 3 bit 0 (2⁰) * bit 0 (20) * no connection 4 bit 1 (2¹) bit 0 (2⁰) bit 1 (2¹) Red no connection 5 bit 2 (2²) * bit 2 (2²) * bit 1 (2¹) * bit 0 (2⁰) Orange **Yellow** bit 3 (2^3) * bit 3 (23) * bit 2 (2²) * bit 1 (2¹) * bit 0 (2⁰) 6 no connection bit 4 (24) * bit 4 (24) * bit 3 (2³) * bit 2 (2²) * bit 1 (2¹) * bit 0 (2⁰) * no connection Green bit 5 (2⁵) * bit 5 (2⁵) * bit 2 (2²) * bit 1 (2¹) * bit 0 (2⁰) * **Purple** Gray 9 bit 6 (2⁶) * bit 6 (26) 3 bit 5 (2⁵) * bit 4 (2⁴) * bit 3 (2³) * bit 2 (2²) * bit 1 (2¹) * White 10 bit 7 (2⁷) * bit 7 (2⁷) * bit 6 (2⁶) * bit 5 (2⁵) * bit 4 (2⁴) * bit 3 (2³) * bit 2 (2²) * Black / White bit 8 (28) * bit 8 (28) * oit 7 (2⁷) * bit 6 (2⁶) * bit 5 (2⁵) * bit 4 (2⁴) * bit 3 (2³) * bit 9 (2⁹) bit 8 (2⁸) bit 7 (2⁷) bit 6 (2⁶) bit 5 (2⁵) bit 4 (2⁴) Red / White bit 9 (2⁹) *

(MSB)

Wiring Connections

Resolution

Numbers in parentheses () are the bits corresponding to binary code.

(MSB)

GND (cable shield) is not connected to encoder body;

bit 10 (2¹⁰)


Orange / White 13

Shield

■ Dimensions – (dimensions = mm [in])

Visit www.AutomationDirect.com for drawings of each part number.

■ Dimensions - TRD-NA Encoder



(MSB)

no connection

(MSB)


(MSB)


(MSB)

the enclosure is grounded through the OVDC line.


Dimensions

JT-035D Mounting Bracket






■ Dimensions NM-9D Mounting Clamp *




■ Dimensions - NF-55D Flange *




* NF-55D flange & included NM-9D bracket: Requires (3) M4 x 0.7 tapped holes equally spaced on a 64mm bolt circle in the mounting surface

■ Index Position



■ Wiring Connections



* Cable shield is not connected to the encoder body; enclosure is grounded through the 0V wire

■ Output Circuit

