

Contents

About This Manual

How to Use This Manual Set	vii
Document Conventions.....	vii
Technical Support	viii
Phone	viii
World Wide Web.....	viii

Chapter 1

Expressions

Creating Expressions	1-3
Data Polymorphism	1-3
Path Names in LookoutDirect	1-6
Expressions on Control Panels	1-8
Expression Objects	1-10
Expressions as Parameters.....	1-11
Expressions as Connections	1-12
Edit/Insert Expression Dialog Box	1-12
Expression Syntax.....	1-14
White Space.....	1-14
Arithmetic Operators	1-15
Text Operator.....	1-15
Comparison Operators.....	1-15
Expression Functions	1-18
Logical Functions	1-18
Lookup Functions	1-20
Mathematical Functions	1-21
Statistical Functions.....	1-24
Text Functions	1-26
Trigonometric Functions	1-29
Date/Time Functions	1-31
Quality Functions	1-31

Chapter 2

Graphics

Setting Snap to Grid.....	2-1
Static Graphics	2-2
Displaying Text, Plates, Insets, Rectangles, and Lines	2-2
Displaying Static Custom Graphics.....	2-4

- Dynamic Graphics.....2-6
 - Displaying Dynamic Logical Signals2-7
 - Displaying Dynamic Numeric Signals2-10
 - Displaying Dynamic Text Signals2-12
- Finding a Lost Graphics File.....2-13
- Creating Custom Graphics2-14
 - Creating Custom Graphics Example2-14
 - Creating the Graphic2-14
 -2-16
 - Save or Export the Graphic and Place in LookoutDirect2-16
 - Testing the Graphic in LookoutDirect2-16
- Graphic File Types.....2-18
 - Bitmaps.....2-18
 - Metafiles2-18
 - Bitmaps or Metafiles?.....2-18
 - Memory Considerations.....2-19

Chapter 3

Serial Port Communication Service

- Introduction to Driver Objects3-1
- Understanding the Communication Service3-2
- Defining Serial Port Settings.....3-3
 - Selecting the Serial Port.....3-3
 - Setting Receive Gap3-3
 - Selecting the Serial Connection.....3-4
 - Hardwired Settings3-4
 - RTS/CTS Handshaking Settings3-4
 - Dial-Up Modem Settings3-5
 - Serial Port Hangup.....3-7
- Serial Port Diagnostics.....3-7

Chapter 4

Networking

- Registering Computers.....4-2
- Logging Data.....4-3
 - Time Synchronization.....4-3
- Checking the Network Connection between Two Computers.....4-6

Chapter 5

Dynamic Data Exchange

- Linking LookoutDirect to Other Applications.....5-2
 - DDE Server Example5-2

DDE Client Example	5-3
DDE Peer-to-Peer Example.....	5-4
DDE Alarms	5-5

Chapter 6 Security

Logging On	6-2
User Manager.....	6-4
Creating User Accounts.....	6-5
Creating Groups.....	6-6
Modifying Users and Groups	6-7
Special Users and Groups.....	6-8
Control Security	6-9
Viewing Security	6-10
Control Panels	6-10
Controllable Objects	6-10
System Security Settings	6-11
Network Security	6-12
Configuring Security for Processes and Objects	6-12
Permissions	6-12
Advanced Security	6-15
Keeping Security Precedence Simple	6-18
Process File Edit Security	6-19
Action Verification	6-20
Importing Old Security Files into LookoutDirect 4.....	6-21

Chapter 7 Logging Data and Events

Spreadsheet Logger.....	7-1
Data Location	7-2
CSV Files.....	7-3
File and Disk Errors.....	7-3
Concurrent File Access.....	7-4
Information Overload	7-4
Citadel Historical Database	7-5
Default Data Location	7-5
Process Data Location	7-6
Creating a Historical Database	7-7
Logging Criteria	7-9
Alarm Information Overload	7-9
Event Logger.....	7-10
Event Data Location	7-10
Event Information Overload.....	7-10

Report Generation7-11
 Control Panel Reports.....7-11
 Third-Party Reports7-13

Chapter 8
Structured Query Language

Introduction8-1
 What is ODBC?8-1
 What is SQL?.....8-1
Creating a Citadel ODBC Data Source8-2
Accessing Citadel Data8-5
 Traces Table.....8-5
 Points Table8-6
 Data Transforms8-6
 SQL Examples8-7
 Accessing Citadel Data with Microsoft Query8-8
 Accessing Citadel Data with Microsoft Excel.....8-13
 Accessing Citadel Data with Microsoft Access.....8-13
Accessing Citadel Data with Visual Basic8-17

Chapter 9
Alarms and Events

Defining Alarm Conditions.....9-1
 Database-Generated Alarms9-1
 Alarm Objects9-2
The Alarm Subsystem.....9-4
 Selecting Processes to Monitor for Alarms9-4
 Alarm Areas.....9-4
 Alarm Priorities9-6
 Alarm Window9-6
 Alarm Display Options9-7
 Alarm Filters.....9-8
 Alarm Print9-10
 Alarm Acknowledgment.....9-11
 Acknowledging Alarms Programatically9-13

Chapter 10
Redundancy

Standby Basics10-2
 Failover Scenarios10-3
Configuring Standby10-4
 Enabling File Sharing in Windows 98/95 and Windows NT10-4

Time Synchronization with Standby Computers.....	10-5
Implementing Redundancy	10-6
Redundancy Overview	10-6
Setting up the Primary Process and Computer	10-6
Setting up the Standby Process and Computer.....	10-9
Configuring Clients for Standby Operation	10-11

Chapter 11

Editing Object Databases

Editing Database Parameters	11-1
Numeric Member Parameters.....	11-4
Logical Member Parameters.....	11-7
Text Member Parameters	11-8
Importing and Exporting Object Databases.....	11-9
Exporting an Object Database	11-9
Creating a Database Spreadsheet.....	11-11
Importing an Object Database	11-13
Copying an Object Database	11-15

Glossary

Appendix A

Networking With DDE

NetDDE Networking Considerations	A-2
Multilink NetDDE Networking	A-3
Linking Controllable Objects	A-3
Linking Controllable Objects Together Across a Network	A-3
Linking Non-Controllable Objects	A-4
To Access Real-Time Data at Another Computer	A-4
Table Networking	A-6
Hardware Networking.....	A-10
Multilink and Table Networking Comparison	A-11
Setting up Networking with DDE.....	A-12
Running NETDDE.EXE Automatically.....	A-12
Windows 98/95	A-12
Windows NT	A-12
Adding a Trusted DDE Share.....	A-13

Appendix B

CBL Compiler

CBL Compiler Error Messages.....	B-2
----------------------------------	-----

Contents

Appendix C
Lookout.INI File

Index