

TABLE OF CONTENTS



Chapter 1: Getting Started

Introduction	1-2
Overview of this Publication	1-2
Who Should Read This Manual.....	1-3
Technical Support	1-3
Conventions Used	1-4
Key Topics for Each Chapter	1-4
Product Overview	1-5
What's in the Box	1-6
Mounting / Clearance Information	1-6
Direct Mounting.....	1-6
DIN Rail Mounting	1-7
Agency Approvals	1-7

Chapter 2: Specifications

Specifications	2-2
LED Indicators	2-3
Dip Switch Information	2-5
Dimensional Drawing	2-6

Chapter 3: Installation, Wiring and Configuration

Safety Guidelines	3-2
Plan for Safety	3-2
Wiring Diagrams	3-3
MB-GATEWAY Configuration	3-4
NetEdit Configuration	3-5

Function Codes Supported..... 3-6
 Log Modbus/TCP and/or RTU requests to SMTPViewer..... 3-6

Chapter 4: Parameters

Home Page 4-2
 Gateway Modbus ID..... 4-3
 Module Name and Module Description 4-4
 IP Setup Configuration Page..... 4-5
 Serial Port Configuration Page 4-6
 Set Up Slave Timeout / Retries Page 4-7
 Gateway Device Status Page..... 4-8
 ① Automatic Reads..... 4-9
 ② Last Modbus TCP Request 4-9
 ③ Last Modbus RTU Request 4-10
 ④ Status Information 4-10
 Setup Automatic Read Page 4-10
 Firmware Updates 4-11

Chapter 5: Automatic Read Feature

Automatic Read Feature 5-2
 Situation 1:..... 5-3
 Situation 2:..... 5-6
 Additional Optimization..... 5-8
 Automatic Read Status Data 5-9

Appendix A: Application Examples

Example 1: Using Modbus Poll to MB-GATEWAY with DL06 Slave..... A-2
 Items needed for this example: A-2
 Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications
 port..... A-2
 Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port. A-3
 Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software. A-7

Example 2: Using Modbus Poll to MB-GATEWAY with CLICK Slave A-11
 Items needed for this example: A-11
 Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC..... A-11
 Step 2: Configure the CLICK serial port and MB-GATEWAY serial port. A-12
 Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software. .. A-18

Example 3: Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave. . A-24
 Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2. A-24
 Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables. A-24
 Step 3: Configure the MRX instruction to read data from the MB-GATEWAY. A-28

Example 4: DirectLogic 06 (H0-ECOM100) as Master (Client) to MB-GATEWAY with Multiple GS Drives as Slaves. A-29
 Step 1: Set up Peer to Peer Configuration A-30
 Step 2: Set the Serial Port Configuration A-31
 Step 3: Set the Communication Parameters A-31
 Step 4: Using Automatic Reads..... A-32
 Step 5: Access the Automatic Read Data A-33
 Step 6: Read and Write from the DL06 A-36

Appendix B: Modbus Error Codes

Modbus Error Codes..... B-2

Index