

Table of Contents

Introduction	*
OP-613 Operator Panel	1
Introduction	1
Applications	1
Features	1
Configuration Options	2
PLC Stand Alone	2
PLC Multi Panels	2
Use With A PLC	3
Memory Mapping	3
Register Definition	3
Operational Overview	4
Reading a Setpoint	4
Writing a Display Point	4
Forcing a Setpoint	4
Reading Pushbutton Status	4
Turning On a Lamp	4
Flashing An Insert LED	4
Turning On the Insert Indicator Light	4
Flashing An Insert LED	4
Button Force Commands	5
Examples of Use with A PLC <i>Direct PLC</i>	6
Register Usage	6
Operations With Lights and Buttons	7
Turning On a Lamp	7
Flashing a Lamp	7
Using a Function Button	7
Lighting an Inset LED	7
Flashing an Inset LED	7
Setpoint and Display Operations	8
Displaying Numeric Data	8
Reading a Setpoint	8
Using Force Functions	9
Forcing Button Status	9
Forcing Setpoints	10
Examples of Use with an Allen-Bradley PLC	11
Interfacing to A-B Memory	11
Operations With Lights and Buttons	12
Turning On a Lamp	12
Flashing a Lamp	12
Using a Function Button	12
Lighting an Inset LED	12
Flashing an Inset LED	12
Setpoint and Display Operations	13
Displaying Numeric Data	13
Reading a Setpoint	13

Using Force Functions	14
Forcing Button Status	14
Forcing Setpoints	15
Set Up and Interconnect	16
Legending the Lamps and Function Keys	16
Connection to the System	17
Connections to a Computer or PLC	17
Serial Connection to OP-9001 Communications Master	17
Termination	17
Power	17
Configuration	18
Configuration Selections	19
Single Panel PLC Based Systems	19
Multi Panel PLC Applications (Uses Communications Master)	19
Label Templates	20
Specifications	21
Physical	21
Electrical	21
Communications	21
Communications Failure Operation	21
Panel Mounting Dimensions	21
Appendix A, Example Programs	A-1
Understanding the Example Programs	A-2
Software Requirements	A-2
9 Steps to Using the Example Programs	A-3
Step 1: Power Supply Connections	A-3
Step 1A: Multi-Panel Power Supply Connections (Optional)	A-3
Step 2: Selecting Configuration Mode: Setting the OP-Panel DIP Switches	A-4
Step 3: Selecting Cables	A-4
Choosing Your Connecting Cables	A-5
Connecting Cable Details	A-6
Step 4: Connecting Configuration Cable OP-ACBL-1	A-7
Step 5: Installing Example Programs on Your Personal Computer Hard Drive	A-7
Step 6: Loading OP-WINEDIT Example Program into the OP-Panel	A-8
Step 7: Setting the OP-Panel DIP Switch Positions for Program/Run Mode	A-9
Step 8: Loading <i>DirectSOFT</i> Example Program into the PLC	A-9
Step 9: Connecting the OP-Panel to the PLC and Running the Program	A-9
Running the OP-613 Example Program	A-10
OP-9001 Multi-Panel Configurations	A-11
Appendix B, Troubleshooting the OP-613	B-1
Troubleshooting the OP-613 Panel	B-2
Troubleshooting	B-2
Panel Configuration Problems	B-2
Panel to PLC Communications Problems	B-3
Allen-Bradley Panel to PLC Communications Problems	B-4