


## RHINO Installation Instructions for PSN24-120 Power Supply

### READ INSTRUCTIONS BEFORE INSTALLING OR OPERATING THIS DEVICE. KEEP FOR FUTURE REFERENCE.












	Overload LED	DC OK LED	DC OK Contact
Normal mode	OFF	ON	Closed
During Power Boost	OFF	ON	Closed
Overload (V <sub>out</sub> < 90%)	Flashing	OFF	Open
Output short circuit	Flashing	OFF	Open
Temperature shut down	Flashing	OFF	Open
No input power	OFF	OFF	Open

Figure 4







#### 1. Safety instructions

- An easily accessible disconnecting device shall be provided to disconnect the unit from the mains supply for servicing.
- Switch main power off before connecting or disconnecting the device. Risk of explosion!
- If the unit is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- To guarantee sufficient convection cooling, please refer to the following instructions to ensure sufficient clearance around the device.

Vertical Mounting: 40 mm [1.57 in] above and 20 mm [0.79 in] below the device as well as a lateral distance of 5 mm [0.20 in] to other units. In case the adjacent device is a heat source, the lateral distance will be 15 mm [0.59 in]. Horizontal Mounting: 40 mm [1.57 in] above and below the device as well as a lateral distance of 20 mm [0.79 in] to other units.

- The external enclosure where the unit will be installed shall meet the requirements for mechanical, electrical and fire enclosure.
- Note that the enclosure of the device can become very hot depending on the ambient temperature and load of the power supply. Risk of burns!
- The main power must be turned off before connecting or disconnecting wires to the terminals!
- · Do not introduce any objects into the unit!
- Dangerous voltage present for at least 5 minutes after disconnecting all sources of power.
- The power supplies are built in units and must be installed in a cabinet or room (condensation free environment and indoor location) that is relatively free of conductive contaminants.
- CAUTION: "For use in a controlled environment".

#### 2. Device description (Fig. 1)

- (1) Input terminal block connector
- (4) DC OK control LED (green)
- (2) Output terminal block connector
- (5) Overload LED (red)
- (3) DC voltage adjustment potentiometer
- (6) 35mm DIN rail mounting (DIN rail sold separately)

#### 3. Mounting and dismounting (Fig. 2, Fig. 3)

The power supply unit can be mounted on 35 mm DIN rails in accordance with EN60715. For Vertical Mounting, the device should be installed with input terminal block on the bottom. For Horizontal Mounting, the device should be installed with input terminal block on the left side.

Each device is delivered ready to install.

- 1. Tilt the unit slightly upwards and put it onto the DIN rail. Snap on the DIN rail as shown in Fig. 2.
- 2. Push downwards until stopped.
- 3. Press against the bottom front side for locking.
- 4. Shake the unit slightly to ensure that it is secured.
- 5. To uninstall, pull or slide down the latch as shown in Fig. 3. Then, slide the PSU in the opposite direction, release the latch and pull out the PSU from the rail.

#### 4. Connection

The terminal block connectors allow easy and fast wiring.

You can use flexible (stranded wire) or solid cables with the following cross sections:

Table 1	Standard / Solid		Torque	
Refer to Fig. 1:	(mm²)	(AWG)	(Nm)	(lb in)
(1)	0.82-8.4	18-8	0.91	8.1
(2)	0.82-3.3	18-12	0.61	5.4

To secure reliable and shock proof connections, the stripping length should be 7 mm [0.28 in] (see Fig. 5 (1)). Please ensure that wires are fully inserted into the connecting terminals as shown in Fig. 5 (2). All wire strands must be fully inserted into the terminals with the screws securely fastened in order to ensure safety and maximum contact. In accordance to EN 60950 / UL 60950, flexible wires require ferrules.

Use appropriate copper wire that is designed to sustain operating temperature of :

- 1. At least 60°C / 75°C (140°F / 167°F) for USA.
- 2. At least 90°C (194°F) for Canada and IEC/EN61010-1, IEC/EN61010-2-201.

#### 4.1. Input connection (Fig. 1, Fig. 6)

For AC input connections, use L, N and PE connections on the input terminal connector (see Fig. 1 (1)) to establish the 100-240 VAC connection. Fig. 6 shows the connection to the various network types.

For DC input connections, connect L pin to + from DC source and connect N pin to – from DC source.

The unit is protected with internal fuse (not replaceable) at L pin and it has been tested and approved on 20A (UL) and 16A (IEC) branch circuits without additional protection device. An external protection device is only required if the supplying branch has an ampacity greater than above. Thus, if an external protective device is necessary, or, utilized, a minimum value of 6A B- or 3A C- characteristic breaker should be used.



The internal fuse must not be replaced by the user.

#### 4.2. Output Connection (Fig. 1 (2))

Use the "+" and "-" screw connections to establish the 24 VDC connection. The output provides 24 VDC. The output voltage can be adjusted from 24 to 28 VDC on the potentiometer. The green LED DC OK displays correct function of the output (Fig. 1 (4)). The device has a short circuit and overload protection and an overvoltage protection limited to 35 VDC.

#### 4.3. Output characteristic curve

The device functions normal under operating line and load conditions. In the event of an over load ( $I_O > 150\%$ ) the output voltage will start to droop and bounce until over load has been removed. If the loads are in short circuit, the secondary voltage will bounce and recover once the short circuit has been removed.

- 4.4. Indicators and relay contacts (Fig. 4)
- 4.5. Thermal behavior (Fig. 7)

If the output capacity is beyond what is recommended in Fig. 7, the device will run into thermal protection by switching off i.e. device will go in bouncing mode and will recover when ambient temperature is lowered or load is reduced as far as necessary to keep device in working condition.

FOR TECHNICAL ASSISTANCE CALL 770-844-4200

# **Technical Data For PSN24-120**

Input (AC)			
Nominal input voltage / frequency	100-240 VAC / 50-60Hz; or		
Voltage range	110-300 VDC (for ITE only)		
Frequency	85-264 VAC (DC input range 88-375 VDC) 47-63Hz		
	< 1.34 A @ 100 VAC, < 0.62 A @ 230 VAC		
Nominal current	< 1.25 A @ 110 VDC, < 0.46 A @ 300 VDC		
Inrush current limitation (+25°C, cold start)	9 A typ. @ 120 VAC, 11 A typ. @ 230 VAC		
Mains buffering at nominal load (typ.)	34 ms typ. @ 120 VAC, 65 ms typ. @ 230 VAC		
Turn-on time	< 750 ms @ 120 VAC & 230 VAC		
Internal fuse	T 3.15 A / 500 VAC or 400 VDC min.		
	TN/TT-system / IT-system: < 0.19 mA / 0.48 mA @ 110 VAC, 50Hz		
Leakage current	TN/TT-system / IT-system: < 0.22 mA / 0.58 mA @ 132 VAC, 50Hz		
Out (DO)	TN/TT-system / IT-system: < 0.48 mA / 1.18 mA @ 264 VAC, 50Hz		
Output (DC)	21/102		
Nominal output voltage U <sub>N</sub>	24 VDC		
Adjustment range of the voltage	24-28 VDC 5 A (Vout = 24 VDC)		
	4.5 A (Vout = 24 VDC)		
Nominal current	7.5 A (for 5 s, Vout = 24 VDC)		
	6.7 A (for 5 s, Vout = 28 VDC)		
Doroting	> 60°C [140°F] (2.5% / °C) in Vertical		
Derating	> 50°C [122°F] (2.5% / °C) in Horizontal		
Startup with capacitive loads	10,000 μF typ.		
Max. power dissipation idling / nominal load approx.	4.3W / 9.4W		
Efficiency	91.6% typ. @ 120 VAC, 92.7% typ. @ 230 VAC		
PARD (20MHz) at 100% load	<50 mVpp		
Max. relay contact rating	30V (SELV) / 1 A resistive load		
Parallel operation	PSB60-REM20S / PSB60-REM40S		
General Data			
Type of housing	Aluminum		
Signals	Green LED DC OK		
	Red LED Overload > 1,800,000 hrs. as per Telcordia SR-332		
MTBF	(I/P: 100 VAC; O/P: 24V, 5 A; Ta: 25°C)		
Dimensions (L x W x H)	124 mm x 40 mm x 117 mm [4.88 in x 1.57 in x 4.61 in]		
Weight	0.63 kg [1.39 lb]		
Connection method	Screw connection		
Wire size / torque	Sciew Confliction See Table 1		
Stripping length	7 mm [0.28 in]		
Operating temperature (surrounding air temperature)	-25°C to +70°C [-13°F to 158°F] (Refer to Fig. 7)		
Storage temperature	-40°C to +85°C [-40°F to 185°F]		
Humidity at +25°C, no condensation	5 to 95% RH		
Vibration (non-operating)	10 to 500Hz @ 30m/S <sup>2</sup> (3G peak); displacement of 0.35mm; 60 min. per axis for all X, Y, Z directions in acc. with IEC60068-2-6		
Shock (non-operating, in all directions)	30G (300m/S²) in all directions according to IEC60068-2-27		
Pollution degree	2		
Altitude (operating)	5000m; 2500m for IEC/EN61558		
Certification and Standards			
Electrical equipment of machines	IEC60204-1 (over voltage category III)		
Electronic equipment for use in electrical power installations	IEC/EN 62477-1 / IEC62103		
Safety entry low voltage	PELV (EN 60204-1), SELV (EN 60950-1)		
Electrical safety (of information technology equipment)	UL/C-UL recognized to UL60950-1 and CSA C22.2 No. 60950-1 (File No. E198298),		
	CB scheme to IEC 60950-1, IEC 61558-1, IEC 61558-2-16, IEC 61010-1, IEC 61010-2-201		
Industrial control equipment	UL/C-UL listed to UL508 and CSA C22.2 No. 107.1-01 (File No. E197592), CSA to CSA C22.2 No. 107.1-01 (File No. 249074)		
CE Component power cumply for general use	In conformance with EMC directive 2014/30/EU and low voltage directive 2014/35/EU		
Component power supply for general use	ENG1204-3 EN 55024, EN 61000-6-2		
Immunity	(EN61000-4-2, 3, 4, 5, 6, 8, 11, 12)		
Emission	EN55032, EN55011, EN61000-3-2 Class A, EN61000-3-3, EN61000-6-3		
2.11001011			
	249074 249074		
CE			
	LISTED Ind. Cont. Eq. E198298		
	inu. vont. Ly. L130230		
RoHS Compliant	Yes		
Safety and Protection			
Transient surge voltage protection	VARISTOR		
Current limitation at short-circuits approx.	Isurge = 150 % of Pomax typically (hiccup mode)		
Surge voltage protection against internal surge voltages	Yes		
Isolation voltage:			
Input / Output	4.54 kVAC		
Input / PE	2.50 kVAC		
Input / DC OK*	4.54 kVAC		
Output / PE	1.50 kVAC		
Output / DC OK	0.50 KVAC		
DC OK / PE	1.50 KVAC		
	IP20		
Protection degree Safety class	Class I with GND connection		

<sup>\*</sup>Recommend connecting DC OK pins to output pins.