



# TABLE OF CONTENTS

---

<b>Chapter 1: Hardware</b> .....	<b>1-1</b>
Introduction .....	1-2
Conventions Used .....	1-2
Product Overview .....	1-3
Managed Switch Accessories .....	1-5
General Information .....	1-6
LED Indicators .....	1-9
Installation, Plastic Case Switches .....	1-11
Installation, Metal Case Switches .....	1-12
Power and Alarm Wiring .....	1-25
Communication Ports Wiring .....	1-27
Technical Specifications .....	1-31
<b>Chapter 2: Managed Switch Quick Start</b> .....	<b>2-1</b>
<b>Connecting to the Switch for the first time</b> .....	<b>2-2</b>
Connecting to the switch over Ethernet: .....	2-2
Setting up PC for USB connection to switch: .....	2-7
PC to switch using Serial Port: .....	2-8
USB and Serial connection to switch with Terminal Software Program: .....	2-9
<b>Default Setup</b> .....	<b>2-13</b>
<b>Why might you need a Managed Switch?</b> .....	<b>2-16</b>
Enhanced traffic filtering: .....	2-16
Troubleshooting: .....	2-16
Redundancy: .....	2-16
Security: .....	2-17
Better Network 'Awareness': .....	2-18

<b>Chapter 3: Managed Switch Software Monitoring</b> . . . . .	<b>3-1</b>
System Information . . . . .	3-2
Port and Power Status . . . . .	3-4
Network Statistics . . . . .	3-5
Spanning Tree Status . . . . .	3-8
Real-Time Ring Status . . . . .	3-10
Multicast Filtering Status . . . . .	3-11
IGMP Port Status: . . . . .	3-11
IGMP Group Status: . . . . .	3-12
MAC Table . . . . .	3-13
Configuration Summary . . . . .	3-14
<b>Chapter 4: Managed Switch Software Setup</b> . . . . .	<b>4-1</b>
Main Settings . . . . .	4-2
System Settings . . . . .	4-2
Remote Access Security . . . . .	4-4
Port Settings . . . . .	4-6
Port Mirroring . . . . .	4-8
Set IP per Port . . . . .	4-9
Switch Time Settings . . . . .	4-10
Manage Firmware . . . . .	4-11
Install Firmware . . . . .	4-12
Redundancy Settings . . . . .	4-14
Spanning Tree Settings . . . . .	4-18
Spanning Tree Port Settings . . . . .	4-21
Real-Time Ring Settings . . . . .	4-23
RSTP Examples . . . . .	4-24
Traffic Priority (Priority Queuing QoS, CoS, ToS/DS) . . . . .	4-29
QoS / CoS Settings . . . . .	4-30
802.1p Tag Settings . . . . .	4-31
Message Rate Limiting . . . . .	4-32
QoS Example . . . . .	4-33
Multicast Filtering (IGMP) . . . . .	4-36

IGMP Protocol Settings . . . . .	4-37
Port Settings. . . . .	4-38
IGMP Example . . . . .	4-39
<b>Virtual LANs (VLANs). . . . .</b>	<b>4-40</b>
VLAN Settings . . . . .	4-41
VLAN Port Settings. . . . .	4-43
VLAN with RSTP. . . . .	4-44
VLAN Examples . . . . .	4-46
<b>Security Settings . . . . .</b>	<b>4-51</b>
Remote Access Security . . . . .	4-51
Port Security Enables and Port Security MAC Entries . . . . .	4-52
IPsec Settings . . . . .	4-54
IKE Policy . . . . .	4-57
IKE Pre-shared Keys . . . . .	4-59
IKE Certificates . . . . .	4-60
<b>Monitoring Settings . . . . .</b>	<b>4-62</b>
Alarm (OK) Output. . . . .	4-62
Modbus . . . . .	4-63
Register Mapping: . . . . .	4-64
SNMP Notifications . . . . .	4-65
<b>Chapter 5: Managed Switch Software Advanced Operations . . . . .</b>	<b>5-1</b>
<b>Configuration Management . . . . .</b>	<b>5-2</b>
<b>Restore Factory Defaults . . . . .</b>	<b>5-4</b>
<b>Reset Switch. . . . .</b>	<b>5-5</b>
<b>Update Firmware. . . . .</b>	<b>5-6</b>
Update Firmware using a TFTP Server: . . . . .	5-6
<b>Appendix A: Troubleshooting . . . . .</b>	<b>A-1</b>
<b>Troubleshooting Fiber Connections: . . . . .</b>	<b>A-2</b>
<b>Troubleshooting Real-Time Ring. . . . .</b>	<b>A-4</b>
<b>Troubleshooting VLANs. . . . .</b>	<b>A-6</b>
<b>Installing Switch Firmware . . . . .</b>	<b>A-8</b>

<b>Appendix B: Glossary</b> .....	<b>B-1</b>
Glossary of Terms .....	B-2
<b>Appendix C: Switch Settings</b> .....	<b>C-1</b>
General Switch Information .....	C-2
Alarm Configuration .....	C-2
Mirror Configuration .....	C-3
VLAN Configuration .....	C-3
Port Configuration .....	C-3
QoS Configuration .....	C-3
<b>Appendix D: CLI Commands</b> .....	<b>D-1</b>
Introduction .....	D-2
Accessing the CLI .....	D-2
<b>CLI Commands:</b> .....	<b>D-3</b>
Global Commands: .....	D-3
Access Configuration: .....	D-3
Alarm Configuration: .....	D-4
Modbus Configuration: .....	D-4
Info Configuration: .....	D-4
Network Configuration: .....	D-5
Ring Configuration: .....	D-6
RSTP Configuration: .....	D-7
QoS Configuration: .....	D-7
VLAN Configuration: .....	D-8
IGMP Configuration: .....	D-9
Checkpoint Configuration: .....	D-9
Firmware Configuration: .....	D-9
TFTP Configuration: .....	D-9
Timezone Configuration: .....	D-10
MSTI Configuration: .....	D-10
General Configuration: .....	D-10

<b>Appendix E: License Agreements</b> .....	<b>E-1</b>
Overview .....	E-2
PCRE Library .....	E-2
libpcap Software .....	E-3
lighttpd Software .....	E-3
spawn-fcgi Software .....	E-4
ipsec-tools Software .....	E-4
net-snmp Software .....	E-6
FastCGI Library .....	E-11
watchdog Software .....	E-12
GPLv2 (General Public License v2) .....	E-12
Crossbrowser/x-tools Library .....	E-18
OpenSSL License .....	E-30
Open SSH License .....	E-32
PPP License .....	E-33
Shadow License .....	E-39
Sudo License .....	E-41

