# Schmersal Configurable Safety Relays



## **SRB-E Electronic Safety Relays**

The SRB-E modules are a series of multi-functional, configurable electronic safety relays. Each module can be adjusted to one of multiple preset configurations, which include selecting the type of reset, activating or deactivating cross-wire monitoring, and selecting the monitored contact configuration – all via the rotary dial on the front of the unit.

The SRB-E series provides a higher level of diagnostic capabilities with LEDs for both controller status as well as error fault codes, assisting with troubleshooting safety circuits.

Once the configurations have been set, the lid may be closed and sealed to prevent tampering with the settings.

## SCHMERSAL

### Features

- Modules with safe PNP outputs
- Modules with safe relay outputs
- Modules with monitoring of two-hand controls
- Modules with monitored input expansion up to Cat 4 PLe
- Fast cycle times (60 switching cycles/ min)
- Modules with high 5.5A PNP switching capacity
- Snap-in blank equipment labels
- Removable terminal blocks for easy wiring

Schmersal SRB-E Electronic Safety Relays Selection Chart																					
			Emergency stop monitoring	Safety guard monitoring	Pull wire emergency stop	Magnetic safety sensors	Light curtains	Input expander module for up to 4 sensors	Two hand control panels	Input signals: 1 channel	Input signals: 2 channel	Input signals: antivalent	Cross-wire detection	Start button/ autostart	Start button with edge detection	Safe Stop 0 dry contact	Safe Stop 0 semiconductor	Safe Stop 1 dry contact	Safe Stop 1 semiconductor	Not safe dry contact	Not safe semiconductor
Part Number Price Drawing		Applications				✓ ALLOWABLE  Input Signals  Start Conditions					Output Contacts										
							I				-	-		Cona				<u> </u>			
SRB-E-201LC	\$171.00	<u>PDF</u>	✓	✓	✓	✓	✓			✓	✓	✓	✓		✓		2				1
<u>SRB-E-201ST</u>	\$257.00	<u>PDF</u>	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓		✓		2				1
SRB-E-201ST-CC	\$269.00	<u>PDF</u>	~	$\checkmark$	✓	$\checkmark$	✓		✓	$\checkmark$	✓	$\checkmark$	$\checkmark$		✓		2				1
<u>SRB-E-301ST</u>	\$216.00	<u>PDF</u>	$\checkmark$	$\checkmark$	✓	✓	✓			✓	✓	✓	$\checkmark$	✓	✓	3				1	
SRB-E-301ST-CC	\$228.00	<u>PDF</u>	✓	$\checkmark$	✓	✓	✓			✓	✓	✓	$\checkmark$	✓	✓	3				1	
<u>SRB-E-402EM</u>	\$191.00	<u>PDF</u>	$\checkmark$	✓	✓	✓	✓			✓	✓	✓	$\checkmark$	✓	✓	4				2	
<u>SRB-E-232ST</u>	\$366.00	<u>PDF</u>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$			$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$		$\checkmark$		2	3		1	1
SRB-E-232ST-CC	\$378.00	PDF	$\checkmark$	~	~	✓	~			✓	~	~	~		$\checkmark$		2	3		1	1
<u>SRB-E-322ST</u>	\$366.00	PDF	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$			$\checkmark$	✓	$\checkmark$	$\checkmark$		✓	3			2	1	1
SRB-E-322ST-CC	\$378.00	<u>PDF</u>	$\checkmark$	✓	✓	✓	✓			✓	✓	✓	$\checkmark$		✓	3			2	1	1
SRB-E-204ST	\$272.00	<u>PDF</u>	$\checkmark$	✓	✓	✓	✓	✓		✓	✓	✓	$\checkmark$		✓		2				4
SRB-E-204ST-CC	\$284.00	PDF	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓		✓		2				4
SRB-E-204PE	\$147.00	PDF	$\checkmark$	✓	~	$\checkmark$	✓	$\checkmark$		✓	~	✓	$\checkmark$	✓			2				4
Combination Module for Two Protective Devices																					
SRB-E-402ST	\$338.00	PDF	$\checkmark$	✓	✓	✓	✓		✓	✓	✓	✓	$\checkmark$		✓	2	2			1	1
SRB-E-402ST-CC	\$350.00	PDF	~	✓	✓	✓	~		✓	✓	~	~	✓		✓	2	2			1	1

#### Notes:

Stop Category 0 (Stop 0) means immediate loss of power. This is often referred to as an uncontrolled stop.

Stop Category 1 (Stop 1) means there is a delay before the loss of power. The control system should bring the machine to a stop prior to the loss of power. This is often referred to as a controlled stop with removal of power.

## Schmersal SRB-E-201 and SRB-E-301 Configurable Safety Relays



 $\leq 2.66 \times 10^{-9} / h$ 

(valid for dual channel and 60% load)



SRB-E-301ST

#### Features

- Pluggable screw terminals or cage clamps
- SAFE STOP 0 function
- 1 or 2-channel control
- Start button / auto-start
- High 5.5 A PNP switching capacity (201ST only)
- Safe PNP outputs (201LC and 201ST only)
- Safe relay outputs (301ST only)
- Monitoring of two-hand controls (201ST only)

# Safety DataValues per EN ISO 13849-1,<br/>EN 62061, IEC 61508Performance LevelUp to eDC AverageHighSIL CLUp to 3HFT (Hardware Failure Tolerance)1

Schmersal SRB-E-201 and SRB-E-301 Selection Chart												
Part Number	Price	Type Voltage		Connection	Configurations	Safety Input	Safety Output	Monitoring Outputs	Drawing			
SRB-E-201LC	\$171.00	Safety relay	24 VDC	Pluggable screw terminals	10	1 pair digital	2 OSSD 3 NO	1 status	PDF			
SRB-E-201ST	\$257.00		24 VDC		11				PDF			
SRB-E-201ST-CC	\$269.00		24 VDC	Push-in cage clamp	11				PDF			
<u>SRB-E-301ST</u>	\$216.00		24 VAC/VDC	Pluggable screw terminals	12			1 NC	PDF			
SRB-E-301ST-CC	\$228.00		24 VAC/VDC	Push-in cage clamp	12				PDF			

PFH(D)

Schmersal SRB-E-201 and SRB-E-301 Specifications								
Input/Output Specifications								
Operating Temperature	-25°C [-13°F] to 60°C [140°F]							
Storage Temperature	-40°C [-40°F] to 85°C [185°F]							
Altitude	2000m [6562ft] max							
Vibration Resistance	Tested to EN 60068-2-6							
Degree of Protection	IP40							
Housing	Glass-fiber reinforced thermoplastic, ventilated							
Weight	130g [4.59 oz] for 201ST and 201LC 175g [6.17 oz] for 301ST							
Agency Approvals and Standards	CE, UL (listed number E57648)							
Terminal Designation per EN 50005	EN 60947-1							
Wire Fixing	Plug-in terminals							
Cable Section Min/Max	Section Min/Max         0.25 mm² [24 AWG] – 2.5 mm² [14 AWG]							
witching Frequency, Max 0.3 Hz								
Input/Output Specifications								
Operating Voltage Range	19.2 to 28.8 VDC for 201ST and 201LC 19.2 to 28.8 VAC/VDC for 301ST							
Maximum Consumption	2.4 W (plus load of semiconductor outputs)							
Overvoltage Protection	Category III							
Control Voltage on S11 etc.	24VDC							
Control Current Over S12 etc.	8mA							
Mechanical Life	10 <sup>7</sup> operations							
Contact Type	Ag-Ni, self-cleaning, positive drive							
Operating Delay (Pull-In Delay) <150ms								
Release Delay (Drop-Out Delay)	<10ms							
Switching Capacity	201ST: 24VDC, max 5.5 A 201LC: 24VDC, max 2.0 A 301ST: dry contacts, max 250V / 6A							

www.automationdirect.com

S SCHMERSAL

## Schmersal SRB-E-201 and SRB-E-301 Configurable Safety Relays

LED

RUN

ERR

In 1

In 2

Out

elays	
LED Indication Descriptions	
Function	
Operating voltage OK – RUN mode	
Error code	

High level at S12


High level at S22

Outputs activated

NOTE: For flash codes, refer to product manual

Configuration Selection									
Rotary Knob Position	Reset Button	Cross-Wire Monitoring Active	Input / Sensor Configuration	Monitoring of Sensor Channels For Synchronization					
С	Configuration Mode								
1	Trailing Edge	Yes	NC / NC	Yes					
2	Trailing Edge	Yes	NC / NC	No					
3	Trailing Edge	No	NC / NC	Yes					
4	Trailing Edge	No	NC / NC	No					
5	Trailing Edge	Yes	NC / NO	Yes					
6	Autostart	Yes	NC / NO	No					
7	Autostart	Yes	NC / NC	Yes					
8	Autostart	Yes	NC / NC	No					
9	Autostart	No	NC / NC	Yes					
10	Autostart	No	NC / NC	No					
11	Function two-hand c	ontrol type IIIC (SRB-E-201ST)	NC/NO, NC/NO	Yes					
	SRB-E-301ST: Evaluation of safety mats SMS								
12	Autostart	No	NC / NC	No					
13	Trailing Edge	No	NC / NC	No					


**Terminal Descriptions** Pin Function Operating voltage A1 + 24 VDC 24 VAC (SRB-E-301ST) Operating voltage A2 0 V 24 VAC (SRB-E-301ST) **X**2 Input of start circuit Х3 Input feedback circult **X**7 Input release signal S11/S21 Test pulse outputs S12 Input channel 1 S22 Input channel 2 Y1 Signalling output (NC) 41/42 Signalling contact (NC) Q1/Q2 13/14 Safety outputs 23/24 33/34



## Schmersal SRB-E-201 and SRB-E-301 Configurable Safety Relays




## Application Example for SRB-E-201ST and SRB-E-201LC



#### Кеу

- a) Safety inputs
- b) Safety outputs
- c) Signalling outputs
- d) Clock outputs
- e) Processing
- f) Power

## Application Example for SRB-E-301ST



#### Кеу

- a) Safety inputs b) Safety outputs
- c) Signalling outputs
- d) Clock outputs
- e) Processing
- f) Power

## **Safety Products**



Warning: Safety products sold by AutomationDirect are Safety components only. The purchaser/installer is solely responsible for the application of these components and ensuring all necessary steps have been taken to assure each application and use meets all performance and applicable safety requirements and/or local, national and/or international safety codes as required by the application. AutomationDirect cannot certify that our products, used solely or in conjunction with other AutomationDirect or other vendors' products, will assure safety for any application. Any person using or applying any products sold by AutomationDirect is responsible for learning the safety requirements for their individual application and applying them, and therefore assumes all risks, and accepts full and complete responsibility, for the selection and suitability of the product for their respective application.

AutomationDirect does not provide design or consulting services, and cannot advise whether any specific application or use of our products would ensure compliance with the safety requirements for any application.